


FILE NO.

SERVICE MANUAL

Remote Control Digital Color Television

HT30744 (U.S.A.) (CANADA) ORIGINAL VERSION



Chassis No. 30744-00

NOTE: Match the Chassis No. on the unit's back cover with the Chassis No. in the Service Manual.

> If the Original Version Service Manual Chassis No. does not match the unit's, additional Service Literature is required. You must refer to "Notices" to the Original Service Manual prior to servicing the unit.

Contents

Safety Instructions 2
Service Adjustments 3 - 17
Service Hints 18
Mechanical Disassemblies 19
Chassis Electrical Parts List 20 - 40
Cabinet Parts List 41
Component and Test Point
Locations
Block Diagrams 50 - 55
Troubleshooting Flow Charts 56 - 58
Control Port Function 59
Schematic Inserts 61 – 76
Schematic Notes 61
Pin Layouts61
Capacitor and Resistor Codes 61
Board Connections & Locations, 62 - 64
Waveforms62 - 64
Main Board 65 – 68
A/V Select and Video Boards 69 – 72
VM Board
CRT Socket Board
Power and Deflection Board74 - 76
Front Board

Specifications

Specifications
Power Rating 120V, 60Hz
140W (Avg), 2.5A (Max)
Antenna Input Impedance
UHF/VHF/CATV
Digital
Receiving Channel 2 - 13 (VHF),
14 - 69 (UHF),
01, 14-94, 95-125 (CATV)
1 - 99 (Digital)
Remote Ready 52 Key Remote Control
Sound Output 5.0 W/CH
Intermediate Frequency
Picture IF Carrier 45.75MHz
Sound IF Carrier 41.25MHz
Color Sub Carrier 42.17MHz
Picture Tube W76QEN693X100
Semiconductors
Integrated Circuits
Transistors89
Except within Tuner, RC Pre-Amp. & Digital Module
Cabinet Dimensions
Width908 mm
Height
Depth

REFERENCE No. SM780094

HT30744, H3GLM, PRODUCT CODE 111370290

SAFETY INSTRUCTIONS

SAFETY PRECAUTIONS

WARNING: The chassis of this receiver has a floating ground with the potential of one half the AC line voltage in respect to earth ground. Service should not be attempted by anyone not familiar with the precautions necessary when working on this type of equipment.

The following precautions must be observed:

- An isolation transformer must be connected in the power line between the receiver and the AC line before any service is performed on the receiver.
- 2. Comply with all caution and safety-related notes provided on the side of the cabinet, inside the cabinet, on the chassis, and the picture tube.
- When replacing a chassis in the cabinet, always be certain that all the protective devices are installed properly, such as control knobs, adjustment covers, shields and barriers.

DO NOT OPERATE THIS TELEVISION RECEIVER WITHOUT THE PROTECTIVE SHIELD IN POSITION AND PROPERLY SECURED.

4. Before replacing the back cover of the set, thoroughly inspect the inside of the cabinet to see that no stray parts or tools have been left inside.

Before returning any television to the customer, the service technician must perform the following safety checks to be sure that the unit is completely safe to operate without danger of electrical shock.

ANTENNA COLD CHECK


Remove AC plug from the 120 VAC outlet and place a jumper across the two blades. Connect one lead of an ohmmeter to the jumpered AC plug, and touch the other lead to each exposed antenna terminal (UHF and VHF antenna terminals). The resistance must measure between 1M ohm and 5.2M ohm. Any resistance value below or above this range indicates an abnormality which requires corrective action.

LEAKAGE CURRENT CHECK

Plug the AC line cord directly into a 120 VAC outlet. (Do not use an isolation transformer for this check.) Use an AC voltmeter, that has 5000 ohms per volt or more sensitivity. Connect a 1500 ohm 10 watt resistor, paralleled by a 0.15 µF 150 VAC capacitor, between a known good earth ground (water pipe, conduit, etc.) and all exposed metal parts of the cabinet (antennas, handle bracket, metal cabinet, screw heads, metal overlays, control shafts, etc.). Measure the AC voltage across the 1500 ohm resistor. The AC voltage should not exceed 750 mV. A reading exceeding 750 mV indicates that a dangerous potential exists. The fault must be located and corrected. Repeat the above test with the receiver power plug reversed.

NEVER RETURN A RECEIVER TO THE CUSTOMER WITHOUT TAKING THE NECESSARY CORRECTIVE ACTION.

READING SHOULD NOT EXCEED 750 mV. AC VOLTMETER (5000 ohms per volt or more sensitivity)



X-RADIATION PRECAUTION

The primary source of X-RADIATION in solid-state receivers is the picture tube. The picture tube is specially constructed to limit X-Ray emission. For continued X-RADIATION protection, the replacement tube must be the same type as the original (including the suffix letter in the part numbers). Excessive high voltage may produce potentially hazardous X-RADIATION. To avoid such hazards, the high voltage must be maintained within specific limits. Refer to the X-RADIATION WARNING NOTE on the CHASSIS SCHEMATIC in this service manual for specific high voltage limits. If the high voltage exceeds specified limits, check the components specified on the chassis schematic diagram and take the necessary corrective action. Carefully follow the instructions for the +B Voltage Check and the High Voltage Check to maintain the high voltage within the specified limits.

HIGH VOLTAGE HOLD-DOWN TEST

To prevent X-RADIATION from the picture tube due to excessive high voltage, a HOLD-DOWN circuit is provided in the high voltage circuit. Every time the receiver is serviced, the high voltage HOLD-DOWN circuit must be tested for proper operation. Refer to the HIGH VOLTAGE HOLD-DOWN TEST in service adjustments.

PRODUCT SAFETY NOTICE

When replacing components in a receiver, always keep in mind the necessary product safety precautions. Pay special attention to the replacement of components marked with a star (*) in the parts list and in the schematic diagrams. To ensure safe product operation, it is necessary to replace those components with the exact same PARTS.

SERVICE ADJUSTMENTS

GENERAL

This set has an On-screen Service Menu system included in the CPU that allows remote operation for most of the service adjustments.

ON-SCREEN SERVICE MENU SYSTEM

1. Enter the Service Menu:

 While pressing the -VOLUME key on the front control panel, reconnect the AC power cord. The Service Menu Display will now appear. The remote can now be used to make adjustments.
 See Figure 1.

2. Service Adjustments:

- Press the Channel ▲ or ▼ key to select the desired service menu you want to adjust. See page 5 for On-screen Service Menu.
- Use the Volume + or key or numeric keys to adjust the data.
 (For Sub Address see below)




Figure 1. Service Menu Display

3. Exit from the Service Menu:

Press the MENU key to turn off the Service Menu display.

ADJUSTMENT FOR SUB ITEM (ADDRESS)

Some service data have Sub - Addresses. Use the numeric keys (from 0 to 7), to adjust the Sub - item data.

ADJUST DATA OF SUB-TITLE

1. Find the title and its bit of binary data from Table 1 (On-Screen Service Menu).

(b7) (b6) (b5) (b4) (b3) (b2) (b1) (b0)

O 1 O 1 O 1 1 O

BINARY DATA (8 bit)

- 2. Enter the service menu (see above) and select the item number needed with the Channel ▲ or ▼ key.
- 3. With the numeric key (from 0 to 7), change the bit data. Each time the numeric key is pressed, the data changes from 0 to 1 alternately. For example, to change the data of bit 5, press the "5" key.

NOTE: The ▲ and ▼ symbols used in the following service adjustments refer to the Channel up and down keys not the Menu keys.

IC802 (EEPROM) REPLACEMENT

When IC802 (EEPROM) is replaced, IC801 (CPU) will automatically write the initial reference data into IC802 for basic TV operation. However, the bus data should be checked and some bus data should be set up before attempting the service adjustments. (See Table 1. on pages 5 – 11 for detailed bus data information.)

INITIAL BUS DATA SETUP

Note: When IC802 (EEPROM) is replaced, change the following initial reference data for proper TV operation before attempting service adjustments.

- 1. Disconnect the AC power cord (AC 120V line).
- 2. While pressing the MENU key, reconnect the AC power cord. The Service Menu display will now appear.
- 3. Select NO. 102 SHU2PO (Sub Hue / Pre/Over Shoot) with ▲ or ▼ key. Adjust the data with number keys for 1F.
- 4. Select NO. 103 SLC2CTI (Sub Color / CTI Level) with ▲ or ▼ key. Adjust the data with number keys for 21.
- 5. Select NO. 105 SSH2LTI (Sub Sharp / LTI Level) with ▲ or ▼ key. Adjust the data with number keys for 89.
- 6. Select NO. 106 RD2PTL (R Drive / P Limit Level) with ▲ or ▼ key. Adjust the data with number keys for 70.
- 7. Select NO. 108 BD2CTIM1 (B Drive / CTI Mode) with ▲ or ▼ key. Adjust the data with number keys for 78.
- 8. Select NO. 109 SBR2GAM (Sub Bright / Gamma) with ▲ or ▼ key. Adjust the data with number keys for 2A.
- 9. Select NO. 10A RCT2LTIM1 (R Cutoff / LTI Mode) with ▲ or ▼ key. Adjust the data with number keys for 88.
- 9. Select NO. 10B GCT2DPL (G Cutoff / DPIC Level) with ▲ or ▼ key. Adjust the data with number keys for 5D.
- 10. Select NO. 10C BCT2DCT (B Cutoff / DC Transit) with ▲ or ▼ key. Adjust the data with number keys for 75.
- 11. Select NO. 10F CBOF2AW1AB (CB Offset / Aging W / Aging B) with ▲ or ▼ key. Adjust the data with number keys for 94.
- 12. Select NO. 110 CROF2SYS (CR Offset / System) with ▲ or ▼ key. Adjust the data with number keys for B8.
- 13. Select NO. 114 VML4FLC2FLS (VM Level / FLCOL / FLCOL Switch) with ▲ or ▼ key. Adjust the data with number keys for F2.
- Select NO. 116 VS (V Size) with ▲ or ▼ key. Adjust the data with number keys for 86.

INITIAL BUS DATA SETUP (Cont.)

- 15. Select NO. 117 VPS (V Position) with ▲ or ▼ key. Adjust the data with number keys for 74.
- 16. Select NO. 118 VLI4SCR (V Lin / s Correction) with ▲ or ▼ key. Adjust the data with number keys for 63.
- 17 Select NO. 119 HSI2UUC (H Size / Up UCP) with ▲ or ▼ key. Adjust the data with number keys for 84.
- 18. Select NO. 11A PAP2LUP (Pin Amp / Lo UCP) with ▲ or ▼ key. Adjust the data with number keys for 6C
- 19. Select NO. 11B UCP 2UUG (Up CPin / Up UCG) with ▲ or ▼ key. Adjust the data with number keys for 80.
- 20. Select NO. 11C LCP2LUG (Up CPin / Lo UCG) with ▲ or ▼ key. Adjust the data with number keys 78.
- 21. Select NO. 11D PPH2UPO1VBS (Pin Phase / Uc Pol / V Blk Sw) with ▲ or ▼ key. Adjust the data with number keys 6D.
- 22. Select NO. 11E HPO2CSH1NIN (H Position / CLP Shift / Non Inter) with ▲ or ▼ key. Adjust the data with number keys for 79.
- 23. Select NO. 11F ABO2RAM (AFC Bow / RF AFC Mode) with ▲ or ▼ key. Adjust the data with number keys for 7D.
- 24. Select NO. 120 AAN2AGS1 (AFC Angle / AGC Sw) with ▲ or ▼ key. Adjust the data with number keys for 88.
- 25. Select NO. 121 LBK2CPH (Left Blk / CLP Phase) with ▲ or ▼ key. Adjust the data with number keys for BC.
- 26. Select NO. 122 RBK2CGA1HSW (R Blk / CLP Gate / H Blk Sw) with ▲ or ▼ key. Adjust the data with number keys for 9D.
- 27. Select NO. 126 VCP4HCP (V Comp / H Comp) with ▲ or ▼ key. Adjust the data with number keys for 89.
- 28. Select NO. 136 RF-HUE (RF Tint) with ▲ or ▼ key. Adjust the data with number keys for 00.
- 29. Select NO. 137 RF-COL (RF Color) with ▲ or ▼ key. Adjust the data with number keys for 00.
- 30. Select NO. 157 RF-SHP (RF Sharpness) with ▲ or ▼ key. Adjust the data with number keys for FE.
- 31. Select NO. 158 41-SHP (480I Sharpness) with ▲ or ▼ key. Adjust the data with number keys for FE.
- 32. Select NO. 159 4P-SHP (480P Sharpness) with ▲ or ▼ key. Adjust the data with number keys for FE.
- 33. Select NO. 15A 1I-SHP (1080I Sharpness) with ▲ or ▼ key. Adjust the data with number keys for FE. 34. Select NO. 15B 7P-SHP (720P Sharpness) with ▲ or ▼ key. Adjust the data with number keys for FE.
- 35. Select NO. 15C DIGITAL-SHP (Digital Sharpness) with ▲ or ▼ key. Adjust the data with number keys for FE.
- 36. Select NO. 15E RF-LLV (Rf LTl Level) with ▲ or ▼ key. Adjust the data with number keys for 01.
- 37. Select No. 171 RF-CB (RF CB Offset) with ▲ or ▼ key. Adjust the data with number keys for 01.
- 38. Select No. 172 4!-CB (480! CB Offset) with ▲ or ▼ key. Adjust the data with number keys for 01.
- 39. Select No. 173 4P-CB (480P CB Offset) with ▲ or ▼ key. Adjust the data with number keys for FF.
- 40. Select No. 174 1I-CB (1080I CB Offset) with ▲ or ▼ key. Adjust the data with number keys for FE.
- 41. Select No. 175 7P-CB (720P CB Offset) with ▲ or ▼ key. Adjust the data with number keys for FF.
- 42. Select No. 176 D-CB (Digital CB Offset) with ▲ or ▼ key. Adjust the data with number keys for F8.
- 43. Select No. 178 RF-CR (RF CR Offset) with ▲ or ▼ key. Adjust the data with number keys for FF.
- 44. Select No. 179 4I-CR (480I CR Offset) with ▲ or ▼ key. Adjust the data with number keys for F8.
- 45. Select No. 17A 4P-CR (480P CR Offset) with ▲ or ▼ key. Adjust the data with number keys for F9.
- 46. Select No. 17B 1I-CR (1080I CR Offset) with ▲ or ▼ key. Adjust the data with number keys for F6.
- 47. Select No. 17C 7P-CR (720P CR Offset) with ▲ or ▼ key. Adjust the data with number keys for F6.
- 48. Select No. 17D D-CR (Digital CR Offset) with ▲ or ▼ key. Adjust the data with number keys for F6.
- 49. Select No. 184 D-SYS (Digital System) with ▲ or ▼ key. Adjust the data with number keys for 01.
- 50. Select No. 1D3 CWUBK (Video 1/2 Letter Box Lo Blk) with ▲ or ▼ key. Adjust the data with number keys for 08.
- 51. Select No. 1D4 CWLBK (Video 1/2 Letter Box Up Blk) with ▲ or ▼ key. Adjust the data with number keys for 0B.
- 52. Select No. 1FA 4PWLBK (480P letter Box Lo Blk) with ▲ or ▼ key. Adjust the data with number keys for 0B.
- 53. Select No. 20C 7PWUBK (720P Letter Box Up Blk) with ▲ or ▼ key. Adjust the data with number keys for 08.
- 54. Select No. 20D 7PWLBK (720P letter Box Lo Blk) with ▲ or ▼ key. Adjust the data with number keys for 0B.
- 55. Select No. 21F 1IWUBK (1080I-Letter Box Up Blk) with ▲ or ▼ key. Adjust the data with number keys for 08.
- 56. Select No. 220 1IWLBK (1080I-Letter Box Lo Blk) with ▲ or ▼ key. Adjust the data with number keys for 0B.
- 57. Select No. 22B DVPS (Digital Full V Position) with ▲ or ▼ key. Adjust the data with number keys for 01.
- 58. Select No. 258 PUBK (PAP-On Up Blk) with ▲ or ▼ key. Adjust the data with number keys for 08.
- 59. Select No. 259 PLBK (PAP-On Lo Blk) with ▲ or ▼ key. Adjust the data with number keys for 0B.
- 60. Select No. 26B DWUBK (Digital Letter Box Up Blk) with ▲ or ▼ key. Adjust the data with number keys for 08.
- 61. Select No. 26C DWLBK (Digital Letter Box Lo Blk) with ▲ or ▼ key. Adjust the data with number keys for 0B.
- 62. Select No. 043 SHU4SCL (Sub Hue / Sub Color) with ▲ or ▼ key. Adjust the data with number keys for 72.
- 63. Select No. 045 YD3SF2F01CM2 (Y Drive / SHP-F0 / FSC Out / CD Mode) with ▲ or ▼ key. Adjust the data with number keys for 32.
- 64. Select No. 053 HP2V11V2 (HP / V1/ V2) with ▲ or ▼ key. Adjust the data with number keys for 7B.
- 65. Select No. 088 OP2 (Option 2) with ▲ or ▼ key. Adjust the data with number keys for 12.
- 66. Select No. 08C AKB (AKB Detect Time) with ▲ or ▼ key. Adjust the data with number keys for 10.
- 67. Press the MENU key to turn off the Service Menu display.

Table 1. ON-SCREEN SERVICE MENU

When IC802 (EEPROM) is replaced, check the bus data to confirm they are the same as below. The shaded menu should be checked and be set up or readjusted according to the procedures described in the following pages. Initial Setup Data marked with an * should be changed from Initial Reference Data. (See pages 3 and 4 for Initial Bus Data Setup.)

	T	T	т		To Saturday,		
No.	TITLE	INITIAL REFERENCE DATA HEX	INITIAL SETUP DATA HEX	INITIAL SETUP DATA BINARY	FUNCTION		
100	PRGBON4DL2ES1SF	FD	FD	11111101	PIC+R+G+B On(7~4), D COL(3~2), ES1(1):0(fixed), SF(0)		
101	BLKBTM	00	00	00000000	BLK_BTM(1~0)		
102	SHUZPO	1975 (123 Spring)	104	00011111	SUB-HUE(7-2); PRE/OVER(1-0)		
103	SCLECTI	3D - 1	21*	-00100001	SUB COLORIZED CTILEVITED		
104	↓	.	↓ ↓	Ţ	NOT USED		
105	55H2LTI	81	891	10001001	SUB SHARPNESS(7-2) LTLUEV(1-0)		
106	RD2PTL	20	701	01110000	R. DRIVE(742). PLIMIT, LEVIT-0)		
107	GD2ABLM	7F	75	QUITALE .			
108	BD2CTIM1	7C	701	011,11000	B_ORIVEI7-21: CTL MODERN		
109	SBRZGAM	36	2A*	00101010	SUB BRIGHT (7-2) GAMMAIT-0		
10A 10B	ACTALTIM1	, 3C	98*	10001800	#_CUTGFF(7-2); LTI_MODE(1)		
10C	GCT2DPL BCT2DCT	, 2F	5D*	01011/01/6	GLOUTOFFO - 2H DPIC LEVII - 0)		
100		75 B	75*	01110101	B_COTOFF(7-2), DC_TRANCEO		
10E	SCO4LR2L	57	57	01010111	SUB CONT/944): LAGB2 LEVIS-00		
10F	PABL4ABLT CB0F2AW1AB	F1	F1	11110001	P_ABL(7~4), ABL_TH(3~0)		
110	CROF2SYS	90 B0	94*	10010100	CB_OFFSET(7~2), AGING_W(1), AGING_B(0)		
111	YOF4VD2VF		B8*	10111000	CR_OFFSET(7~2), SYSTEM(1~0)		
112	RYR4RYB	02 88	02	00000010	Y_OFFSET(7~4), VM_DLY(3~2), VM_FO(1~0)		
113	GYR4GYP		88	10001000	R-Y/R(7~4), R-Y/B(3~0)		
114	VML4FLC2FLS	88 F8	88	10001000	G-Y/R(7~4),G-Y/B(3~0)		
115	UBK4LBK	00	F2*	11110010	VM_LEV(7~4), FLCOL(3~2), FLCOL SW(1)		
116	VS	BE	86	00000000	UP_BLK(7~4), LO_ BLK(3~0)		
117	VPS	78		10000110	V_SIZE(7-2) bit(1,6)(0,0)(st/b0; fixed)		
118	VLI4SCR	76	63*	01100011	V_POSITION(2+2) V_LIN(7~4), S_CORRECTION(3~0)		
119	HSIZUUC	61	84*	10000100	V_LIN(7~4), S_CORREC (10N(3~0)		
114	PAP2LUP	65	loc•	91101100	PIN AMPRIZATIO LICENZO		
118	UCPZUUG	BD .	801	10000000	UP CPINIZZI UP UCCITADI		
11C	LCP2LUG	99	78*	01111000	Co.cept.2.00.0cg/ar		
110	PPH2UPO1VBS	83	60*	elitorioi	PIN_PHASIDADAUC_POULT VELX SWID		
. 11E	HPO2CSH1NIN	9C	79*	G1111001	H_POSTIONIZ-PLILEESHETINI, KONINTERIO		
11F	ABO2RAM	86 P 186	anesyp* mag	55 01111101 55	AFC BOWING PEAFOLMODE (NO.)		
120	AAN2AG51	₽4	88*	10001000	ALC, ANGLEW BI PAGC, SMAIL		
121	LBK2CPH	E0	BC*	10111100	LEFT_BLK(7-2), CLP_PHASE(1-0)		
122	RBK2CGA1HSW	71	9D*	10011101	RIGHT_BLK(7-2), CLP_GATE(1), HBLK_SW(0)		
123	VAS2JSW	00	00	00000000	V_ASPECT(7-2), JMP_SW (0)		
124	VSR	7D	7D	07111101	V_SCROLL(7-2), b1 : 0, b0 : 1 (b1 / b0: fixed)		
125	UVL4LVL	00	00	00000000	UP_VLIN(7-4), LO_VLIN(3-0)		
126	VCP4HCP	49	89*	10001001	V_COMP(7-4), H_COMP(3-0)		
127	ATI3HVS2BOF1AOF	70	70	01110000	AKB-TIM(7-3), HVBTM_SW(2),BLK OFF(1), AKB OFF(0)		
128	128	00	00	00000000	PRELIMINARY		
129	RF-SF0	01	01	00000001	RF SHP_F0(0)		
12A 12B	4I-SF0 4P-SF0	01	01	00000001	480I SHP_F0(0)		
12B	1I-SF0	01	01	00000001	480P SHP_F0(0)		
12D	7P-SF0	01	01	00000001	1080I SHP_F0(0)		
12E	D-SF0	01	01	00000001	720P SHP_F0(0)		
12F	RF-CON	01	01	00000001	DIGITAL SHP_F0(0)		
130	4I-CON	00	00	00000000	RF CONTRAST		
131	4P-CON	00	00	00000000	480I CONTRAST		
			00	00000000	480P CONTRAST		

Table 1. ON-SCREEN SERVICE MENU (Continued)

No.	TITLE	INITIAL REFERENCE DATA HEX	INITIAL SETUP DATA HEX	INITIAL SETUP DATA BINARY	FUNCTION
132	1I-CON	00	00	00000000	1125I CONTRAST
133	7P-CON	00	00	00000000	720P CONTRAST
134	D-CON	00	00	00000000	DIGITAL CONTRAST
135	W-CON	00	00	00000000	LETTER BOX CONTRAST
136	RF-HUE	FC	00*	00000000	RF TINT
137	4I-HUE	00	00	00000000	4801 TINT
138	4P-HUE	00	00	00000000	480P TINT
139	1I-HUE	00	00	0000000	1080i TINT
13A	7P-HUE	00	00	00000000	720P TINT
13B	D-HUE	00	00	0000000	DIGITAL TINT
13C	W-HUE	FF	FF	11111111	LETTER BOX TINT
13D	RF-PRE	02	02	00000010	RF PRE/OVER(1-0)
13E	4I-PRE	03	03	00000011	4801 PRE/OVER(1-0)
13F	4P-PRE	03	03	00000011	480P PRE/OVER(1-0)
140	1I-PRE	03	03	00000011	1080I PRE/OVER(1-0)
141	7P-PRE	03	03	00000011	720P PRE/OVER(1-0)
142	D-PRE	03	03	00000011	DIGITAL PRE/OVER(1-0)
143	RF-COL	01	00*	00000000	RF COLOR
144	4I-COL	04	04	00000100	480I COLOR
145	4P-COL	05	05	00000101	480P COLOR
146	1I-COL	04	04	00000100	1080I COLOR
147	7P-COL	04	04	00000100	720P COLOR
148	D-COL	00	00	00000000	DIGITAL COLOR
149	W-COL	00	00	00000000	LETTER BOX COLOR
14A	RF-CLV	01	01	00000001	RF CTI_LEV(1-0)
14B	4I-CLV	01	01	0000001	480I CTI_LEV(1-0)
14C	4P-CLV	01	01	00000001	480P CTI_LEV(1-0)
14D	1I-CLV	01	01	00000001	1080I CTI_LEV(1-0)
14E	7P-CLV	01	01	00000001	720P CTI_LEV(1-0)
14F	D-CLV	01	01	00000001	DIGITAL CTI_LEV(1-0)
150	RF-BRI	00	00	00000000	RF BRIGHT
151	4i-BRI	00	00	00000000	480I BRIGHT
152	4P-BRI	00	00	00000000	480P BRIGHT
153	1I-BRI	00	00	00000000	1080I BRIGHT
154	7P-BRI	00	00	00000000	720P BRIGHT
155	D-BRI	00	00	00000000	DIGITAL BRIGHT
156	W-BRI	00	00	00000000	LETTER BOX BRIGHT
157	RF-SHP	00	FE*	11111110	RF SHARPNESS
158	4I-SHP	00	FE*	11111110	4801 SHARPNESS
159	4P-SHP	00	FE*	11111110	480P SHARPNESS
15A	1I-SHP	00	FE*	11111110	1080I SHARPNESS
15B	7P-SHP	00	FE*	11111110	720P SHARPNESS
15C	DIGITAL-SHP	00	FE*	00000000	DIGITAL SHARPNESS
15D	W-SHP	00	00	00000000	LETTER BOX SHARPNESS
15E	RF-LLV	00	01*	00000001	RF LTI_LEV(1-0)
15F	4i-LLV	01	01	00000001	480I_LTI_LEV(1-0)
160	4P-LLV	01	01	0000001	480P LTI_LEV(1-0)
161	1I-LLV	01	01	00000001	1080I LTI_LEV(1-0)
162	7P-LLV	01	01	00000001	720P LTI_LEV(1-0)
163	D-LLV	01	01	00000001	DIGITAL LTI_LEV(1-0)

No	D. TITLE	INITIAL REFEREN DATA HEX			FUNCTION
16	4 RF-CMD	00	DATA HEX		
16	5 4I-CMD	00	00	00000000	RF CTI_MODE(0)
160	6 4P-CMD	00	00		480I CTI_MODE(0)
16:	7 11-CMD	00	00	00000000	480P CTI_MODE(0)
168	3 7P-CMD	00	00	00000000	1080I CTI_MODE(0)
169	D-CMD	00	00	00000000	720P CTI_MODE(0)
164	11-GAM	02	02	00000000	DIGITAL CTI_MODE(0)
16E	RF-LMD	00	00	00000000	1125I ÇfAMMA(1-0)
160	4I-LMD	00	00	0000000	RF LTI_MODE(0)
160	4P-LMD	00	00	00000000	480I LTI_MODE(0) 480P LTI_MODE(0)
16E	1I-LMD	00	00	00000000	1080I LTI_MODE(0)
16F	7P-LMD	00	00	00000000	720P LTI_MODE(0)
170	D-LMD	00	00	00000000	DIGITAL LTI_MODE(0)
171	RF-CB	00	01*	00000001	RF CB_OFFSET
172	4I-CB	00	01*	00000001	4801 CB_OFFSET
173	4P-CB	F0	FF*	11111111	480P CB_OFFSET
174	1I-CB	F0	FE*	11111110	1080f CB_OFFSET
175	7P-CB	F0	FF*	11111111	720P CB_OFFSET
176	D-CB	F0	F8*	11111000	DIGITAL CB_OFFSET
177	W-CB	00	00	00000000	000000 LETTER BOX CB_OFFSET
178	RF-CR	00	FE*	11111110	RF CR_OFFSET
179	4I-CR	00	FB*	11111011	480I CR_OFFSET
17A	4P-CR	F0	F9*	11111001	480P CR_OFFSET
17B	11-CR	F0	F6*	11110110	1080I CR_OFFSET
17C	7P-CR	00	F5*	11110101	720P CR_OFFSET
17D	D-CR	00	F6*	11110110	DIGITAL CR_OFFSET
17E	W-CR	00	00	00000000	LETTER BOX CR_OFFSET
17F	RF-SYS	00	00	00000000	RF SYSTEM(1-0)
180	4I-SYS	00	00	00000000	480I SYSTEM(1-0)
181	4P-SYS	00	00	00000000	480P SYSTEM(1-0)
182	11-SYS	01	01	00000001	1080I SYSTEM(1-0)
183	7P-SYS	01	01	00000001	720P SYSTEM(1-0)
184	D-SYS	00	01*	00000001	DIGITAL SYSTEM(1-0)
185	RF-VMD	00	00	00000000	RF VM_DLY(1-0)
186	4I-VMD	00	00	00000000	480I VM_DLY(1-0)
187	4P-VMD	00	00	00000000	480P VM_DLY(1-0)
188	1I-VMD	00	00	00000000	1080I VM_DLY(1-0)
189	7P-VMD	00	00	00000000	720P VM_DLY(1-0)
18A	D-VMD	00	00	00000000	DIGITAL VM_DLY(1-0)
18B	RF-VMF	02	02	00000010	RF VM_F0(1-0)
18C	4I-VMF	02	02	00000010	480I VM_F0(1-0)
18D	4P-VMF	02	02	00000010	480P VM_F0(1-0)
18E	1I-VMF	02	02	00000010	1080I VM_F0(1-0)
18F	7P-VMF	02	02	00000010	720P VM_F0
190	D-VMF	02	02	00000010	DIGITAL VM_F0
191	W-VMF	02	02	00000010	LETTER BOX VM_F0
192	RF-RYR	08	08	00001000	RF RYR(3-0)
193	4l-RYR	08	08	00001000	4801 RYR(3-0)
194	4P-RYR	08	08	00001000	480P RYR(3-0)
195	11-RYR	08	08	00001000	1080I RYR(3-0)
196	7P-RYR	08	08	00001000	720P RYR(3-0)
197	D-RYR	08	08	00001000	DIGITAL RYR(3-0)
198	RF-RYB	08	08	00001000	RF RYB(3-0)
199	4I-RYB	08	08	00001000	4801 RYB(3-0)

Table 1. ON-SCREEN SERVICE MENU (Continued)

No.	TITLE	INITIAL REFERENCE DATA HEX	INITIAL SETUP DATA HEX	INITIAL SETUP DATA BINARY	
19A	4P-RYB	08	08	00001000	480P RYB(3-0)
198	11-RYB	08	08	00001000	1080I RYB(3-0)
19C	7P-RYB	08	08	00001000	720P RYB(3-0)
19D	D-RYB	08	08	00001000	DIGITAL RYB(3-0)
19E	RF-GYR	08	08	00001000	RF GYR(3-0)
19F	4J-GYR	08	08	00001000	480L GYR(3-0)
1A0	4P-GYR	08	08	00001000	480P GYR(3-0)
1A1	1I-GYR	08	08	00001000	
1A2	7P-GYR	08	08	00001000	1080I GYR(3-0) 720P GYR(3-0)
1A3	D-GYR	08	08	00001000	DIGITAL GYR(3-0)
1A4	RF-GYB	08	08	00001000	RF GYB(3-0)
1A5	4I-GYB	08	08	00001000	
1A6	4P-GYB	08	08	00001000	
1A7	1I-GYB	08	08	00001000	
1A8	7P-GYB	08	08	00001000	1080! GYB(3-0)
1A9	D-GYB	08	08	00001000	720P GYB(3-0)
1AA	RF-VLV	OF OF	OF	00001000	DIGITAL GYB(3-0)
1AB	4I-VLV	0F	OF I	00001111	RF VM_LEV(3-0)
1AC	4P-VLV	OF OF	OF :	00001111	4801 VM_LEV(3-0)
1AD	1FVLV	0F	0F	00001111	480P VM_LEV(3-0)
1AE	7P-VLV	0F	0F	00001111	1080I VM_LEV(3-0)
1AF	D-VLV	0F	0F	00001111	720P VM_LEV(3-0)
1B0	W-VLV	00	00	00000000	1080/ VM_LEV(3-0)
181	1B1	00	00	0000000	LETTER BOX VM_LEV(3-0)
1B2	1B2	00	00	00000000	PRELIMINARY
1B3	1B3	00	00	00000000	PRELIMINARY PRELIMINARY
1B4	184	00	00	00000000	PRELIMINARY
1B5	1B5	00	00	00000000	PRELIMINARY
1B6	RWUBK	00	00	00000000	RF-LETTER BOX_UP_BLK
1B7	RWLBK	00	00	00000000	
1B8	RWVS	00	00	00000000	RF-LETTER BOX LO_BLK RF-LETTER BOX V SIZE
1 B 9	RWVPS	00	00	00000000	RF-LETTER BOX V_POSITION
18A	RWUUC	00	00	00000000	RF-LETTER BOX_UP_UCP
188	RWPAP	00	00	00000000	RF-LETTER BOX PIN_AMP
1BC	RWLUP	00	00	0000000	RF-LETTER BOX_LO_UCP
1BD	RWUCP	00	00	00000000	RF-LETTER BOX UP CPIN
1BE	RWUUG	00	00	00000000	RF-LETTER BOX UP_UCG
1BF	RWLCP	00	00	00000000	RF-LETTER BOX LO_CPIN
1C0	RWLUG	00	00	00000000	
1C1	RWPPH	00	00	00000000	RF-LETTER BOX_LO_UCG RF-LETTER BOX PIN_PHASE
1C2	RWVBS	00	00	00000000	RF-LETTER BOX PRIN_PHASE RF-LETTER BOX VBLK_SW
1C3	RWABO	00	00	00000000	RF-LETTER BOX_VBLK_SW
1C4	RWAAN	00	00	00000000	RF-LETTER BOX AFC_ANGLE
1C5	RWVAS	00	00	00000000	RF-LETTER BOX V_ASPECT
1C6	RWJSW	00	00	00000000	RF-LETTER BOX V_ASPECT
1C7	RWVSR	00	00	00000000	RF-LETTER BOX JMP_SW RF-LETTER BOX V_SCROLL
1C8	1C8	00	00	00000000	
1C9	CFUBK	00	00	00000000	RF-LETTER BOX PRELIMINARY
1CA	CFLBK	00	00	00000000	VIDEO1/2-FULL UP_BLK
1CB	CFVS	00	00	00000000	VIDEO1/2-FULL LO_BKL
1CC	CFVPS	00	00	00000000	VIDEO1/2-FULL V_SIZE
				00000000	VIDEO1/2-FULL V_POSITION

	1				
No		INITIAL REFERENC DATA HEX	E INITIAL SETUI DATA HEX	P INITIAL SETUP DATA BINARY	FUNCTION
1CI		00	00	00000000	VIDEO1/2-FULL H_SIZE
1C		00	00	00000000	VIDEO1/2-FULL H_POSITION
1CI		00	00	00000000	VIDEO1/2-FULL L_BLK
1D(00	00	00000000	VIDEO1/2-FULL R_BLK
1D'		00	00	00000000	VIDEO1/2-FULL V_ASPECT
1D2		00	00	00000000	VIDEO1/2-FULL V_SCROLL
1D3		09	08*	00001000	VIDEO1/2-LETTER BOX LO_BLK
1D4		0D	0B*	00001011	VIDEO1/2-LETTER BOX LO_BLK
1D5		00	00	00000000	VIDEO1/2-LETTER BOX V_SIZE
1D6		00	00	00000000	VIDEO1/2-LETTER BOX V_POSITION
1D7		01	01	00000001	VIDEO1/2-LETTER BOX VBLK_SW
1D8		12	12	00010010	VIDEO1/2-LETTER BOX V_ASPECT
1D9		01	01	00000001	VIDEO1/2-LETTER BOX JMP_SW
1DA		00	00	00000000	VIDEO1/2-LETTER BOX V_SCROLL
1DB	 	00	00	00000000	VIDEO1/2-LETTER BOX PRELIMINARY
1DC		00	00	00000000	480I-FULL UP_BLK
1DD		00	00	00000000	480I-FULL LO_BLK
1DE	4IVS	00	00	00000000	480i-FULL V_SIZE
1DF	4IVPS	00	00	00000000	480I-FULL V_POSITION
1E0	4IHSI	00	00	00000000	480I-FULL H_SIZE
1E1	4IHPO	00	00	00000000	480I-FULL H_POSITION
1E2	4ILBK	00	00	00000000	480I-FULL L_BLK
1E3	4IRBK	00	00	00000000	480I-FULL R_BLK
1E4	4IVAS	00	00	00000000	480I-FULL V_ASPECT
1E5	4IVSR	00	00	00000000	480I-FULL V_SCROLL
1E6	4IWUBK	08	08	00001000	480I-LETTER BOX UP_BLK
1E7	4IWLBK	OB_	OB_	00001011	480I-LETTER BOX LO_BLK
1E8	4IWVS	00	00	00000000	480I-LETTER BOX V_SIZE
1E9	4iWVPS	00	00	00000000	480I-LETTER BOX V_POSITION
1EA	4IWVBS	01	01	0000000	1480I-LETTER BOX VBLK_SW
1EB	4IWVAS	12	12	00010010	480I-LETTER BOX V_ASPECT
1EC	4lWJSW	01	01	00000001	480I-LETTER BOX JMP_SW
1ED	4IWVSR	00	00	00000000	480I-LETTER BOX V_SCROLL
1EE	1EE	00	00	00000000	4801 PRELIMINARY
1EF	4PUBK	00	00	00000000	480P-FULL UP_BLK
1F0	4PLBK	00	00	00000000	480P-FULL LO_BLK
1F1	4PVS	00	00	00000000	480P-FULL V_SIZE
1F2	4PVPS	00	00	00000000	480P-FULL V_POSITION
1F3	4PHSI	00	00	00000000	480P-FULL H_SIZE
1F4	4PHPO	00	00	00000000	480P-FULL H_POSITION
1F5	4PLBK	00	00	00000000	480P-FULL L_BLK
1F6	4PRBK	00	00	00000000	480P-FULL R_BLK
1F7	4PVAS	00	00	00000000	480P-FULL V_ASPECT
1F8	4PVRS	00	00	00000000	480P-FULL V_SCROLL
1F9	4PWUBK	08	- 08	00001000	480P-LETTER BOX UP_BLK
1FA	4PWLBK	OD OD	08*	00001011	480P-LETTER BOX LO_BLK
1FB	4PWVS	00	00	00000000	480P-LETTER BOX V_SIZE
1FC	4PWVPS	00	00	00000000	480P-LETTER BOX V_POSITION
1FD	4PWVBS	01	01	00000001	480P-LETTER BOX VBLK_SW
1FE	4PWVAS	12	12	00010010	480P-LETTER BOX V_ASPECT
1FF	4PWJSW	01	01	00000001	480P-LETTER BOX JMP_SW
200	4PWVSR	00	00	00000000	480P-LETTER BOX V_SCROLL
201	201	00	00	00000000	480P PRELIMINARY
202	7PUBK	00	00	00000000	720P-FULL UP_BLK

(7

Table 1. ON-SCREEN SERVICE MENU (Continued)

Γ	1	1	,			
No.	TITLE	INITIAL REFERENCE DATA HEX	INITIAL SETUP DATA HEX	INITIAL SETUP DATA BINARY	FUNCTION	
203	7PLBK	00	00	00000000	720P-FULL LO_BLK	
204	7PVS	00	00	00000000	720P-FULL V_SIZE	
205	7PVPS	00	00	00000000	720P-FULL V_POSITION	
206	7PHSI	00	00	00000000	720P-FULL H_SIZE	
207	7PHPO	00	00	00000000	720P-FULL H_POSITION	
208	7PLBK	00	00	00000000	720P-FULL L_BLK	
209	7PRBK	00	00	00000000	720P-FULL R_BLK	
20A	7PVAS	00	00	00000000	720P-FULL V_ASPECT	
208	7PVSR	00	00	00000000	720P-FULL V SCROLL	
20C	7PWUBK	09	08*	00001000	720P-LETTER BOX UP BLK	
20D	7PWLBK	0D	0B*	00001011	720P-LETTER BOX LO_BLK	
20E	7PWVS	00	00	00000000	720P-LETTER BOX V_SIZE	
20F	7PWVPS	00	00	00000000	720P-LETTER BOX V_POSITION	
210	7PWVBS	01	01	00000001	720P-LETTER BOX VBLK_SW	
211	7PWVAS	12	12	00010010	720P-LETTER BOX V_ASPECT	
212	7PWJSW	01	01	00000001	720P-LETTER BOX JMP_SW	
213	7PWVSR	00	00	00000000	720P-LETTER BOX V SCROLL	
214	214	00	00	00000000	720P PRELIMINARY	
215	1IUBK	00	00	00000000	1080I-FULL UP_BLK	
216	1ILBK	00	00	00000000	1080I-FULL LO_BLK	
217	1IVS	00	00	00000000	1080I-FULL V_SIZE	
218	1IVPS	00	00	00000000	1080I-FULL V_POSITION	
219	1/HSI	00	00	00000000	1080I-FULL H_SIZE	
21A	1 IHPO	00	00	00000000	1080I-FULL H_POSITION	
21B	1ILBK	00	00	00000000	1080I-FULL L_BLK	
21C	1IRBK	00	00	00000000	1080I-FULL R BLK	
21D	1IVAS	00	00	00000000	1080I-FULL V_ASPECT	
21E	1/VSR	00	00	00000000	1080I-FULL V SCROLL	
21F	1IWUBK	09	08*	00001000	1080I-LETTER BOX UP_BLK	
220	11WLBK	oc .	OB*	00001011	1080I-LETTER BOX LO_BLK	
221	1IWVS	00	00	00000000	1080I-LETTER BOX V_SIZE	
222	1IWVPS	00	00	00000000	1080I-LETTER BOX V_POSITION	
223	1IWVBS	01	01	00000001	1080I-LETTER BOX VBLK SW	
224	1IWVAS	12	12	00010010	1080I-LETTER BOX V_ASPECT	
225	1lWJSW	01	01	00000001	1080I-LETTER BOX JMP SW	
226	1IWVSR	00	00	00000000	1080I-LETTER BOX V_SCROLL	
227	227	00	00	00000000	1080I PRELIMINARY	
228	DUBK	00	00	00000000	DIGITAL-FULL UP_BLK	
229	DLBK	00	00	00000000	DIGITAL-FULL LO BLK	
22A	DVS	00	00	00000000	DIGITAL-FULL V SIZE	
22B	DVPS	00	01*	0000001	DIGITAL-FULL V POSITION	
22C	DHSI	00	00	00000000	DIGITAL-FULL V_POSITION DIGITAL-FULL H SIZE	
22D	DHPO	00	00	00000000	DIGITAL-FULL H_POSITION	
22E	DLBK	00	00	00000000	DIGITAL-FULL L_BLK	
22F	DRBK	00	00	00000000	DIGITAL-FULL R_BLK	
230	DVAS	00	00	00000000	DIGITAL-FULL V_ASPECT	
231	DVSR	00	00	00000000	DIGITAL-FULL V_SCROLL	
232	232	00	00	00000000	DIGITAL PRELIMINARY	
233	RZVS	00	00	00000000	RF-ZOOM V_SIZE	
234	RZVPS	00	00	00000000	RF-ZOOM V_POSITION	
235	RZVBS	00	00	00000000	RF-ZOOM VBLK_SW	
				0000000	VII FOOM ADEK OAA	

NI-	TITLE	INITIAL REFERENCE	INITIAL SETUP	INITIAL SETUP	ELINICTION
No.		DATA HEX	DATA HEX	DATA BINARY	FUNCTION
236	RZVAS	00	00	00000000	RF-ZOOM V_ASPECT
237	RZZSW	00	00	00000000	RF-ZOOM_ZOOM_SW
238	RZVSR	00	00	00000000	RF-ZOOM V_SCROLL
239	239	00	00	00000000	RF PRELIMINARY
23A	CZVS	00	00	00000000	VIDEO1/2-ZOOM V_SIZE
23B	CZVPS	00	00	00000000	VIDEO1/2-ZOOM V_POSITION
23C	CZVAS	00	00	00000000	VIDEO1/2-ZOOM V_ASPECT
23D	CZVSR	00	00	00000000	VIDEO1/2-ZOOM V_SCROLL
23E	23E	00	00	00000000	VIDEO1/2 PRELIMINARY
23F	4IZVS	00	00	00000000	480I-ZOOM V_SIZE
240	41ZVPS	00	00	00000000	480I-ZOOM V_POSITION
241	4IZVAS	00	00	00000000	480I-ZOOM V_ASPECT
242	4IZVSR	00	00	00000000	480I-ZOOM V_SCROLL
243	243	00	00	00000000	480I PRELIMINARY
244	4PZVS	00	00	00000000	480P-ZOOM V_SIZE
245	4PZVPS	00	00	00000000	480P-ZOOM V_POSITION
246	4PZVAS	00	00	00000000	480P-ZOOM V_ASPECT
247	4PZVSR	00	00	00000000	480P-ZOOM V_SCROLL
248	248	00	00	00000000	480P PRELIMINARY
249	4PZVS	00	00	0000000	720P-ZOOM V_SIZE
24A	4PZVPS	00	00	00000000	720P-ZOOM V_POSITION
24B	4PZVAS	00	00	00000000	720P-ZOOM V_ASPECT
24C	4PZVSR	00	00	00000000	720P-ZOOM V_SCROLL
24D	24D	00	00	00000000	720P PRELIMINARY
24E	1IZVS	00	00	•	
24F	1IZVPS	00	00	00000000	1080I-ZOOM V_SIZE
+		 		00000000	1080I-ZOOM V_POSITION
250	1IZVAS	00	00	00000000	1080I-ZOOM V_ASPECT
251	1IZVSR	00	00	00000000	1080I-ZOOM V_SCROLL
252	252	00	00	00000000	1080! PRELIMINARY
253	DZVS	00	00	00000000	DIGITAL-ZOOM V_SIZE
254	DZVPS	00	00	00000000	DIGITAL-ZOOM V_POSITION
255	DZVAS '	00	00	00000000	DIGITAL-ZOOM V_ASPECT
256	DZVSR	00	00	00000000	DIGITAL-ZOOM V_SCROLL
257	257	00	00	00000000	DIGITAL PRELIMINARY
258	PUBK	07	08*	00001000	PAP-ON UP_BLK
259	PLBK	0F	0F	00001011	PAP-ON LO_BLK
25A	PVS	00	00	00000000	PAP-ON V_SIZE
25B	PVPS	00	00	00000000	PAP-ON V_POSITION
25C	PUUC	00	00	00000000	PAP-ON UP_UCP
25D	PPAP	00	00	00000000	PAP-ON PIN_AMP
25E	PLUP	00	00	00000000	PAP-ON LO_UCP
25F	PUCP	00	00	00000000	PAP-ON UP_UCP
260	PUUG	00	00	00000000	PAP-ON_UP_UCG
261	PLCP	00	00	00000000	PAP-ON LO_CPIN
262	PLUG	00	00	00000000	PAP-ON LO_UCG
263	PPPH	00	00	00000000	PAP-ON PIN_PHASE
264	PVBS	01	01	00000001	PAP-ON VBLK_SW
265	PABO	00	00	00000000	PAP-ON AFC_BOW
266	PAAN	00	00	00000000	PAP-ON AFC_ANGLE
267	PVAS	12	12	00010010	PAP-ON V_ASPECT
268	PJSW	01	01	00000001	PAP-ON JMP_SW
269	PVSR	00	00	00000000	PAP-ON V_SCROLL
26A	26A	00	00	00000000	PAP-ON PRELIMINARY
26B	DWUBK	07	08*	00001000	DIGITAL-LETTER BOX UP_BLK
	•				

Table 1. ON-SCREEN SERVICE MENU (Continued)

	- 	I				
No.		INITIAL REFERENCI DATA HEX	INITIAL SETUR DATA HEX	DATA BINARY		
26C	 	0F	0B*	00001011	DIGITAL-LETTER BOX LO_BLK	
26D	 	00	00	00000000	DIGITAL-LETTER BOX V_SIZE	
26E	DWVPS	00	00	00000000	DIGITAL-LETTER BOX V_POSITION	
26F	DWVBS	01	01	00000001	DIGITAL-LETTER BOX VBLK_SW	
270	DWVAS	12	12	00010010	DIGITAL-LETTER BOX V_ASPECT	
271	DWJSW	01	01	00000001	DIGITAL-LETTER BOX ZOOM_SW	
272	DWVSR	00	00	00000000	DIGITAL-LETTER BOX V_SCROLL	
040	HU2DO1CY	83	83	10000011	HUE(7-2), DPIC OFF(1), CV/YC(0)	
041	COL2RHM1CAN	52	52	01010010	COLOR(7-2), RF HMASK(1), CANAL(0)	
042	SHA4SCO	47	47	01000111	SHARPNESS(7-4), SUBCONT(3-0)	
043	SHU4SCL	77	72*	01110010	SUBHUE(7-4), SUBCOLOR(3-0)	
044	CAJ4RAF2TRO1TOO	78	78	01111000	CTRAPADJ(7-4),AFC(3-2),TRAPON(1),TOT ON(0)	
045	YD3SF2F01CM2	2A	32*	00110010	Y DRIVE(7-3),SHP-f0(2), FSC OUT(1), CD MODE2(0)	
046	UPD4VPD	68	68	01101000	U PED(7-4), V PED(3-0)	
047	U2PD4V2PD	00	00	00000000	U2 PED(7-4), V2 PED(3-0)	
048	Y2D3DCT	00	00	00000000	Y2 DRIVE(7-3), DC TRAN(2-0)	
049	U2D3PRO1	00	00	00000000	U2 DRIVE(7-3), PRE OVER(2-1),bit0: 0 (bit0: fixed)	
04A	V2D	00	00	00000000	V2(7-3), bit2: 0, bit1: 0, bit0: 0 (bit2 / 1/ 0: fixed)	
04B	CS6XP4VF2DL	02	02	00000010	CS(7-6),XP(5-4),VF(3-2),DL(1-0)	
04C	-	01	01	00000001	bit7, 6: 0, bit5, 4: 0, bit3, 2: 0, bit1: 0 ,bit0: 1	
04D	EXAFC	00	00	00000000	EX(V1/V2)AFC	
04E	EXCAFC	01	01	00000001	EX(V3)AFC	
04F	04F	00	00	00000000	PRELIMINARY	
050	HF61SW42SW2SL	3C	3C	00111100	HF6(7-6),1SW(5-4), 2SW(3-2), SL(1-0)	
051	D16D24D33T21l12l	03	03	00000011	D16(7-6), D24(5-4), D33(3), T2(2), 111(1), 21(0)	
052	VF6CP4FDS2IS	СС	СС	11001100	VF6(7-5), CP(4), FDS(3-2), IS(1-0)	
053	HP2V11V2	53	7B*	01111011	HP(7-2),V1(1),V2(0)	
054	4PHF	01	01	00000000	480P H-FREQUENCY	
056	7PHF	03	03	00000000	720P H-FREQUENCY	
057	4PVF	04	04	00000000	480P V-FREQUENCY	
058	1IVF	03	03	00000000	1080I V-FREQUENCY	
059	7PVF	01	01	00000000	720P V-FREQUENCY	
05A	WDT	1A	1A	00000000	WATCH DOG TIMER (*500MSEC)	
05B	3D04	29	29	00000000	3D Y/C DATA 04	
05C	3D05	36	36	00000000	3D Y/C DATA 05	
05D	3D06	99	99	00000000	3D Y/C DATA 06	
05E	3D0A	52	52	00000000	3D Y/C DATA 11	
05F	3D0B	3A	3A	00000000	3D Y/C DATA 12	
060	3D10	50	50	00000000	3D Y/C DATA 17	
080	ATT	07	07	00000000	MTS INPUT LEVELIS-0)	
081	WDB	20	20	00000000		
082	Section ASPC Property	20 -	7 1 20 1 W	00000000	MTS LOW SEPARATION(5-0) MTS HI SEPARATION(5-0)	
083	083	00	00	00000000	NOT AVAILABLE	
084	084	00	00	00000000	NOT AVAILABLE	
085	085	00	00	00000000	NOT AVAILABLE	
086	086	00	00	00000000	NOT AVAILABLE	
087	OP1	on and the	7 mm 100 mm li	09000000	OPTIONI DATA	
388	阿克里斯森 安德斯 泰斯克		(1944年)	00010000	OPTION2 DATA	
-089	0.80	02	4 D 2	00000010	OSD H-POSITION	
08A	A80	00	00	0000000	NOT AVAILABLE	
08B	VMT	48	48	01001000	VIDEO MUTE TIME	
لتتا	*****	70	40	01001000	VIDEO MOTE TRUE	

No.	TITLE	INITIAL REFERENCE DATA HEX	INITIAL SETUP DATA HEX	INITIAL SETUP DATA BINARY	FUNCTION
08C	AKB	30	10*	00010000	AKB DETECT TIME
08D	<u>-</u>	00	00	00000000	NOT AVAILABLE
08E	-	00	00	00000000	NOT AVAILABLE
255		00	00	00000000	NOT AVAILABLE
- .	R/B DRIVE		an also de Plants	e follow-banks	RVADRIVE LEVEL AGJUSTMENT
is in the	SCREEN			1. 香度岩原建筑	BLACK SCREEN FOR SCREEN ADJUSTMENT
0B0	ROO			_	ROM CORRECTION DATA
		↓	↓	+	↓
0F7	R47	- "	-		ROM CORRECTION DATA

PROGRAM CODES

The microprossesor used in this model is a multi-purpose type and is used in several different models. To ensure proper operation and the correct features for your particular model, the program codes must be correct.

Note 1. Option Data 1 (NO. 087 OP1).

Is not used in this model.

Note 2. Option Data 2 (NO. 088 OP2) should be Hexadecimal 10 (00010000 binary). If this program code is wrong the TV will not operate properly.

BIT	FUNCTION	DA	TA
		0	1
0	NOT USED		_
1	TV ASPECT RATIO	4:3	16:9
2	NOT USED		
3	NOT USED	-	-
4	PAP	NONE	YES
5	NOT USED	-	_
6	NOT USED	-	-
7	NOT USED		_

SERVICE ADJUSTMENTS (Continued)


ANTENNA CONNECTIONS

This receiver is designed for UHF/VHF and Digital RF reception. A 75 ohm terminal is provided for UHF/VHF reception and a separate 75 ohm terminal is provided for Digital RF reception. When connecting a CATV antenna system, connect the 75 ohm coaxial cable directly to the 75 ohm UHF/VHF terminal. For 300 ohm VHF antenna, use an adapter (not included with the TV set).

CIRCUIT PROTECTION

Fuse F601 (4A) is included in the AC line. This fuse must be replaced with the proper fuse (see Parts List).

CAUTION



FOR CONTINUED PROTECTION AGAINST A RISK OF FIRE, REPLACE ONLY WITH THE SAME TYPE 4A, 125V FUSE.

ATTENTION: POUR MAINTENIR LA PRO-TECTION CONTRE LES RISQUES D'INCENDIE UTILISER UN FUSIBLE DE RECHANGE DE MEME TYPE 4A, 125V.

+B VOLTAGE CHECK

- Connect Voltmeter + lead to TJ1 (140 V) and lead to ground (Power/Deflection board).
- 2. Connect receiver to AC 120V line.
- 3. Tune receiver to an active channel.
- Set the picture controls to the Sports level or Reset (use MENU key and ▲ or ▼ key or RESET key).
- 5. Voltage must measure between 139.0 V and 142.0V. If the voltage is out of range, the power circuit must be checked. No +B adjustment is provided on this chassis.

HORIZONTAL CENTERING ADJUSTMENT

- 1. Tune receiver to an active analog channel.
- 2. Select Full Mode.
- 3. Check that picture is in the horizontal center of TV screen. If picture is not centered horizontally, perform steps 3 6.
- 4. Turn off the receiver and disconnect the AC power cord. (120V AC line)
- 5. While pressing the VOLUME key, reconnect the AC power cord. The Service Menu display will now appear.
- 6. Select NO. 11E (HPO2: Horizontal Position, Bit 7 2) with ▲ or ▼ key.
- Adjust the data with numeric keys for horizontal center. To turn off the Service Menu display, press the MENU key.

HORIZONTAL WIDTH ADJUSTMENT

- 1. Tune receiver to an active analog channel.
- 2. Select Full Mode.
- 3. Check the picture for proper width. If width is not correct, perform steps 3 6.
- 4. Turn off the receiver and disconnect the AC power cord.
- While pressing the VOLUME key, reconnect the AC power cord. The Service Menu display will now appear.
- Adjust the data with numeric keys for proper width. To turn off the Service Menu display, press the MENU key.

VERTICAL SIZE ADJUSTMENT

- 1. Tune receiver to an active analog channel.
- Check the vertical size of the picture. If the vertical size is too large or small, perform steps 3 ~ 6.
- 3. Turn off the receiver and disconnect the AC power cord.
- While pressing the VOLUME key, reconnect the AC power cord. The Service Menu display will now appear.
- Select NO. 116 (VS: Vertical Size, Bit 7 2) with ▲ or ▼
- Adjust the data with + or key for full scan. To turn off the Service Menu display, press the MENU key.

VERTICAL CENTERING ADJUSTMENT


- 1. Tune receiver to an active analog channel.
- Check that picture is in the vertical center of TV screen.
 If picture is not centered vertically, perform steps 3 6.
- 3. Turn off the receiver and disconnect the AC power cord.
- While pressing the VOLUME key, reconnect the AC power cord. The Service Menu display will now appear.
- 5. Select NO. 117 (VPS: Vertical Position) with ▲ or ▼ key.
- Adjust the data with numeric key for vertical center. To turn off the Service Menu display, press the MENU key.

GRAYSCALE ADJUSTMENT

- Connect a color-bar generator to the analog antenna terminal.
- 2. Switch the generator to the white pattern.
- Set the picture controls to the Sports level or Reset (use MENU key and ▲ or ▼ key or RESET key).
- Turn off the receiver and disconnect the AC power cord (120V AC line).
- While pressing the VOLUME key, reconnect the AC power cord. The Service Menu display will now appear.
- Select the following service menu items with the ▲ or ▼ keys and set the data with the numeric keys.
- Select NO. 106 RD2 (Red Drive) and set data to 70, NO. 107 GD2 (Green Drive) and set data to 7F, and NO. 108 BD2 (Blue Drive) and set data to 70.
- Set NO. 10A RCT2 (Red Cutoff) data to 88, NO. 10B GCT2 (Green Cutoff) data to 5D, and NO. 10C BCT2 (Blue Cutoff) data to 75.
- Set NO. 109 SBR2 (Sub Brightness) data to 2A and NO. 105 SSH2 (Sub Sharpness) data to 89.

Screen Adjustment

- Connect oscilloscope probe (at least 50:1) to TP47G and ground lead to TE47 on the CRT socket PWB.
- 11. Select "Screen Adjustment" Menu (between NO. 08F and 0B0) with ▲ or ▼ key (Black Picture).
- 12. Adjust Screen Control (T402) to obtain 15 Vp-p from black to white level. (See Figure 2.)



Drive Level Adjustment

- 13. Select "Drive Level Adjustment" Menu (between NO. 08E and NO. 0B0) with ▲ or ▼ key. The Menu display will appear.
- 14. Adjust Red and Blue Drive Levels alternately with 1, 3, 7, or 9 key to produce normal black and white picture in highlight areas. The Drive Level adjustment data will be written in the Service Menu No. 106 and 108 automatically. (See Figure 3.)




Figure 3. Remote Control Number keys' functions in Service Menu "Drive Level Adjustment"

15. Check for proper grayscale at all brightness levels.

Note: If Grayscale Adjustment is made after picture tube replacement, check Brightness Adjustment.

BRIGHTNESS LEVEL ADJUSTMENT

Note: Grayscale Adjustment and High Voltage Check must be completed before attempting Brightness Level Adjustment.


- 1. Connect a color-bar generator to the analog antenna terminal.
- 2. Switch the generator to the 15 IRE flat pattern.
- 3. Select Full Mode.
- 4. Reset the picture controls to the Sports level.
- Connect voltmeter (high impedance) + lead to terminal TP51 and - lead to terminal TP50 on P/D board. Set voltmeter for 1.5V ~ 3V range.
- 6. Turn off the receiver and disconnect the AC power cord.
- While pressing the VOLUME key, reconnect the AC power cord. The Service Menu display will now appear.
- Select NO. 109 (SBR2: Sub Brightness, Bit 7 2) with ▲ or ▼ key.
- 9. Adjust the data with numeric keys for 20mVDC.
- 10. Press the MENU key to turn off the Service Menu display.
- Check brightness level on every active channel, readjust (repeat steps 5 ~ 9), if necessary.

Note: Do not set to excessive brightness level, otherwise the contrast level will be suppressed.

SUB CONTRAST ADJUSTMENT

- 1. Connect a color-bar generator to the analog antenna terminal.
- 2. Switch the generator to the crosshatch pattern.
- Connect oscilloscope probe (at least 50:1) to TP47G and ground lead to TE47 on the CRT socket PWB.
- 4. Turn off the receiver and disconnect the AC power cord.
- While pressing the VOLUME key, reconnect the AC power cord. The Service Menu display will now appear.
- Select NO. 109 (SBR2: Sub Brightness, Bit 7 2) with ▲ or ▼ key. Remember this data setting.

- 7. Set the data with numeric key to 2E with numeric keys.
- 8. Select NO. 10D (SCO4: Sub Contrast, Bit 7 4) with ▲ or ▼ key.
- 9. Set the data with numeric keys 4 7 for 100Vp-p.
- Reset brightness level to previous data (repeat steps 6 7). To turn off the Service Menu display, press the MENU key.



SUB COLOR AND SUB HUE ADJUSTMENT Sub Hue (Tint)

- Connect a color-bar generator to the analog antenna terminal. Set picture controls to Sports level.
- 2. Switch the generator to the color-bar (NTSC) pattern.
- Connect oscilloscope probe (at least 50:1) to TP47G and ground lead to TE47 on the CRT socket PWB.
- 4. Turn off the receiver and disconnect the AC power cord.
- While pressing the VOLUME key, reconnect the AC power cord. The Service Menu display will now appear.
- 6. Select NO. 102 (SHU2: Sub HUE, Bit 7 2) with ▲ or ▼ key.
- 7. Set the data with numeric keys 2 7 for waveform shown in Figure 5.



Figure 5. Sub Hue

Sub Color

- 8. Select NO. 103 (SCL2: Sub Color, Bit 7 2) with ▲ or ▼ key.
- 9. Set the data with numeric keys 7 -2 for waveform shown in Figure 6 (Flat Waveform).
- After adjustment add 8 steps to NO. 102 (SHU2: Sub HUE) data and 8 steps to NO. 103 (SCL2: Sub Color) data.
 To turn off the Service Menu display, press the MENU key.




Figure 6. Sub Color

SERVICE ADJUSTMENTS (Continued)

HIGH VOLTAGE HOLD-DOWN TEST

Every time the receiver is serviced, the HIGH VOLTAGE HOLD-DOWN circuit must be tested for proper operation by following these steps:

- Connect receiver to 120V AC line. Tune receiver to active channel. Reset the picture controls to the Sports level.
- Check that the voltage measured between TP7 and TE7 (ground side) on the P/D PC board is within 20 VDC to 24 VDC. If the voltage is out of this range, the Hold-Down Circuit must be checked.
- 3. Connect a DC Voltage supply to TP7 and TE7 through a 100 ohm 1/4W resistor. Adjust the DC voltage to 26 VDC. The receiver should shut down, losing raster and sound. Then the receiver should turn off automatically. This reaction indicates that the Hold-Down circuit is functioning properly. If the receiver does not shutdown, a malfunction is indicated and its cause must be found and corrected.
- 4. To obtain picture again, remove the DC Supply and wait a few minutes. Now turn on the receiver.

HIGH VOLTAGE CHECK

Note: +B (+140V) Voltage Check and Grayscale Adjustment must be completed before attempting High Voltage Check.

- Connect high voltage voltmeter lead to ground, and connect + lead to anode of picture tube.
- 2. Tune receiver to an active channel and confirm TV is operating properly.
- 3. Eliminate the beam current by adjusting the contrast and brightness controls to minimum.
- 4. Confirm high voltage is within 28.2 KV and 32.9 KV. If reading is not within range, check horizontal circuit.

No high-voltage adjustment is provided on this chassis.

FOCUS ADJUSTMENT

Adjust focus control (T402) for well defined scanning lines.

PURITY AND CONVERGENCE ADJUSTMENTS

Purity and Convergence have been aligned at the factory. No re-alignment is necessary.

MULTI-SOUND SECTION ADJUSTMENTS

Note: Multi-Sound Section must be adjusted after A101 (U/V Tuner), IC3601 (MTS Decoder), Digital Module or IC802 (EEPROM) is replaced.

INPUT LEVEL ADJUSTMENT

- 1. Connect a signal to the analog antenna terminal with audio of 1 KHz 100% modulation.
- 2. Turn off the receiver and disconnect the AC power cord (AC 120V line).
- Connect voltmeter (RMS) to TP317 and ground on the Main PC board.
- 4. While pressing the VOLUME key, reconnect the AC power cord. The Service Menu will now appear.
- Select NO. 080 (ATT: MTS Input Level) with the ▲ or ▼ key.
- 6. Adjust the + or key for a voltmeter reading of 400 \pm 20 mVrms at TP317.

SEPARATION ADJUSTMENT

- 7. Turn off the receiver and disconnect the AC power cord (AC 120V line).
- Connect oscilloscope CH1 to TP317 and CH2 to TP318 and ground.
- 9. Connect an MTS TV/Stereo generator to antenna terminal.
- 10. While pressing the VOLUME key, reconnect the AC power cord. The Service Menu will now appear.
- Select pilot, 300Hz audio frequency and Left modulating signal.
- 12. Select NO. 081 (WDB: Wide Band) with the ▲ or ▼ key.
- 13. Adjust the + or key for minimum low frequencies at TP317. (See Figure 7.)
- 14. Select 4 KHz audio frequency and Right modulating signal.
- 15. Select NO. 082 (SPC: Spectral) with the ▲ or ▼ key.
- 16. Adjust the + or key for minimum high frequencies at TP318. (See Figure 7.)

Repeat adjustments (steps 11–16) until no further decreases in amplitude can be obtained. Press the MENU key to turn off the Service Menu display.




Figure 7. Separation Adjustments

PINCUSHION CORRECTION ADJUSTMENT

- Connect a color-bar generator to the analog antenna terminal and select a crosshatch pattern.
- 2. Set the picture controls to the Sports level.
- Turn off the receiver and disconnect the AC power cord (AC 120V line).
- While pressing the VOLUME key, reconnect the AC power cord. The Service Menu will now appear.
- Select the items below with ▲ or ▼ key according to the symptoms of Figure 8.

NO.ITEM	Bit	NAME	
11A	PAP2	7 - 2	Pin AMP
11D	PPH2	7 - 2	Pin Phase
11F	ABO2	7 - 2	AFC Bow
120	AAN2	7 - 2	AFC Angle
11B	UCP2	7 - 2	Upper Corner Pin
11C	LCP2	7 - 2	Lower Corner Pin




Figure 8. Pincushion Adjustments

Adjust the data with numeric keys for straight vertical lines. To turn off the Service Menu display, press the MENU key.

OSD ADJUSTMENT

- 1. Connect a color-bar generator to the analog antenna terminal.
- 2. Set the picture controls to the Sports level.
- Turn off the receiver and disconnect the AC power cord. (120V AC line)
- While pressing the VOLUME key, reconnect the AC power cord. The Service Menu display will now appear.
- Select NO. 089 (OSD: On-Screen Display) with ▲ or ▼ key.
- Adjust the + or key for proper position shown in Figure 9. To turn off the Service Menu display, press the MENU key.





Figure 9.

COMPONENTY LEVEL CONFIRM

- Connect a color-bar generator to the analog antenna terminal.
- 2. Switch the generator to the color-bar (NTSC) pattern.
- 3. Connect oscilloscope probe to Connector KG pin 12 and ground on the main board.
- 4. Confirm a reading of 0.7 Vp-p ± .05. See Figure 10.



SERVICE HINTS

POWER FAILURE DETECTOR

This unit is equipped with a Power Failure Detector function included in the CPU which checks for an abnormal condition in the chassis power supplies, including the power supply derived from the Horizontal Output Transformer.

If, while the power is on, a failure is caused by any of the following that results in a low voltage supply, the CPU will turn the unit off in 1.5 seconds to prevent further damage:


- Failure within the power supply circuits.
- A short circuit in the load side from the supply.
- Stoppage of the Horizontal Output Oscillator caused by the X-Radiation protection Hold-Down Circuit.

If, while the power is off, the power is switched on and any of these failures remains uncorrected, the CPU will shut off the power within three seconds.

Check the following if the unit is turned off by the power failure detector.

- 1. Disconnect the AC power cord (120V AC line) for at least 10 seconds.
- 2. Connect a DC Voltmeter to the circuits shown below.

Block Diagram (Power Fail Lines)



- 3. Press the Power key and check for the proper voltage supplies.
- 4. If any of these voltages is low, the power failure detector should turn the unit off within three seconds.
- 5. Check all circuits shown above.

Note: This unit is equipped with a Power Surge Protection feature included in the CPU. If power failure occurs three times within 15 minutes, the CPU will automatically stop functioning to help prevent secondary damage. (TV will not turn on by pressing the power key.) To reset the operating programs within the CPU, disconnect the AC power cord for at least 10 seconds.

MECHANICAL DISASSEMBLIES

CABINET BACK REMOVAL

- 1. Refer to Figure 1, remove 13 screws.
- 2. Pull off cabinet back and remove.




Figure 1. Cabinet Back Removal

CHASSIS REMOVAL

- 1. Remove cabinet back.
- 2. Discharge the picture tube anode (2nd anode lead) to the dag coating (picture tube grounding lead).
- Disconnect degaussing coil socket (KD), picture tube socket, deflection yoke connector (KX), speakers connector (KSP), picture tube ground leads (2), velocity modulation coil connector (K17A) and 2nd anode lead.
- 4. Remove chassis completely by sliding it straight back.

PICTURE TUBE REMOVAL

CAUTION: Do not disturb the deflection yoke or magnet assembly on the picture tube neck. Care must be taken to keep these assemblies intact, unless picture tube is being replaced. Discharge the picture tube to the coating before handling the tube.

- 1. Remove chassis, referring to Chassis Removal instructions.
- 2. Place cabinet's front face down on a soft surface.
- Remove the screw on each corner of the picture tube and GENTLY lift the picture tube out of the cabinet.
- 4. Install a replacement picture tube in reverse order. Properly install the degaussing coil and picture tube grounding lead on the picture tube. See Figure 2.

Note: If Picture Tube is being replaced, mount the Degaussing Coil properly on the tube. See Figure 2.




Figure 2. Picture Tube Removal

CHASSIS ELECTRICAL PARTS LIST

CAUTION: To Protect against electrical shock and for continued product safety, refer to SAFETY PRECAUTIONS, X-RADIATION PRECAUTIONS, HIGH VOLTAGE HOLD-DOWN TEST, and PRODUCT SAFETY NOTICE on Page 2.

PRODUCT SAFETY NOTICE

PRODUCT SAFETY SHOULD BE CONSIDERED WHEN A REPLACEMENT IS MADE IN ANY AREA OF A RECEIVER. COMPONENTS INDICATED BY A STAR (*) IN THIS PARTS LIST AND THE SCHEMATIC DIAGRAM DESIGNATE COMPONENTS IN WHICH SAFETY CAN BE OF SPECIAL SIGNIFICANCE. IT IS PARTICULARLY RECOMMENDED THAT ONLY PARTS DESIGNATED ON THE FOLLOWING PARTS LIST BE USED FOR COMPONENT REPLACEMENT DESIGNATED BY A STAR. NO DEVIATIONS FROM RESISTANCE, WATTAGE, AND VOLTAGE RATINGS MAY BE MADE FOR REPLACEMENT ITEMS DESIGNATED BY A STAR.

Numbers 1700 SeriesOn the Velocity Modulation Board

Numbers 2000 Series On the Video Board

All Other NumbersOn the Main Board and AV Board

Note: Schematic part location numbers may not always match with the part descriptions.

Q . .+30 - 10% T . .+50 - 10% U . .+75 - 10% V . .+20 - 10% W .+100 - 10% X . .+40 - 20%

The part descriptions are correct and should be used.

CAPACITORS

NOTES:

(Example)

Read description of the Capacitor as follows:

CERAMIC 100P Κ 50V - Rated Voltage Tolerance Symbols: less than 10PF A . . Not specified B . .±0.1PF C . .±0.25PF D . .±0.5PF F ..±1PF G . ±2PF R . .+0.25 - 0PF S ..+0 - 0.25PF E ..+0 - 1PF more than 10PF A . . Not specified B . .±0.1% C ..±0.25% D . .±0.5% F ..±1% G . .±2% H . .±3% J . .±5% K . .±10% L ..±15% M . .±20% N . .±30% P ..+100 - 0%

Y ..+150 - 10% Z ..+80 - 20%

Rated Value: P...Pico Farad U...Micro Farad Material:
CERAMIC Ceramic MT-PAPER Metalized Paper

POLYESTER ...Polyester MT-POLYEST ..Metalized Polyester

POLYPROPolypropylene MT-POLYPRO ..Metalized Polypropylene

COMPO-FILM ...Composite Film MT-COMPOMetalized Composite

STYRENE Styrene
TA-SOLID Tantalum Solid

AL-SOLID Aluminum Solid ELECT Electrolytic


NP-ELECTNon-Polarized Electrolytic
OS-SOLIDAluminum Solid with Organic
Semiconductive Electrolytic

RESISTORS

NOTES

Read description of the Resistor as follows:

FUSIBLE RES Fusible



Schematic Location	Part No.	De	scription	·	Schematic Location	Part No.	De	escription	
	MAIN PC	BOARD	·		C864	403 235 6203	CERAMIC	0.01U Z	
	0.1.0.1.0.1.0.0.1	_			C865	404 084 2507	ELECT	47U M	10V
0.400	CAPACITOR				C866	404 084 3801	ELECT	1U M	50V
C100	403 224 6108	CERAMIC	0.01U K		C867	403 235 6203	CERAMIC	0.01U Z	50V
C101	404 084 2408	ELECT	470U M	6.3V	C871	403 279 0106	CERAMIC	0.1U Z	
C102	403 224 6108	CERAMIC	0.01U K		C1261	403 279 0106	CERAMIC	0.1U Z	
C103	403 235 6203	CERAMIC	0.01U Z	50V	C1262	404 084 3207	ELECT	47U M	
C105	404 084 4303	ELECT	47U M	50V	C1263	403 279 0106	CERAMIC	0.1U Z	
C106	403 224 6108	CERAMIC	0.01U K	50V	C1264	403 279 0106	CERAMIC	0.1U Z	
C489	404 084 3306	ELECT	470U M	16V	C1265	403 279 0106	CERAMIC	0.1U Z	
C646	404 084 3405	ELECT	1000U M	25V	C1266	404 085 5606	NP-ELECT	22U M	
C648	403 279 0106	CERAMIC	0.1U Z	25V	C1267	404 085 5606	NP-ELECT	22U M	
C650	404 084 3405	ELECT	1000U M	25V	C1268	404 085 5606	NP-ELECT	22U M	
C651	403 279 0106	CERAMIC	0.1U Z	25V	C1269	404 084 2804	ELECT	100U M	
C652	404 084 3405	ELECT	1000U M	25V	C1270	404 085 5606	NP-ELECT	22U M	
C653	404 087 1804	ELECT	1000U M	10V	C1273	404 085 5606	NP-ELECT	22U M	
C654	403 260 2003	MT-COMPO	1U J	50V	C1276	404 085 5606	NP-ELECT	22U M	16V
C655	403 279 0106	CERAMIC	0.1U Z	25V	C1279	404 088 5702	ELECT	22U M	
C658	404 087 1804	ELECT	1000U M	10V	C1292	404 088 5702	ELECT		
C659	403 260 2003	MT-COMPO	1U J	50V	C1293	404 088 5702		22U M	
C660	404 087 1804	ELECT	1000U M	10V	C1294		ELECT	22U M	16V
C661	404 084 2804	ELECT	1000U M	16V		404 088 5702	ELECT	22U M	16V
C662	404 084 2804	ELECT	1000 M	16V	C1815	403 279 0106	CERAMIC	0.1U Z	
C663	403 279 0106	CERAMIC			C1851	404 084 3207	ELECT	47U M	16V
C664	404 084 2804		0.1U Z	25V	C1852	403 279 0106	CERAMIC	0.1U Z	25V
C665		ELECT	100U M	16V		403 235 0607	CERAMIC	100P J	50V
C666	404 084 2804	ELECT	100U M	16V		403 235 0607	CERAMIC	100P J	50V
	403 279 0106	CERAMIC	0.1U Z	25V		403 235 0904	CERAMIC	180P J	50V
C671	404 084 2804	ELECT	100U M	16V		403 235 1406	CERAMIC	470P J	50V
C672	403 260 2003	MT-COMPO	1U J	50V		403 279 0106	CERAMIC	0.1U Z	25V
C801	403 224 5507	CERAMIC	22P J	50V		403 279 0106	CERAMIC	0.1U Z	25V
C802	403 224 5507	CERAMIC	22P J	50V		403 279 0106	CERAMIC	0.1U Z	25V
C804	403 235 6203	CERAMIC	0.01U Z	50V		403 279 0106	CERAMIC	0.1U Z	25V
C806	403 235 6203	CERAMIC	0.01U Z	50V		404 084 4006	ELECT	2.2U M	50V
C814	403 235 6203	CERAMIC	0.01U Z	50V		403 224 6108	CERAMIC	0.01U K	50V
C816	403 235 0003	CERAMIC	33P J	50V		404 084 2804	ELECT	100U M	16V
C818	403 224 5507	CERAMIC	22P J	50V		403 279 0106	CERAMIC	0.1U Z	25V
C821	403 224 5507	CERAMIC	22P J	50V		404 084 2804	ELECT	100U M	16V
C822	404 084 2408	ELECT	470U M	6.3V		403 279 0106	CERAMIC	0.1U Z	25V
C823	403 235 6203	CERAMIC	0.01U Z	50V		403 279 0106	CERAMIC	0.1U Z	25V
C824	404 084 3801	ELECT	1U M	50V		404 084 3801	ELECT	1U M	50V
C825	403 224 5705	CERAMIC	1000P K	50V		404 084 3801	ELECT	1U M	50V
C826	403 235 0706	CERAMIC	120P J	50V		404 084 2705	ELECT	10U M	16V
C827	403 235 6203	CERAMIC	0.01U Z	50V		404 084 2705	ELECT	10U M	16V
C829	403 235 6203	CERAMIC	0.01U Z	50V		403 279 0106	CERAMIC	0.1U Z	25V
C832	403 224 5507	CERAMIC	22P J	50V	C2907	404 084 2705	ELECT	10U M	16V
C833	403 235 0300	CERAMIC	56P J	50V	C2908	404 084 2804	ELECT	100U M	16V
C834	403 235 0300	CERAMIC	56P J	50V	C2914 4	403 279 0106	CERAMIC	0.1U Z	25V
C835	403 235 0300	CERAMIC	56P J	50V	C2940 4	404 084 2705	ELECT	10U M	16V
C836	403 235 0300	CERAMIC	56P J	50V	C2943 4	404 084 2705	ELECT	10U M	16V
C837	403 235 4605	CERAMIC	270P K	50V	C2945 4	404 084 2705	ELECT	10U M	16V
C840	403 224 5507	CERAMIC	22P J	50V	C2950 4	403 279 0106	CERAMIC	0.1U Z	25V
C841	403 224 5507	CERAMIC	22P J	50V		104 084 2804	ELECT	100U M	16V
C842	403 224 5507	CERAMIC	22P J	50V		104 085 5606	NP-ELECT	22U M	16V
C844	403 224 5804	CERAMIC	2200P K	50V		104 085 5606	NP-ELECT	22U M	16V
C852	403 235 1000	CERAMIC	220P J	50V		104 085 5606	NP-ELECT	22U M	16V
C854	403 155 4600	CERAMIC	4P C	50V		104 087 1200	ELECT	0.1U M	50V
C855	403 155 4600	CERAMIC	4P C	50V		104 089 6500	NP-ELECT	4.7U M	50V
C856	403 155 4600	CERAMIC	4P C	50V		104 084 3801	ELECT	4.70 M	50V 50V
C862	403 235 6203	CERAMIC	0.01U Z	50V		04 084 3801	ELECT	10 M	50V -50V
C863	404 084 3801	ELECT	10 M	50V		04 084 3801	ELECT		
· -		,	10 191	55 V	00704 4	100 POV FO	LLLUI	1U M	50V

Schematic Location	Part No.	De	scription		Schem Locati	I Part No	ο.	Description
C3406	403 343 4603	CERAMIC	0.022U K	50V	D672		5209	DIODE RK46 015-304
C3407	403 224 5804	CERAMIC	2200P K	50V	D676			DIODE 188133
C3408	404 087 1200	ELECT	0.1U M	50V	D801			ZENER DIODE UDZS10B TE-17
C3409	404 084 4204	ELECT	4.7U M	50V	D805			ZENER DIODE UDZS10B TE-17
C3410	404 084 3900	ELECT	10U M	50V	D809			ZENER DIODE UDZS10B TE-17
C3411	404 084 3801	ELECT	1U M	50V	D810			ZENER DIODE UDZS10B TE-17
C3412	404 084 3801	ELECT	1U M	50V	D812			ZENER DIODE UDZS5.1B TE-17
C3415	404 084 2903	ELECT 1	000U M	16V	D816		5608	ZENER DIODE UDZS10B TE-17
C3416	404 084 3306	ELECT	470U M	16V	D822	407 206	5608	ZENER DIODE UDZS10B TE-17
C3417	404 084 3801	ELECT	1U M	50V	D825	407 206	5608	ZENER DIODE UDZ\$10B TE-17
C3418	404 084 3801	ELECT	1U M	50V	D826	407 149	0807	DIODE 1SS355 TE-17
C3419	404 084 3801	ELECT	1U M	50V	D827	407 206	5608	ZENER DIODE UDZS108 TE-17
C3420	404 084 5607	MT-POLYES		63V	D828	407 206	5608	ZENER DIODE UDZS10B TE-17
C3420	403 260 2904	MT-COMPO		50V	D835		7106	ZENER DIODE UDZS-TE-1712B
C3421	404 084 3900	ELECT	10U M	50V	D836			ZENER DIODE UDZS-TE-1712B
C3422	404 084 4204	ELECT	4.7U M	50V	D837			ZENER DIODE UDZS10B TE-17
C3424	403 224 5804	CERAMIC	2200P K	50V	D838			ZENER DIODE UDZS10B TE-17
C3425	404 084 3801	ELECT	1U M	50V	D839			ZENER DIODE UDZS10B TE-17
C3427	404 084 3801	ELECT	1U M	50V	D840			ZENER DIODE UDZS10B TE-17
C3428	404 084 3801	ELECT	1U M	50V	D841			ZENER DIODE UDZS10B TE-17
C3429	404 084 3801	ELECT	1U M	50V	D842			ZENER DIODE UDZS10B TE-17
C3430	404 089 6500	NP-ELECT	4.7U M	50V	D857			ZENER DIODE UDZS6.2B TE-17
C3435 C3437	404 091 6604 404 091 6604	ELECT	4.7U M	25V	D858			DIODE 1SS133
C3606	404 091 6604	ELECT NP-ELECT	4.7U M 4.7U M	25V 50V	D871 D896	407 206		ZENER DIODE UDZS10B TE-17
C3608	403 235 5701	CERAMIC	5600P K	50V 50V	D897	407 206 407 206		ZENER DIODE UDZS10B TE-17 ZENER DIODE UDZS10B TE-17
C3609	403 325 2504	CERAMIC	0.012U K	50V 50V	D898			ZENER DIODE UDZS10B TE-17
C3610	404 084 3702	ELECT 0	.47U M	50V	D899			ZENER DIODE UDZS10B TE-17
C3611	404 084 3702	ELECT 0	.47U M	50V	D128			DIODE 1SS133
C3612	404 084 3207	ELECT	47U M	16V	D128			DIODE 1SS133
C3613	403 235 1307	CERAMIC	390P J	50V	D340			DIODE SB07-03C-TB
C3615	404 091 6604	ELECT	4.7U M	25V	D341:			ZENER DIODE UDZS10B TE-17
C3616	404 084 3306	ELECT	470U M	16V	D3414			ZENER DIODE UDZS10B TE-17
C3617	404 089 6500	NP-ELECT	4.7U M	50V	D3416	407 221	7106	ZENER DIODE UDZS-TE-1712B
C3618	404 084 2903	ELECT	1000U M	16V	D3617	7 407 092	9526	DIODE SB07-03C-TB
C3619	404 091 6604	ELECT	4.7U M	25V				
C3620	404 089 6500	NP-ELECT	4.7U M	50V				CIRCUITS
C3622	403 224 5606	CERAMIC	2700P K	50V	IC651			IC SI-8050SS LF1113
C3623	403 323 3602	CERAMIC	0.047U K	50V	IC652			IC PQ1CG3032FZ
C3624	403 342 9203	TA-SOLID	3.3U K	10V	IC653			IC PQ1CG3032FZ
C3626	404 089 6500	NP-ELECT	4.7U M	50V	IC661			IC SI-3090FA LF1113
C3627	403 299 1820	TA-SOLID	10U K	10V	IC662			IC SI-3050FA LF1113
C3628	404 084 3801	ELECT	1U M	50V	10801			IC M37151M*-***FP
C3629	404 089 6500	NP-ELECT	4.7U M	50V	IC802 IC803			IC MN1381-Q
C3630	404 089 6500	NP-ELECT	4.7U M	50V	10003	409 495 1 409 383 (IC CAT24WC08P IC 24LC08B/P
C3631 C5506	404 085 5606	NP-ELECT	22U M	16V	IC804			IC TC7SET08F-TE85L
C5506 C5507	403 279 0106 404 084 3801	CERAMIC ELECT	0.1U Z	25V	IC126			IC NJM2534M-TE2
63307	404 004 3001	ELEGI	1U M	50V	IC126			IC NJM2534M-TE2
	DIODES				IC126			IC NJM2534M-TE2
D101	407 221 7106	ZENER DIOD	E UDZS-TF-	1712B	IC126			IC NJM2268M
D651	407 223 5209	DIODE RK46			IC185			IC MC74HC04AF
D653	407 224 4706	ZENER DIOD		(TPH3	IC280			IC TA1318AF
D654	407 012 4406	DIODE 1881:		,	IC290			IC TC4052BF-EL
D655	407 223 5209	DIODE RK46			IC340			IC NJW1142M
D659	407 224 4706	ZENER DIOD	E 02DZ3.0Z(ТРН3	IC360 ⁻			IC CXA2104S
D661	407 012 4406	DIODE 1SS13			IC550			IC M51957BFP
D663	407 012 4406	DIODE 18813	33					
D664	407 012 4406	DIODE 18813						
D665	407 012 4406	DIODE 18813	33					

Schematic Location	Part No.	Description	Schematic Location	Part No.	Description
	COILS			405 173 9902	TR 2SC3928A1S
L001	645 008 2894	INDUCTOR, 5.6U K	Q1293	405 014 4509	TR 2SC2412K-T-96-R
	645 016 3104	INDUCTOR, 5.6U K		405 014 4608	TR 2SC2412K-T-96-S
L101	645 008 2894	INDUCTOR, 5.6U K		405 015 8724	TR 2SC2812-L6-TB
	645 016 3104	INDUCTOR, 5.6U K		405 015 8922	
L651	645 045 9436	INDUCTOR, 330U K		405 163 1602	TR 2SC2812-L7-TB
L652	645 049 3751	INDUCTOR, 47UH K		405 163 1701	TR 2SC2812N-L6-TB
L653	645 047 6655	INDUCTOR, 33U K			TR 2SC2812N-L7-TB
L654	645 047 6655	INDUCTOR, 33U K		405 173 9803	TR 2SC3928A1R
L661	645 049 3751	INDUCTOR, 47UH K	01005	405 173 9902	TR 2SC3928A1S
L801	645 008 2894	INDUCTOR, 470H K	Q1295	405 014 4509	TR 2SC2412K-T-96-R
2001	645 016 3104			405 014 4608	TR 2SC2412K-T-96-S
L802		INDUCTOR, 5.6U K		405 015 8724	TR 2SC2812-L6-TB
LOUZ	645 008 2894	INDUCTOR, 5.6U K		405 015 8922	TR 2SC2812-L7-TB
1.000	645 016 3104	INDUCTOR, 5.6U K		405 163 1602	TR 2SC2812N-L6-TB
L803	645 008 2894	INDUCTOR, 5.6U K		405 163 1701	TR 2SC2812N-L7-TB
	645 016 3104	INDUCTOR, 5.6U K		405 173 9803	TR 2SC3928A1R
L804	645 008 2894	INDUCTOR, 5.6U K		405 173 9902	TR 2SC3928A1S
	645 016 3104	INDUCTOR, 5.6U K	Q1297	405 014 4509	TR 2SC2412K-T-96-R
L811	645 006 2490	INDUCTOR, 1U K		405 014 4608	TR 2SC2412K-T-96-S
	645 016 2411	INDUCTOR, 1U K		405 015 8724	TR 2SC2812-L6-TB
L837	645 006 2490	INDUCTOR, 1U K		405 015 8922	TR 2SC2812-L7-TB
	645 016 2411	INDUCTOR, 1U K		405 163 1602	TR 2SC2812N-L6-TB
L1851	645 008 2894	INDUCTOR, 5.6U K		405 163 1701	TR 2SC2812N-L7-TB
	645 016 3104	INDUCTOR, 5.6U K		405 173 9803	TR 2SC3928A1R
	TRANSISTO	RS	Q2902	405 173 9902	TR 2SC3928A1S
Q825	405 134 5925	TR 2SA1037AK T146 R	Q290Z	405 014 4509	TR 2SC2412K-T-96-R
	405 147 2205	TR 2SA1037AK T146 S		405 014 4608	TR 2SC2412K-T-96-S
	405 002 0308	TR 2SA1037K-T-96-R		405 015 8724	TR 2SC2812-L6-TB
	405 002 0407	TR 2SA1037K-T-96-S		405 015 8922	TR 2SC2812-L7-TB
	405 002 6726	TR 2SA1179-M6		405 163 1602	TR 2SC2812N-L6-TB
	405 002 6924	TR 2SA1179-M7-TB		405 163 1701	TR 2SC2812N-L7-TB
	405 163 1503	TR 2SA1179-M7-1B		405 173 9803	TR 2SC3928A1R
	405 163 2708	TR 2SA1179N-M7-TB		405 173 9902	TR 2SC3928A1S
	405 173 9605		Q2903	405 014 4509	TR 2SC2412K-T-96-R
		TR 2SA1235A1E		405 014 4608	TR 2SC2412K-T-96-S
Q851	405 173 9704	TR 2SA1235A1F		405 015 8724	TR 2SC2812-L6-TB
QOST	405 014 4509	TR 2SC2412K-T-96-R		405 015 8922	TR 2SC2812-L7-TB
	405 014 4608	TR 2SC2412K-T-96-S		405 163 1602	TR 2SC2812N-L6-TB
	405 015 8724	TR 2SC2812-L6-TB		405 163 1701	TR 2SC2812N-L7-TB
	405 015 8922	TR 2SC2812-L7-TB		405 173 9803	TR 2SC3928A1R
	405 163 1602	TR 2SC2812N-L6-TB		405 173 9902	TR 2SC3928A1S
	405 163 1701	TR 2SC2812N-L7-TB	Q2904	405 014 4509	TR 2SC2412K-T-96-R
	405 173 9803	TR 2SC3928A1R		405 014 4608	TR 2SC2412K-T-96-S
	405 173 9902	TR 2SC3928A1S		405 015 8724	TR 2SC2812-L6-TB
Q1280	405 014 4509	TR 2SC2412K-T-96-R		405 015 8922	TR 2SC2812-L7-TB
	405 014 4608	TR 2SC2412K-T-96-S		405 163 1602	
	405 015 8724	TR 2SC2812-L6-TB			TR 2SC2812N-L6-TB
	405 015 8922	TR 2SC2812-L7-TB		405 163 1701	TR 2SC2812N-L7-TB
	405 163 1602	TR 2SC2812N-L6-TB		405 173 9803	TR 2SC3928A1R
	405 163 1701	TR 2SC2812N-L7-TB	00000	405 173 9902	TR 2SC3928A1S
	405 173 9803	TR 2SC3928A1R	Q2906	405 014 4509	TR 2SC2412K-T-96-R
	405 173 9902	TR 2SC3928A1S		405 014 4608	TR 2SC2412K-T-96-S
	100 110 9302	III ZUUJIZOMIO		405 015 8724	TR 2SC2812-L6-TB
Q1281	405.014.4500	TD 0000440V T 00 5		405 015 8922	TR 2SC2812-L7-TB
41201	405 014 4509	TR 2SC2412K-T-96-R		405 163 1602	TR 2SC2812N-L6-TB
	405 014 4608	TR 2SC2412K-T-96-S		405 163 1701	TR 2SC2812N-L7-TB
	405 015 8724	TR 2SC2812-L6-TB		405 173 9803	TR 2SC3928A1R
	405 015 8922	TR 2SC2812-L7-TB		405 173 9902	TR 2SC3928A1S
	405 163 1602	TR 2SC2812N-L6-TB	Q2910	405 014 4509	TR 2SC2412K-T-96-R
	405 163 1701	TR 2SC2812N-L7-TB		405 014 4608	TR 2SC2412K-T-96-S
	405 173 9803	TR 2SC3928A1R			

Schematic Location	Part No.	Description	Schematic Location	Part No.	Description
		TD 0000040 L7 TD	Location	105 170 0000	TD 0000000140
Q2910 (Cor	nt.)405 015 8922 405 163 1602	TR 2SC2812-L7-TB TR 2SC2812N-L6-TB	05501	405 173 9902	TR 2SC3928A1S
			Q5501	405 014 4509 405 014 4608	TR 2SC2412K-T-96-R
	405 163 1701	TR 2802812N-L7-TB			TR 2SC2412K-T-96-S
	405 173 9803 405 173 9902	TR 2SC3928A1R TR 2SC3928A1S		405 015 8724	TR 2SC2812-L6-TB TR 2SC2812-L7-TB
Q2942	405 173 9902	TR 2SC2412K-T-96-R		405 015 8922 405 163 1602	TR 2SC2812N-L6-TB
Q2342	405 014 4608	TR 2SC2412K-T-96-S		405 163 1701	TR 2SC2812N-L7-TB
	405 015 8724	TR 2SC2812-L6-TB		405 173 9803	TR 2SC3928A1R
	405 015 8922	TR 2SC2812-L7-TB		405 173 9902	TR 2SC3928A1S
	405 163 1602	TR 2SC2812N-L6-TB	Q5502	405 014 4509	TR 2SC2412K-T-96-R
	405 163 1701	TR 2SC2812N-L7-TB	Q0002	405 014 4608	TR 2SC2412K-T-96-S
	405 173 9803	TR 2SC3928A1R		405 015 8724	TR 2SC2812-L6-TB
	405 173 9902	TR 2SC3928A1S		405 015 8922	TR 2SC2812-L7-TB
Q2943	405 014 4509	TR 2SC2412K-T-96-R		405 163 1602	TR 2SC2812N-L6-TB
	405 014 4608	TR 2SC2412K-T-96-S		405 163 1701	TR 2SC2812N-L7-TB
	405 015 8724	TR 2SC2812-L6-TB		405 173 9803	TR 2SC3928A1R
	405 015 8922	TR 2SC2812-L7-TB		405 173 9902	TR 2SC3928A1S
	405 163 1602	TR 2SC2812N-L6-TB			
	405 163 1701	TR 2SC2812N-L7-TB		RESISTORS	
	405 173 9803	TR 2SC3928A1R	R101	401 024 6700	CARBON 100 JA 1/6W
	405 173 9902	TR 2SC3928A1S	R102	401 024 6700	CARBON 100 JA 1/6W
Q2950	405 014 4509	TR 2SC2412K-T-96-R	R103	401 026 0607	CARBON 270 JA 1/6W
	405 014 4608	TR 2SC2412K-T-96-S	R104	401 026 9907	CARBON 4.7K JA 1/6W
	405 015 8724	TR 2SC2812-L6-TB	R106	401 024 6700	CARBON 100 JA 1/6W
	405 015 8922	TR 2SC2812-L7-TB	R634	401 256 6905	MT-GLAZE 680 JA 1/10W
	405 163 1602	TR 2SC2812N-L6-TB	R650	401 256 6905	MT-GLAZE 680 JA 1/10W
	405 163 1701	TR 2SC2812N-L7-TB	R651	401 256 2907	MT-GLAZE 150 JA 1/10W
	405 173 9803	TR 2SC3928A1R	R652 R653	401 162 4002	MT-GLAZE 560 JA 1/10W MT-GLAZE 1.2K JA 1/10W
00410	405 173 9902	TR 2SC3928A1S	R654	401 162 2404 401 256 3706	MT-GLAZE 1.2K JA 1/10W MT-GLAZE 750 JA 1/10W
Q3410	405 014 4509	TR 2SC2412K-T-96-R	R655	401 162 3104	MT-GLAZE 730 3A 1/10W
	405 014 4608 405 015 8724	TR 2SC2412K-T-96-S TR 2SC2812-L6-TB	R656	401 150 6100	MT-GLAZE 2.2K JA 1/10W
	405 015 8922	TR 2SC2812-L7-TB	R659	401 150 6001	MT-GLAZE 0.000 ZA 1/10W
	405 163 1602	TR 2SC2812N-L6-TB	★ R663	401 069 0404	OXIDE-MT 6.8 JA 2W
	405 163 1701	TR 2SC2812N-L7-TB	R665	401 150 6209	MT-GLAZE 1K JA 1/10W
	405 173 9803	TR 2SC3928A1R	★ R666	401 111 3100	OXIDE-MT 0.82 JA 2W
-	405 173 9902	TR 2SC3928A1S	R676	401 150 6209	MT-GLAZE 1K JA 1/10W
Q3420	405 014 4509	TR 2SC2412K-T-96-R	R801	401 162 4101	MT-GLAZE 5.6K JA 1/10W
	405 014 4608	TR 2SC2412K-T-96-S	R802	401 150 5905	MT-GLAZE 10K JA 1/10W
	405 015 8724	TR 2SC2812-L6-TB	R803	401 150 6001	MT-GLAZE 0.000 ZA 1/10W
	405 015 8922	TR 2SC2812-L7-TB	R804	401 255 6500	MT-GLAZE 100 JA 1/10W
	405 163 1602	TR 2SC2812N-L6-TB	R805	401 024 6700	CARBON 100 JA 1/6W
	405 163 1701	TR 2SC2812N-L7-TB	R806	401 255 6500	MT-GLAZE 100 JA 1/10W
	405 173 9803	TR 2SC3928A1R	R807	401 024 6700	CARBON 100 JA 1/6W
	405 173 9902	TR 2SC3928A1S	R809	401 024 6700	CARBON 100 JA 1/6W
Q3457	405 014 4509	TR 2SC2412K-T-96-R	R810	401 162 3708	MT-GLAZE 4.7K JA 1/10W
	405 014 4608	TR 2SC2412K-T-96-S	R811	401 150 5905	MT-GLAZE 10K JA 1/10W
	405 015 8724	TR 2SC2812-L6-TB	R812	401 024 7004	CARBON 1K JA 1/6W
	405 015 8922	TR 2SC2812-L7-TB	R814	401 255 6500	MT-GLAZE 100 JA 1/10W
	405 163 1602	TR 2SC2812N-L6-TB	R815	401 150 6209	MT-GLAZE 1K JA 1/10W
	405 163 1701	TR 2SC2812N-L7-TB	R816	401 024 6700	CARBON 100 JA 1/6W
	405 173 9803	TR 2SC3928A1R	R817	401 024 6700	CARBON 100 JA 1/6W
00450	405 173 9902	TR 2SC3928A1S	R823 R824	401 150 5905 401 024 7004	MT-GLAZE 10K JA 1/10W CARBON 1K JA 1/6W
Q3459	405 014 4509	TR 2SC2412K-T-96-R	R826	401 025 7805	CARBON 1K JA 1/6W CARBON 2.2K JA 1/6W
	405 014 4608	TR 2SC2412K-T-96-S	R827	401 255 6500	MT-GLAZE 100 JA 1/10W
	405 015 8724	TR 2SC2812-L6-TB	R828	401 150 5905	MT-GLAZE 100 JA 1/10W
	405 015 8922	TR 2SC2812-L7-TB	R829	401 255 6500	MT-GLAZE 100 JA 1/10W
	405 163 1602 405 163 1701	TR 2SC2812N-L6-TB TR 2SC2812N-L7-TB	R830	401 150 5806	MT-GLAZE 100 JA 1/10W
	405 173 9803	TR 2SC3928A1R	R831	401 150 5806	MT-GLAZE 100K JA 1/10W
	400 1/0 3000	111 ZOUJJZOKIN	11001	101 100 0000	IIII GENEE TOOK ON THOSE

Schematic		T		0.1	I			
Location	Part No.	Des	cription	Schematic Location	Part No.	Des	scription	
R833	401 256 3805	MT-GLAZE	1.5K JA 1/10W	R1296	401 256 7209	MT-GLAZE	18K JA 1/10W	
R834	401 162 3708	MT-GLAZE	4.7K JA 1/10W	R1297	401 256 4109	MT-GLAZE	56 JA 1/10W	
R835	401 162 3708	MT-GLAZE	4.7K JA 1/10W	R1298	401 150 6209	MT-GLAZE	1K JA 1/10W	
R836	401 162 3708	MT-GLAZE	4.7K JA 1/10W	R1299	401 256 4109	MT-GLAZE	56 JA 1/10W	
R837	401 024 7400	CARBON	10K JA 1/6W	R1851	401 025 4606	CARBON	18K JA 1/6W	
R838	401 024 6700	CARBON	100 JA 1/6W	R1852	401 162 3104	MT-GLAZE	3.3K JA 1/10W	
R839	401 162 3708	MT-GLAZE	4.7K JA 1/10W	R1855	401 256 3607	MT-GLAZE	15K JA 1/10W	
R840	401 150 5905	MT-GLAZE	10K JA 1/10W	R1856	401 256 7209	MT-GLAZE	18K JA 1/10W	
R841	401 162 4101	MT-GLAZE	5.6K JA 1/10W	R1857	401 256 6608	MT-GLAZE	68K JA 1/10W	
R842	401 150 5905	MT-GLAZE	10K JA 1/10W	R2807	401 162 4101	MT-GLAZE	5.6K JA 1/10W	
R843	401 024 6700	CARBON	100 JA 1/6W	R2809	401 256 4901	MT-GLAZE	360 JA 1/10W	
R844	401 024 6700	CARBON	100 JA 1/6W	R2811	401 150 6001	MT-GLAZE	0.000 ZA 1/10W	
R845	401 024 6700	CARBON	100 JA 1/6W	R2815	401 024 6700	CARBON	100 JA 1/6W	
R846 R849	401 162 3708	MT-GLAZE	4.7K JA 1/10W	R2816	401 150 5905	MT-GLAZE	10K JA 1/10W	
R851	401 162 3708	MT-GLAZE	4.7K JA 1/10W	R2819	401 150 5905	MT-GLAZE	10K JA 1/10W	
R852	401 150 5905 401 256 6301	MT-GLAZE MT-GLAZE	10K JA 1/10W 47K JA 1/10W	R2820	401 024 6700	CARBON	100 JA 1/6W	
R853	401 256 6301	MT-GLAZE	47K JA 1/10W	R2821	401 255 6500	MT-GLAZE	100 JA 1/10W	
R854	401 162 3708	MT-GLAZE	4.7K JA 1/10W	R2822	401 255 6500	MT-GLAZE	100 JA 1/10W	
R855	401 162 4101	MT-GLAZE	5.6K JA 1/10W	R2824 R2827	401 150 6001	MT-GLAZE	0.000 ZA 1/10W	
R856	401 162 4101	MT-GLAZE	5.6K JA 1/10W	R2828	401 024 6700	CARBON	100 JA 1/6W	
R866	401 255 6005	MT-GLAZE	1M JA 1/10W	R2829	401 150 5905	MT-GLAZE MT-GLAZE	10K JA 1/10W	
R876	401 024 7004	CARBON	1K JA 1/6W	R2830	401 150 5905 401 024 6700	CARBON	10K JA 1/10W 100 JA 1/6W	
R880	401 256 7308	MT-GLAZE	6.8K JA 1/10W	R2901	401 150 6100	MT-GLAZE	2.2K JA 1/10W	
R881	401 256 7308	MT-GLAZE	6.8K JA 1/10W	R2902	401 150 5905	MT-GLAZE	10K JA 1/10W	
R883	401 256 7308	MT-GLAZE	6.8K JA 1/10W	R2903	401 024 7004	CARBON	1K JA 1/6W	
R886	401 150 5905	MT-GLAZE	10K JA 1/10W	R2904	401 150 5905	MT-GLAZE	10K JA 1/10W	
R887	401 150 5905	MT-GLAZE	10K JA 1/10W	R2906	401 026 9303	CARBON	47 JA 1/6W	
R894	401 150 6209	MT-GLAZE	1K JA 1/10W	R2907	401 256 0408	MT-GLAZE	12K JA 1/10W	
R895	401 024 7004	CARBON	1K JA 1/6W	R2908	401 256 0408	MT-GLAZE	12K JA 1/10W	
R896	401 024 6700	CARBON	100 JA 1/6W	R2909	401 256 5601	MT-GLAZE	47 JA 1/10W	
R897	401 024 6700	CARBON	100 JA 1/6W	R2910	401 150 6100	MT-GLAZE	2.2K JA 1/10W	
R898	401 024 6700	CARBON	100 JA 1/6W	R2916	401 026 9303	CARBON	47 JA 1/6W	
R899	401 024 6700	CARBON	100 JA 1/6W	R2917	401 256 0408	MT-GLAZE	12K JA 1/10W	
R1262	401 256 2709	MT-GLAZE	75 JA 1/10W	R2918	401 256 0408	MT-GLAZE	12K JA 1/10W	
R1263	401 027 6608	CARBON	75 JA 1/6W	R2919	401 256 5601	MT-GLAZE	47 JA 1/10W	
R1264	401 024 7004	CARBON	1K JA 1/6W	R2920	401 150 6100	MT-GLAZE	2.2K JA 1/10W	
R1265	401 256 2709	MT-GLAZE	75 JA 1/10W	R2921	401 024 7004	CARBON	1K JA 1/6W	
R1266	401 027 6608	CARBON	75 JA 1/6W	R2922	401 150 6100	MT-GLAZE	2.2K JA 1/10W	
R1267	401 256 1702	MT-GLAZE	33K JA 1/10W	R2926	401 026 9303	CARBON	47 JA 1/6W	
R1268	401 256 2709	MT-GLAZE	75 JA 1/10W	R2927	401 256 0408	MT-GLAZE	12K JA 1/10W	
R1269	401 027 6608	CARBON	75 JA 1/6W	R2928	401 256 0408	MT-GLAZE	12K JA 1/10W	
R1270 R1271	401 024 6700	CARBON	100 JA 1/6W 100 JA 1/6W	R2929	401 256 5601	MT-GLAZE	47 JA 1/10W	
R1271	401 024 6700 401 024 6700	CARBON CARBON	100 JA 1/6W	R2930	401 150 6100	MT-GLAZE	2.2K JA 1/10W	
R1272	401 150 6209	MT-GLAZE	1K JA 1/10W	R2931 R2932	401 256 2709	MT-GLAZE	75 JA 1/10W	
R1279	401 256 4109	MT-GLAZE	56 JA 1/10W	R2933	401 256 2709 401 256 2709	MT-GLAZE MT-GLAZE	75 JA 1/10W 75 JA 1/10W	
R1281	401 256 6301	MT-GLAZE	47K JA 1/10W	R2940	401 256 0408	MT-GLAZE	12K JA 1/10W	
R1282	401 150 5905	MT-GLAZE	10K JA 1/10W	R2941	401 256 0408	MT-GLAZE	12K JA 1/10W	
R1283	401 162 3005	MT-GLAZE	22K JA 1/10W	R2942	401 256 5601	MT-GLAZE	47 JA 1/10W	
R1284	401 024 7400	CARBON	10K JA 1/6W	R2943	401 150 6100	MT-GLAZE	2.2K JA 1/10W	
R1285	401 256 1702	MT-GLAZE	33K JA 1/10W	R2944	401 026 9303	CARBON	47 JA 1/6W	
R1286	401 256 7209	MT-GLAZE	18K JA 1/10W	R2945	401 256 2709	MT-GLAZE	75 JA 1/10W	
R1287	401 256 1702	MT-GLAZE	33K JA 1/10W	R2946	401 256 0408	MT-GLAZE	12K JA 1/10W	
R1288	401 256 4109	MT-GLAZE	56 JA 1/10W	R2947	401 256 0408	MT-GLAZE	12K JA 1/10W	
R1289	401 256 7209	MT-GLAZE	18K JA 1/10W	R2948	401 256 5601	MT-GLAZE	47 JA 1/10W	
R1290	401 256 1702	MT-GLAZE	33K JA 1/10W	R2949	401 150 6100	MT-GLAZE	2.2K JA 1/10W	
R1291	401 256 4109	MT-GLAZE	56 JA 1/10W	R2950	401 026 9303	CARBON	47 JA 1/6W	
R1294	401 256 4109	MT-GLAZE	56 JA 1/10W	R2951	401 256 0408	MT-GLAZE	12K JA 1/10W	
R1295	401 150 6209	MT-GLAZE	1K JA 1/10W	R2952	401 150 6100	MT-GLAZE	2.2K JA 1/10W	

Schematic Location	Part No.	Des	cription	Schematic Location	Part No.	Desc	cription	,
R2953	401 026 9303	CARBON	47 JA 1/6W	PO	WER / DEFLE	CTION PO	BOAF	RD
R2954	401 256 2709	MT-GLAZE	75 JA 1/10W					
R2955	401 256 2709	MT-GLAZE	75 JA 1/10W	_	CAPACITORS			
R2956	401 256 2709	MT-GLAZE	75 JA 1/10W	C401	403 050 6600	ELECT	3.3U M	50V
R2957	401 256 5601	MT-GLAZE	47 JA 1/10W	C402	403 148 1609	ELECT	470U M	50V
R2958	401 256 2709	MT-GLAZE	75 JA 1/10W	★ C403	403 247 5003	CERAMIC	470P K	1K
R2959	401 256 0408	MT-GLAZE	12K JA 1/10W	★ C404	403 222 1907	CERAMIC	2200P K	1K
R2960	401 256 2709	MT-GLAZE	75 JA 1/10W		403 263 6305	CERAMIC	2200P K	1K
R3411	401 150 5905	MT-GLAZE	10K JA 1/10W	C405	403 334 4209	ELECT	2200U M	16V
R3412	401 150 5905	MT-GLAZE	10K JA 1/10W	C408	403 364 5405	CERAMIC	150P K	1K
R3413	401 024 6700	CARBON	100 JA 1/6W	★ C411	403 348 5625	MT-POLYPRO		1.5K
R3414	401 024 6700	CARBON	100 JA 1/6W	★ C412	403 348 5625	MT-POLYPRO	04000P H	1.5K
R3415	401 255 6500	MT-GLAZE	100 JA 1/10W	★ C414	403 076 0507	CERAMIC	2200P K	500V
R3416	401 150 6209	MT-GLAZE	1K JA 1/10W	★ C415	403 324 3106	CERAMIC	820P K	3K
R3417	401 255 6500	MT-GLAZE	100 JA 1/10W	★ C416	403 076 1405	CERAMIC	2700P K	500V
R3422	401 150 5905	MT-GLAZE	10K JA 1/10W	★ C417	403 036 5207	CERAMIC	68P J	500V
R3423	401 150 5905	MT-GLAZE	10K JA 1/10W	C421	404 091 6406	ELECT	220U M	6.3V
R3424	401 024 6700	CARBON	100 JA 1/6W	★ C423	403 349 3105	MT-POLYPRO	0.12U J	250V
R3425	401 150 6209	MT-GLAZE	1K JA 1/10W		403 376 2706	MT-POLYPRO	0.12U J	250V
R3426	401 024 6700	CARBON	100 JA 1/6W		403 372 6203	MT-POLYPRO	0.12U J	250V
R3434	401 162 4002	MT-GLAZE	560 JA 1/10W	★ C424	403 349 3105	MT-POLYPRO	0.12U J	250V
R3435	401 150 5806	MT-GLAZE	100K JA 1/10W		403 376 2706	MT-POLYPRO	0.12U J	250V
R3436	401 162 4002	MT-GLAZE	560 JA 1/10W		403 372 6203	MT-POLYPRO	0.12U J	250V
R3437	401 150 5806	MT-GLAZE	100K JA 1/10W	C460	403 183 7901	MT-POLYEST	0.1U K	100V
R3458	401 150 6209	MT-GLAZE	1K JA 1/10W	★ C462	403 084 3527	POLYPRO	6800P J	630V
R3460	401 150 6209	MT-GLAZE	1K JA 1/10W	★ C463	403 084 3527	POLYPRO	6800P J	630V
R3601	401 150 5905	MT-GLAZE	10K JA 1/10W	★ C464	403 188 0808	MT-POLYEST	2.2U J	100V
R3602	401 150 5905	MT-GLAZE	10K JA 1/10W	★ C465	403 188 0808	MT-POLYEST	2.2U J	100V
R3603	401 025 7409	CARBON	220 JA 1/6W	★ C466	403 188 0808	MT-POLYEST	2.2U J	100V
R3604	401 025 7409	CARBON	220 JA 1/6W	C468	403 258 8505	NP-ELECT	22U M	16V
R3608	401 255 6005	MT-GLAZE	1M JA 1/10W	★ C470	403 084 3527	POLYPRO	6800P J	630V
R3609	401 150 5806	MT-GLAZE	100K JA 1/10W	C471	403 063 7809	POLYESTER	0.082U K	50V
R3611	401 256 7308	MT-GLAZE	6.8K JA 1/10W		403 312 3507	POLYESTER	0.082U K	50V
R3613	401 265 4008	MT-GLAZE	62K JA 1/10W	C472	403 059 6205	POLYESTER	0.022U K	50V
R3622	401 162 3104	MT-GLAZE	3.3K JA 1/10W		403 312 0506	POLYESTER	0.022U K	50V
R3623	401 255 6401	MT-GLAZE	3K JA 1/10W	C482	403 259 9907	ELECT	47U M	160V
R3628	401 256 7605	MT-GLAZE	3.9K JA 1/10W	C483	403 059 3808	POLYESTER	2200P K	50V
R5501	401 256 0408	MT-GLAZE	12K JA 1/10W		403 312 0308	POLYESTER	2200P K	50V
R5502	401 150 5905	MT-GLAZE	10K JA 1/10W	C484	404 084 4204	ELECT	4.7U M	50V
R5503	401 150 5905	MT-GLAZE	10K JA 1/10W	C493	404 056 5307	NP-ELECT	2.2U M	100V
R5504	401 256 6301	MT-GLAZE	47K JA 1/10W	C504	403 209 7205	ELECT	2200U M	25V
R5505	401 256 6301	MT-GLAZE	47K JA 1/10W	C505	403 148 0404	ELECT	1000U M	25V
R5506	401 162 3005	MT-GLAZE	22K JA 1/10W	C507	403 148 1401	ELECT	220U M	50V
R5507	401 024 7400	CARBON	10K JA 1/6W	C508	403 161 8302	MT-POLYEST	0.47U K	100V
				C510	403 036 2503	CERAMIC	47P K	
	MISCELLAN			C513	403 075 8009	CERAMIC	0.01U K	
A100	610 312 3240		MAIN-H3ELM	C515	404 084 4006	ELECT	2.2U M	50V
★ A101	645 064 2555	TUNER, TU/I		★ C608	403 247 5003	CERAMIC	470P K	1K
X2809	645 046 9213		IIC 503.0KHZ		403 269 1809	CERAMIC	470P K	1K
X8219	645 026 8434	OSC, CRYST	AL 8.000MHZ		403 232 0501	CERAMIC	470P K	1K
				★ C609	404 096 2809	ELECT	680U M	200V
				C613	403 148 1708	ELECT	100U M	35V
				C614	403 083 4307	POLYPRO	0.022U J	400V
				C615	403 138 9905	POLYESTER	470P J	50V
					403 276 9102	POLYESTER	470P J	50V
				C616	403 057 5309	POLYESTER	1200P J	50V
					403 179 3702	POLYESTER	1200P J	50V
				C619	403 069 8305	CERAMIC	0.01U Z	50V
				C622	404 085 4500		2200U M	25V
				C624	404 096 2403	ELECT	470U M	160V

Schematic Location	Part No.	De	scription		Schematic Location	Part No.	Description
C625	403 266 5008	CERAMIC	2700P K	1K	D504	407 100 0204	ZENER DIODE MTZJ36A
	403 232 0402	CERAMIC	2700P K	1K		407 100 0303	ZENER DIODE MTZJ36B
C626	403 196 4201	ELECT	3300U M	16V		407 100 0402	ZENER DIODE MTZJ36C
C628A	404 096 2403	ELECT	470U M	160V	D508	408 008 2406	DIODE 1N4148
C629	403 196 4201	ELECT	3300U M	16V		407 013 4306	DIODE 182076A
★ C633	404 088 7706	CERAMIC	1500P M	250V		407 013 7109	DIODE 1S2473
	404 088 7805	CERAMIC	1500P M	250V	D509	407 063 9108	ZENER DIODE MTZJ6.8B
★ C635	404 088 7706	CERAMIC	1500P M	250V	2000	407 099 5709	ZENER DIODE MTZJ6.8C
	404 088 7805	CERAMIC	1500P M	250V	D510	408 008 2406	
C640	404 092 1905	ELECT	100U M	50V	0010	407 013 4306	DIODE 1N4148
C641	403 271 9602	CERAMIC	1000P K	1K			DIODE 1S2076A
	403 262 1806	CERAMIC	1000P K	1K	D511	407 013 7109	DIODE 1S2473
C642	404 092 2001	ELECT	470U M	50V	D512	407 118 2207	ZENER DIODE 1Z75
C644	404 074 9103	ELECT	220U M	160V		407 118 2207	ZENER DIODE 1Z75
C656	404 087 3105	ELECT	2200 M	50V	D513	407 063 8606	ZENER DIODE MTZJ5.1A
C686	403 247 5003	CERAMIC				407 099 5204	ZENER DIODE MTZJ5.1B
0000	403 269 1809		470P K	1K		407 063 8705	ZENER DIODE MTZJ5.1C
		CERAMIC	470P K	1K	D514	407 063 8606	ZENER DIODE MTZJ5.1A
	403 232 0501	CERAMIC	470P K	1K		407 099 5204	ZENER DIODE MTZJ5.1B
	DIODES					407 063 8705	ZENER DIODE MTZJ5.1C
D401		ZENED DIOE	NE 47450		★ D612	407 231 2801	PHOTO COUPLE PC123YC2
D401 D402	407 222 4401	ZENER DIOD			D613	407 006 0100	DIODE ERA91-02
0402	408 008 2406	DIODE 1N41			D614	407 006 0100	DIODE ERA91-02
	407 013 4306	DIODE 1S20			D615	407 099 3309	ZENER DIODE MTZJ13C
	407 013 7109	DIODE 1S24				407 054 4808	ZENER DIODE RD13EB3
D411	407 142 5908	DIODE FMP-			D616	408 008 2406	DIODE 1N4148
D412	407 157 0806	DIODE RS4F				407 013 4306	DIODE 1S2076A
D413	407 063 9603	ZENER DIOD	E MTZJ9.1A			407 013 7109	DIODE 182473
	407 099 6003	ZENER DIOC	E MTZJ9.1B		D617	408 008 2406	DIODE 182473
★ D421	407 158 1307	ZENER DIOD	E HZ11B2L		2011	407 013 4306	DIODE 1S2076A
★ D422	407 158 1307	ZENER DIOD	E HZ11B2L		D618	408 008 2406	DIODE 1N4148
D428	407 099 8007	ZENER DIOD	E MTZJ20C		D010	407 013 4306	DIODE 182076A
	407 055 1905	ZENER DIOD				407 013 4300	
D429	408 008 2406	DIODE 1N41			D621	407 106 2806	DIODE 1S2473
	407 013 4306	DIODE 18207			D623		DIODE RU3YX
	407 013 7109	DIODE 1S247			DUZO	408 008 2406	DIODE 1N4148
D460	408 008 2406	DIODE 1N414				407 013 4306	DIODE 1S2076A
	407 013 4306	DIODE 1S207			Den4	407 013 7109	DIODE 1S2473
	407 013 7109	DIODE 1S247			D624	407 168 6507	DIODE FMX-G12S
D461	407 221 5003	DIODE FMC-(D625	407 191 3900	DIODE FML-G16S
D462	407 099 6102	ZENER DIODI			D627	407 168 6507	DIODE FMX-G12S
D467	408 008 2406	DIODE 1N414			D631	407 007 7603	DIODE EU2
<i>-</i>	407 013 4306	DIODE 18207			_	407 007 7801	DIODE EU2Z
	407 013 7109	DIODE 13207			D635	407 099 9509	ZENER DIODE MTZJ30B
D468	408 008 2406				D641	407 007 7306	DIODE EU01Z
D400		DIODE 1N414			D642	407 099 9509	ZENER DIODE MTZJ30B
	407 013 4306	DIODE 1S207				407 056 0204	ZENER DIODE RD30EB2
D 404	407 013 7109	DIODE 1S247			D643	407 222 4401	ZENER DIODE 1Z150
D481	407 124 6404	DIODE ERA18	3-04		D649	408 008 2406	DIODE 1N4148
	407 007 6606	DIODE ES1				407 013 4306	DIODE 1S2076A
	407 124 5506	DIODE RMPG	06G			407 013 7109	DIODE 1S2473
D482	407 011 4407	DIODE TVR16			D652	408 008 2406	DIODE 1824/3
D486	408 008 2406	DIODE 1N414	8		5002	407 013 4306	DIODE 182076A
	407 013 4306	DIODE 1S207				407 013 4306	
	407 013 7109	DIODE 1S247			D656		DIODE 1S2473
D501	407 005 7308	DIODE EM01Z			D695	407 106 2806	DIODE RUSYX
	407 005 8602	DIODE ERA15			נפסט	407 129 3002	DIODE ERA22-06
	407 088 6502	DIODE MPGO				407 007 7108	DIODE EU01A
D502	407 118 2207	ZENER DIODE				INITEODATES	CIDOLITO
D502	407 110 2207	ZENER DIODE			1 1000	INTEGRATED	
2000	407 100 0204	ZENER DIODE			★ IC501	409 374 0607	IC LA7846N
					★ IC601	409 169 5800	IC SE140NL
	407 100 0402	ZENER DIODE	W17736C		IC602	410 355 9205	IC STR-F6628 LF1351

Schematic	.]					1			
Location	Part No.		Descriptio	on	Schematic Location	Part No.	De	scription	1
	COILS				R428	401 025 1902	CARBON	15K J	A 1/6V
L411	610 236 6440	JUMPER	LEAD		R429	401 025 5405	CARBON	2.2 J	
L413	610 078 5946	PIPE COP	RE		★ R461	402 002 9805	FUSIBLE RE		
L414	610 078 6820	PIPE COR	ξE		R462	401 202 1909	MT-FILM	680 F	
L416	610 078 4635	PIPECOR	E		R464	401 097 3903	MT-FILM		
L417	610 078 4635	PIPECORI			R466	401 053 3008		39K F/	
L421	645 039 9381	COIL, LIN			R467	401 053 2605	MT-FILM	470 FA	
L460	645 020 4043	INDUCTO			R468		MT-FILM	3.3K FA	
★ L461	610 000 0148	COIL	11, 70000		R470	401 024 7004	CARBON	1K JA	
	645 037 8065	INDUCTO	D 21211			401 025 8208	CARBON	22K JA	
★ L462	610 000 0148	COIL	1, 2120		R475	401 097 3903	MT-FILM	39K FA	
A 2102	645 037 8065		2 04011		R480	401 006 7701	CARBON	1 JB	
L463	610 078 5946	INDUCTO			R481	401 006 7701	CARBON	1 JB	1/2W
L464		PIPE COR			R482	401 021 0701	CARBON	56 JA	1/4W
	610 078 5946	PIPE COR			R487	401 008 2605	CARBON	180K JA	1/2W
L610	610 078 5946	PIPE CORI			R488	401 021 3009	CARBON	5.6K JA	1/4W
L613	610 078 5946	PIPE CORI			R491	401 012 5708	CARBON	1K JA	
L621	610 078 5946	PIPE CORI			R493	401 019 2601	CARBON	39K GA	
1.000	652 000 1725	CORE, PIP			R494	401 019 2601	CARBON	39K GA	
L623	610 078 5946	PIPE CORE			R495	401 024 9602	CARBON	12K GA	
	652 000 1725	CORE, PIP	E		★ R497	401 061 0808	OXIDE-MT	3.9 JA	
L624	610 078 5946	PIPE CORE	:		R501	401 026 6906	CARBON	3.9K GA	
	652 000 1725	CORE, PIP	E		★ R503	402 002 3803	FUSIBLE RES		170W
L625	610 078 5946	PIPE CORE			★ R504	402 061 0201	FUSIBLE RES		
	652 000 1725	CORE, PIPI	E		★ R506	401 064 7507	OXIDE-MT	100 JA	1/2W
L628	610 078 5946	PIPE CORE			R507	401 007 3603	CARBON		2W
	652 000 1725	CORE, PIPI			★ R508	401 066 3002		12 JA	
L641	645 007 8156	INDUCTOR			R509	401 053 4203	OXIDE-MT	2.2 JA	2W
	645 005 5423	INDUCTOR			R511		MT-FILM	5.6K FA	1/6W
			, 020 K		R512	401 011 9004	CARBON	1 JB	1/4W
	TRANSISTO	RS			R513	401 026 6906	CARBON	3.9K GA	1/6W
Q401	405 136 0205	TR 2SC529	1S-AY			401 053 4203	MT-FILM	5.6K FA	
	405 136 0304	TR 2SC529			R515	401 027 5502	CARBON	6.8K JA	1/6W
★ Q402	406 017 4503	TR TT2140			R516	401 026 4605	CARBON	33K JA	1/6W
Q460	405 029 6307	TR 2SB817			★ R604	401 068 5509	OXIDE-MT	47K JA	2W
Q462	405 018 0507	TR 2SC333			★ R613	401 238 3304	OXIDE-MT	0.18 JA	2W
	405 018 0606	TR 2SC333			★ R615	401 238 3304	OXIDE-MT	0.18 JA	2W
Q642	405 011 8401				R616	401 014 2903	CARBON	150 JA	1/4W
GOTZ.	405 011 8500	TR 2SC174			R617	401 018 3807	CARBON	3.3K JA	1/4W
		TR 2SC1740			R618	401 024 7004	CARBON	1K JA	
	405 011 8609	TR 2SC1740			R619	401 016 3809	CARBON	2.2K JA	
	405 012 2002	TR 2SC1818			R621	401 026 9907		4.7K JA	
	405 012 2309	TR 2SC1815			R622	401 022 2001	CARBON		1/4W
	405 157 0505	TR 2SC5361			R623	401 027 8602			1/6W
	405 151 8705	TR 2SC536N			R624	401 024 7400	CARBON	10K JA	
	405 020 7501	TR 2SC945A			★ R635	401 065 4604	OXIDE-MT	12K JA	2W
	405 020 7709	TR 2SC945A	\-QA		R640	401 024 7707		100K JA	
					R641	401 011 2708	CARBON		
	RESISTORS				R642	401 025 8208	CARBON	68K JA	
R402	401 027 2303	CARBON	560 JA	1/6W	R646	401 024 7400		22K JA	
R405	401 027 2600	CARBON	5.6K JA	1/6W	11070	401 024 / 400	CARBON	10K JA	1/6W
★ R406	401 064 8702	OXIDE-MT	1K JA	2W		TRANSFORM	EDC		
★ R407	401 068 6902	OXIDE-MT	56 JA	2W		645 041 1083			
★ R409	401 069 5607	OXIDE-MT	8.2 JA	2W			TRANS, DRIVE	217	
★ R410	401 062 5109	OXIDE-MT	56 JA	1W		6450637957	TRANS, FLYBAC		
★ R411	401 063 2008	OXIDE-MT	6.8K JA	1W	★ T601	645 063 6417	TRANS, POWER	i, PULSE	
	401 024 9701	CARBON	12K JA	1/6W					
_	401 012 4503	CARBON	100 JA			MISCELLANE	OUS		
	401 148 7201	MT-FILM		1/4W		610 310 6823	ASSY, PWB, P/[)_H2C1.44	
	401 052 6802		1.8K FA		71701	- 10 010 0020	AUUT, FWD, P/L	rnsuLIVI	
	401 053 2605	MT-FILM	10K FA		,				
	401 067 5302	MT-FILM	3.3K FA						
A 11767	701 007 0002	OXIDE-MT	330 JA	2W					

Schematic Location	Part No.	Description	Schematic Location	Part No.	Description
	FRONT P	C BOARD		TRANSISTO	DRS
	040401701	_	Q001	405 011 8401	TR 2SC1740S-Q
0004	CAPACITOR			405 011 8500	TR 2SC1740S-R
C001	404 084 3900	ELECT 10U M 50V		405 011 8609	TR 2SC1740S-S
C006	404 084 4204	ELECT 4.7U M 50V		405 012 2002	TR 2SC1815-GR
C007	404 089 2700	ELECT 100U M 25V		405 012 2101	TR 2SC1815-0
C008	403 073 8308	CERAMIC 4700PK 50V		405 012 2309	TR 2SC1815-Y
C009	403 073 8308	CERAMIC 4700P K 50V		405 157 0505	TR 2SC536NF-NPA
C010	404 089 4100	ELECT 3300U M 25V		405 151 8705	TR 2SC536NG-NPA
C011	404 089 4100	ELECT 3300U M 25V		405 020 7501	TR 2SC945A-PA
C013	404 084 3900	ELECT 10U M 50V		405 020 7709	TR 2SC945A-QA
C015	404 084 3405	ELECT 1000U M 25V		405 020 7907	TR 2SC945A-RA
★ C600	403 076 4000	CERAMIC 4700P K 500V	Q688	406 000 6804	TR 2SA1015-GR(SAN)
★ C601	404 096 0706	MT-POLYEST 0.22U M 275V		405 001 7605	TR 2SA1015-Y(SAN)
★ C602	403 075 7101	CERAMIC 1000P K 500V		405 004 3208	TR 2SA564A-R(CU)
★ C604	403 075 7101	CERAMIC 1000P K 500V		405 151 3304	TR 2SA608NF-NPA
★ C610	404 096 0508	MT-POLYEST 0.1U M 275V		405 006 1806	TR 2SA933S-R
C688	404 084 2804	ELECT 100U M 16V	Q1611	405 016 9403	TR 2SC3068
C689	403 069 8305	CERAMIC 0.01U Z 50V			
C1613	404 095 1704	ELECT 2200U M 16V		RESISTORS	
C1614	403 069 8305	CERAMIC 0.01U Z 50V	R001	401 024 7004	CARBON 1K JA 1/6W
C1615	404 084 2606	ELECT 470U M 10V	R002	401 024 7004	CARBON 1K JA 1/6W
C1618	403 069 8305	CERAMIC 0.01U Z 50V	R003	401 027 5205	CARBON 680 JA 1/6W
C1620	403 069 8305	CERAMIC 0.01U Z 50V	R004	401 027 5205	CARBON 680 JA 1/6W
C1902	404 084 2705	ELECT 10U M 16V	★ R007	402 070 4108	WIRE WOUND 0.47 KA 5W
C1903	404 084 2408	ELECT 470U M 6.3V		402 073 9506	WIRE WOUND 0.47 KA 5W
	510556		R008	401 027 8602	CARBON 8.2K JA 1/6W
. 5004	DIODES		R011	401 026 3905	CARBON 330 JA 1/6W
★ D601	407 124 9801	DIODE RBV-608	R012	401 027 2600	CARBON 5.6K JA 1/6W
D683	408 008 2406	DIODE 1N4148	★ R601	402 097 5607	WIRE WOUND 1 KA 15W
	407 013 4306	DIODE 1S2076A	★ R602	401 069 3702	OXIDE-MT 6.8K JA 2W
D007	407 013 7109	DIODE 1S2473	R603	402 000 1603	SOLID 3.3M MA 1/2W
D687	408 008 2406	DIODE 1N4148		402 088 1502	RESISTER 3.3M JA 1/2W
	407 013 4306	DIODE 1S2076A		402 090 2108	RESISTER 3.3M JA 1/2W
D4044	407 013 7109	DIODE 1S2473	R686	401 013 4205	CARBON 120 JA 1/4W
D1611	407 012 4406	DIODE 1SS133	R687	401 025 8208	CARBON 22K JA 1/6W
D1612	407 005 8602	DIODE ERA15-02	R688	401 024 9701	CARBON 12K JA 1/6W
D4642	407 124 5605	DIODE RMPG06D	R1611	401 027 2600	CARBON 5.6K JA 1/6W
D1613	407 005 8602	DIODE ERA15-02	R1612	401 026 4605	CARBON 33K JA 1/6W
D1614	407 124 5605	DIODE RMPG06D	R1901	401 024 7400	CARBON 10K JA 1/6W
D1014	407 005 8602	DIODE ERA15-02	R1902	401 024 7004	CARBON 1K JA 1/6W
D1615	407 124 5605	DIODE RMPG06D	R1903	401 025 4200	CARBON 1.8K JA 1/6W
D1615	407 005 8602	DIODE ERA15-02	R1904	401 025 7805	CARBON 2.2K JA 1/6W
D1901	407 124 5605	DIODE RMPG06D	R1905	401 026 7002	CARBON 3.9K JA 1/6W
וטפום	407 063 9306	ZENER DIODE MTZJ7.5C	R1906	401 027 2600	CARBON 5.6K JA 1/6W
	407 057 6502	ZENER DIODE RD7.5EB3	R1909	401 024 7004	CARBON 1K JA 1/6W
	INTEGRATED	CIDCUITE	R1910	401 024 7004	CARBON 1K JA 1/6W
IC001	409 569 1907	IC LA42052-E		011/12/01/20	
IC1611	409 528 6202	IC PQ050ES1MXP	0144004	SWITCHES	
101011	703 320 0202	TO FOUNDESTIMAP	SW1901	645 006 9673	SWITCH, PUSH (POWER)
	COILS			645 027 7382	SWITCH, PUSH (POWER)
★ LF601	645 012 0589	LINE FILTER	01111000	645 052 2284	SWITCH, PUSH (POWER)
	645 026 8274	LINE FILTER	SW1902	645 006 9673	SWITCH, PUSH (VOL +)
★ LF602	645 012 0589	LINE FILTER		645 027 7382	SWITCH, PUSH (VOL +)
	645 026 8274	LINE FILTER	011114	645 052 2284	SWITCH, PUSH (VOL +)
L1901	645 008 2894	INDUCTOR, 5.6U K	SW1903	645 006 9673	SWITCH, PUSH (VOL -)
,	645 016 3104	INDUCTOR, 5.6U K		645 027 7382	SWITCH, PUSH (VOL -)
	100100101	5 5 7 5 11, 5.55 K		645 052 2284	SWITCH, PUSH (VOL -)

Schematic Location	Part No.	Description	Schematic Location	Part No.	De	scription	
SW1904	645 006 9673	SWITCH, PUSH (CH ▲)	C1281	403 279 0106	CERAMIC	0.1U Z	25V
3441904	645 027 7382	SWITCH, PUSH (CH ▲)	C1282	404 084 2804	ELECT	100U M	16V
	645 052 2284	SWITCH, PUSH (CH ▲)	C1283	404 084 2804	ELECT	100U M	16V
SW1905	645 006 9673	SWITCH, PUSH (CH ▼)	C7003	403 235 0003	CERAMIC	33P J	50V
0111000	645 027 7382	SWITCH, PUSH (CH ▼)	C7004	403 235 0003	CERAMIC	33P J	50V
	645 052 2284	SWITCH, PUSH (CH ♥)	C7005	404 084 2507	ELECT	47U M	10V
			C7009	403 279 0106	CERAMIC	0.1U Z	25V
	MISCELLAN		C7010	404 085 4203	ELECT	100U M	10V
A1900	610 311 2145	ASSY, PWB, FRONT-H3GLM UNIT, REMOCON RECEIVER	C7011	403 235 0706	CERAMIC	120P J	50V
A1901	645 047 6228	FUSE 125V 6A	C7012	403 279 0106	CERAMIC	0.1U Z	25V 25V
★ F601	423 030 9704	HOLDER, FUSE	C7020	403 279 0106	CERAMIC	0.1U Z 22P J	50V
F601A	645 000 5077	HOLDER, FUSE	C7021	403 224 5507	CERAMIC NP-ELECT	22F J 22U M	16V
CO4D	645 016 0479 645 000 5077	HOLDER, FUSE	C7022	404 085 5606	ELECT	100U M	10V
F601B	645 016 0479	HOLDER, FUSE	C7023	404 085 4203	ELECT	22U M	16V
★ PS601	408 044 7106	THERMISTOR PTDAA1BF1R5	C7030	404 088 5702	ELECT	100U M	107
★ RL601	645 040 3583	RELAY	C7031 C7032	404 085 4203 403 279 0106	CERAMIC	0.1U Z	25V
* NEUU1	645 059 0306	RELAY	C7032	404 084 4006	ELECT	2.2U M	50V
★ RL602	645 040 3583	RELAY	C7033	404 085 5606	NP-ELECT	22U M	16V
A MEGOZ	645 059 0306	RELAY	C7034	403 224 5705	CERAMIC	1000P K	50V
★ T681	645 065 8938	TRANS, POWER	C7036	404 084 6901	NP-ELECT	1U M	50V
★ VA601	408 023 5802	VARISTOR ENC271D-10AS	C7038	403 093 7206	OS-SOLID	22U M	10V
X *******	407 151 8105	VARISTOR 270NR14D	C7039	403 279 0106	CERAMIC	0.1U Z	25V
★ W601	645 023 1698	CORD, POWER	C7041	403 279 0106	CERAMIC	0.1U Z	25V
	645 056 9548	CORD, POWER-2.05MK	C7101	403 093 7206	OS-SOLID	22U M	10V
			C7102	403 093 7206	OS-SOLID	22U M	10V
	AV SELEC	T PC BOARD	C7103	403 279 0106	CERAMIC	0.1U Z	25V
	O A DA OLTODA	.	C7104	403 224 5507	CERAMIC	22P J	50V
04004	CAPACITORS	S ELECT 10U M 16V	, C7105	403 224 5507	CERAMIC	22P J	50V
C1001	404 084 2705	ELECT 2.2U M 50V		403 279 0106	CERAMIC	0.1U Z	25V
C1002 C1003	404 084 4006 404 084 4006	ELECT 2.2U M 50V	(1/10/	403 279 0106	CERAMIC	0.1U Z	25V
C1003	404 084 2705	ELECT 10U M 16V	, C/108	403 093 7206	OS-SOLID	22U M	10V
C1004 C1005	404 084 4006	ELECT 2.2U M 50V	, 6/109	403 279 0106	CERAMIC	0.1U Z	25V
C1005	404 084 4006	ELECT 2.2U M 50V	, 6/110	403 093 6209	OS-SOLID	10U M	10V
C1008	404 084 4006	ELECT 2.2U M 50V	, G/111	403 279 0106	CERAMIC	0.1U Z	25V
C1009	404 084 4006	ELECT 2.2U M 50V	, 07112	403 279 0106	CERAMIC	0.1U Z	25V
C1054	403 279 0106	CERAMIC 0.1U Z 25V	, 6/113	403 235 0805	CERAMIC	150P J	50V
C1055	404 084 2705	ELECT 10U M 16V	, 6/115	403 235 0805	CERAMIC	150P J	50V 25V
C1056	403 235 6203	CERAMIC 0.01U Z 50V	, C7116	403 279 0106	CERAMIC CERAMIC	0.1U Z 2.2U K	16V
C1057	403 279 0106	CERAMIC 0.1U Z 25V	, C7118	403 314 6209	CERAMIC	0.1U Z	25V
C1059	404 084 2705	ELECT 10U M 16V	C7119	403 279 0106	CERAMIC	0.10 Z	25V
C1201	404 084 5508	MT-POLYEST 0.1UJ 63V	, C7120 , C7121	403 279 0106 403 279 0106	CERAMIC	0.1U Z	25V
C1201	403 237 8007	MT-COMPO 0.1UJ 50V	, 07121 , 07122	403 279 0106	CERAMIC	0.1U Z	25V
C1204	404 084 2606	ELECT 470U M 10\	C7124	403 279 0106	CERAMIC	0.1U Z	25V
C1205	404 088 5702	ELECT 22UM 16V	07106	404 084 2705	ELECT	10U M	16V
C1206	403 235 4704	CERAMIC 330P K 50V	C7197	403 279 0106	CERAMIC	0.1U Z	25V
C1207	403 235 4704	CERAMIC 330P K 50V	C7400	403 279 0106	CERAMIC	0.1U Z	25V
C1211	403 235 6203	CERAMIC 0.01U Z 50\	C7120	403 279 0106	CERAMIC	0.1U Z	25V
C1214	403 235 4704	CERAMIC 330P K 50\	r7120	403 279 0106	CERAMIC	0.1U Z	25V
C1215	403 235 4704	CERAMIC 330P K 50\	r7131	403 279 0106	CERAMIC	0.1U Z	25V
C1231	404 084 2606	ELECT 470U M 10\	r7122	403 093 6209	OS-SOLID	10U M	10V
C1235	403 279 0106	CERAMIC 0.1U Z 25\ ELECT 470U M 10\	(7194	403 279 0106	CERAMIC	0.1U Z	25V
C1236	404 084 2606		/ C712E	403 093 7206	OS-SOLID	22U M	10V
C1238	403 235 6203	= = 1 11 11 11	07106	403 283 6309	CERAMIC	1U K 10	٧
C1241	403 235 0003		(7126	403 309 1400	CERAMIC	1P Z 10V	
C1251	403 279 0106		(7126	403 336 5600	CERAMIC	1.0U Z	10V
C1252	404 084 3207		(1/1/2/	404 084 2507	ELECT	47U M	10V
C1253	404 085 5606	NP-ELECT 22U M 16\ NP-ELECT 22U M 16\	, C7138	403 279 0106	CERAMIC	0.1U Z	25V
C1254	404 085 5606	INT-LLLOI ZZU IVI TO	C7139	403 279 0106	CERAMIC	0.1U Z	25V

Schematic Location	Part No.	Description		Schematic Location	Part No.	Description
C7140	404 084 2507	ELECT 47U M	10V	IC7103	409 517 6107	IC UPC2925T-E2
C7146	403 279 0106	CERAMIC 0.1U Z	25V	IC8201	409 449 2901	IC CXA2019AQ
C7147	404 084 2507	ELECT 47U M	10V	IC8230	409 441 8426	IC LA7217M-T-TRM
C8201	404 084 2903	ELECT 1000U M	16V			
C8202	404 084 3702	ELECT 0.47U M	50V		COILS	
C8203	403 235 0904	CERAMIC 180P J	50V	L1201	645 008 2276	INDUCTOR, 22U K
C8204	403 234 9700	CERAMIC 12P J	50V	L7002	645 040 3101	INDUCTOR, 3.3U M
C8205	403 235 6203	CERAMIC 0.01U Z	50V	L7002	645 026 1008	INDUCTOR, 3.3U M
C8206	403 235 1406	CERAMIC 470P J	50V	L.7003	645 040 3101	INDUCTOR, 3.3U M
C8207	403 235 0607	CERAMIC 100P J	50V		645 026 1008	INDUCTOR, 3.3U M
C8208	404 084 4204	ELECT 4.7U M	50V	L7004	645 040 3101	INDUCTOR, 3.3U M
C8209	404 084 6901	NP-ELECT 1U M	50V		645 026 1008	INDUCTOR, 3.3U M
C8210	403 235 5909	CERAMIC 8200P K	50V	L7007	645 021 1607	INDUCTOR, 10U J
C8211	404 084 3702	ELECT 0.47U M	50V		645 032 8213	INDUCTOR, 100 J
C8212	403 224 5903	CERAMIC 3300P K	50V	L7061	645 025 7797	INDUCTOR, 120 OHM
C8213	404 084 3801	ELECT 1U M	50V	L7101	645 040 3064	INDUCTOR, 10U K
C8214	403 235 6203	CERAMIC 0.01U Z	50V	. =	645 026 0964	INDUCTOR, 10U K
C8216	403 279 0106		25V	L7102	645 040 3064	INDUCTOR, 10U K
C8217	404 084 5508		63V	. =	645 026 0964	INDUCTOR, 10U K
C8217	403 237 8007		50V	L7103	645 040 3064	INDUCTOR, 10U K
C8219	404 084 2903		16V		645 026 0964	INDUCTOR, 10U K
C8227	403 235 1307		50V	L7105	645 025 7797	INDUCTOR, 120 OHM
C8230	404 092 3701		63V	L7106	645 025 7797	INDUCTOR, 120 OHM
C8230	403 219 4904		50V	L7108	645 025 7797	INDUCTOR, 120 OHM
C8231	403 235 6203		50V	L7110	645 025 7797	INDUCTOR, 120 OHM
C8232	403 235 6203		50V	L7112	645 040 3101	INDUCTOR, 3.3U M
C8233	403 309 1202		16V		645 026 1008	INDUCTOR, 3.3U M
C8234	403 235 6203		50V	L7119	645 021 1621	INDUCTOR, 15U J
C8235	403 062 7107		50V	17400	645 030 5627	INDUCTOR, 15U J
C8235	403 179 0503		50V	L7120	645 025 7797	INDUCTOR, 120 OHM
C8236	403 235 4704		50V	L7121	645 025 7797	INDUCTOR, 120 OHM
C8237 C8238	404 084 6901		50V	L7139	645 025 7797	INDUCTOR, 120 OHM
C8238	404 092 3701		63V	L7152	645 025 7797	INDUCTOR, 120 OHM
C8239	403 219 4904 403 235 5206		50V	L7154 L7156	645 025 7797	INDUCTOR, 120 OHM
C8240	404 084 3801		50V	L7162	645 025 7797	INDUCTOR, 120 OHM
C8241	403 057 0601		50V	L7163	645 036 3894	INDUCTOR, 220 OHM
C8241	403 179 3801		50V	L7164	645 036 3894 645 025 7797	INDUCTOR, 220 OHM
C8242	404 084 3207		50V 16V	L7165	645 025 7797	INDUCTOR, 120 OHM
C8243	404 084 3207		16V 16V	L8201	645 008 2221	INDUCTOR, 120 OHM
00240	404 004 3201	LLEO1 470 W	OV	L8203	645 021 1768	INDUCTOR, 2.2U K
	DIODES			L0203	645 037 1622	INDUCTOR, 6.8U J INDUCTOR, 6.8U J
D1054	407 206 5608	ZENER DIODE UDZS10B TE	-17	L8218	645 008 2221	INDUCTOR, 0.80 J
D1057	407 206 5608	ZENER DIODE UDZS10B TE		L8220	401 150 6001	MT-GLAZE 0.000 ZA 1/10W
D1211	407 206 5608	ZENER DIODE UDZS10B TE		L8221	401 150 6001	MT-GLAZE 0.000 ZA 1/10W
D1212	407 206 5608	ZENER DIODE UDZS10B TE		L8227	645 021 1607	INDUCTOR, 10U J
D1281	407 149 0807	DIODE 1SS355 TE-17	.,	LUZZI	645 032 8213	INDUCTOR, 100 J
D7100	407 149 0807	DIODE 1SS355 TE-17			040 002 0210	MDOCTOR, 100 J
D7101	407 231 8506	ZD UDZS3.0B-TE-17				
D7102	407 149 0807	DIODE 1SS355 TE-17			TRANSISTOR	s
D7103	407 149 0807	DIODE 1SS355 TE-17		Q1202	405 134 5925	TR 2SA1037AK T146 R
D8230	407 149 0807	DIODE 1SS355 TE-17			405 147 2205	TR 2SA1037AK T146 S
					405 002 0308	TR 2SA1037K-T-96-R
					405 002 0407	TR 2SA1037K-T-96-S
	INTEGRATED	CIRCUITS			405 002 6726	TR 2SA1179-M6
	409 419 5406	IC MM1313BD			405 002 6924	TR 2SA1179-M7-TB
IC1252	409 444 4722	IC NJM2534M-TE2			405 163 1503	TR 2SA1179N-M6-TB
	409 124 5708	IC L78M09T-TL			405 163 2708	TR 2SA1179N-M7-TB
	409 515 9803	IC UPD64083GF-3BA			405 173 9605	TR 2SA1235A1E
IC7102	409 437 4801	IC L88M33TL-TL			405 173 9704	TR 2SA1235A1F
					· - ·	

Schematic Location	Part No.	Description	Schemati Location	Part No.	Description
Q1223	405 134 5925	TR 2SA1037AK T146 R		405 173 9803	3 TR 2SC3928A1R
	405 147 2205	TR 2SA1037AK T146 S		405 173 9902	
	405 002 0308	TR 2SA1037K-T-96-R	Q7012	405 134 5925	
	405 002 0407	TR 2SA1037K-T-96-S	WIGIE		
	405 002 6726	TR 2SA1179-M6		405 147 2205	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	405 002 6924	TR 2SA1179-M7-TB		405 002 0308	
	405 163 1503	TR 2SA1179N-M6-TB		405 002 0407	
	405 163 2708	TR 2SA1179N-M7-TB		405 002 6726	111 =0111 113 1410
	405 173 9605			405 002 6924	TR 2SA1179-M7-TB
	405 173 9704	TR 2SA1235A1E		405 163 1503	TR 2SA1179N-M6-TB
Q1224		14	405 163 2708	TR 2SA1179N-M7-TB	
Q1224	405 134 5925			405 173 9605	
	405 147 2205	TR 2SA1037AK T146 S		405 173 9704	
	405 002 0308	TR 2SA1037K-T-96-R	Q7013	405 134 5925	
	405 002 0407	TR 2SA1037K-T-96-S	w. • · · ·	405 147 2205	
	405 002 6726	TR 2SA1179-M6			
	405 002 6924	TR 2SA1179-M7-TB		405 002 0308	TR 2SA1037K-T-96-R
	405 163 1503	TR 2SA1179N-M6-TB	•	405 002 0407	TR 2SA1037K-T-96-S
	405 163 2708	TR 2SA1179N-M7-TB		405 002 6726	TR 2SA1179-M6
	405 173 9605	TR 2SA1235A1E		405 002 6924	TR 2SA1179-M7-TB
	405 173 9704	TR 2SA1235A1F		405 163 1503	TR 2SA1179N-M6-TB
Q1232	405 014 4509			405 163 2708	TR 2SA1179N-M7-TB
	405 014 4608	TR 2SC2412K-T-96-R		405 173 9605	TR 2SA1235A1E
		TR 2SC2412K-T-96-S		405 173 9704	TR 2SA1235A1F
	405 015 8724	TR 2SC2812-L6-TB	Q7020	405 134 5925	TR 2SA1037AK T146 R
	405 015 8922	TR 2SC2812-L7-TB		405 147 2205	TR 2SA1037AK T146 S
	405 163 1602	TR 2SC2812N-L6-TB		405 002 0308	TR 2SA1037K-T-96-R
	405 163 1701	TR 2SC2812N-L7-TB		405 002 0407	TR 2SA1037K-T-96-S
	405 173 9803	TR 2SC3928A1R		405 002 6726	
	405 173 9902	TR 2SC3928A1S		405 002 6924	TR 2SA1179-M6
21233	405 014 4509	TR 2SC2412K-T-96-R		405 163 1503	TR 2SA1179-M7-TB
	405 014 4608	TR 2SC2412K-T-96-S			TR 2SA1179N-M6-TB
	405 015 8724	TR 2SC2812-L6-TB		405 163 2708	TR 2SA1179N-M7-TB
	405 015 8922	TR 2SC2812-L7-TB		405 173 9605	TR 2SA1235A1E
	405 163 1602	TR 2SC2812N-L6-TB	07004	405 173 9704	TR 2SA1235A1F
	405 163 1701	TR 2SC2812N-L7-TB	Q7021	405 014 4509	TR 2SC2412K-T-96-R
	405 173 9803	TR 2SC3928A1R		405 014 4608	TR 2SC2412K-T-96-S
	405 173 9902			405 015 8724	TR 2SC2812-L6-TB
11234	405 014 4509	TR 2SC3928A1S		405 015 8922	TR 2SC2812-L7-TB
11204	405 014 4608	TR 2SC2412K-T-96-R		405 163 1602	TR 2SC2812N-L6-TB
		TR 2SC2412K-T-96-S		405 163 1701	TR 2SC2812N-L7-TB
	405 015 8724	TR 2SC2812-L6-TB		405 173 9803	TR 2SC3928A1R
	405 015 8922	TR 2SC2812-L7-TB		405 173 9902	TR 2SC3928A1S
	405 163 1602	TR 2SC2812N-L6-TB	Q7022	405 134 5925	TR 2SA1037AK T146 R
	405 163 1701	TR 2SC2812N-L7-TB		405 147 2205	TR 2SA1037AK T146 S
	405 173 9803	TR 2SC3928A1R		405 002 0308	TD 20A1037AN 1140 5
	405 173 9902	TR 2SC3928A1S		405 002 0407	TR 2SA1037K-T-96-R
7010	405 134 5925	TR 2SA1037AK T146 R			TR 2SA1037K-T-96-S
	405 147 2205	TR 2SA1037AK T146 S		405 002 6726	TR 2SA1179-M6
	405 002 0308	TR 2SA1037K-T-96-R		405 002 6924	TR 2SA1179-M7-TB
	405 002 0407	TR 2SA1037K-T-96-S		405 163 1503	TR 2SA1179N-M6-TB
2 2 2 4	405 002 6726	TR 2SA1179-M6		405 163 2708	TR 2SA1179N-M7-TB
	405 002 6924	TR 2SA1179-M7-TB		405 173 9605	TR 2SA1235A1E
	405 163 1503			405 173 9704	TR 2SA1235A1F
	405 163 2708	TR 2SA1179N-M6-TB	Q7023	405 134 5925	TR 2SA1037AK T146 R
		TR 2SA1179N-M7-TB		405 147 2205	TR 2SA1037AK T146 S
	405 173 9605	TR 2SA1235A1E		405 002 0308	TR 2SA1037K-T-96-R
7011 4 4	405 173 9704	TR 2SA1235A1F		405 002 0407	TR 2SA1037K-T-96-S
	405 014 4509	TR 2SC2412K-T-96-R		405 002 6726	TD 0044470 440
	105 014 4608	TR 2SC2412K-T-96-S			TR 2SA1179-M6
	· · · · · · ·	TR 2SC2812-L6-TB		405 002 6924	TR 2SA1179-M7-TB
		TR 2SC2812-L7-TB		405 163 1503	TR 2SA1179N-M6-TB
		TR 2002012-L/-JD		405 163 2708	TR 2SA1179N-M7-TB
		TR 2SC2812N-L6-TB		405 173 9605	TR 2SA1235A1E
	107 102 1701	TR 2SC2812N-L7-TB		405 173 9704	TR 2SA1235A1F

Schematic Location	Part No.	Description	Schematic Location	Part No.	Description
Q7030	405 134 5925	TR 2SA1037AK T146 R	Q7100	405 134 5925	TR 2SA1037AK T146 R
	405 147 2205	TR 2SA1037AK T146 S		405 147 2205	TR 2SA1037AK T146 S
	405 002 0308	TR 2SA1037K-T-96-R		405 002 0308	TR 2SA1037K-T-96-R
	405 002 0407	TR 2SA1037K-T-96-S		405 002 0407	TR 2SA1037K-T-96-S
	405 002 6726	TR 2SA1179-M6		405 002 6726	TR 2SA1179-M6
	405 002 6924	TR 2SA1179-M7-TB		405 002 6924	TR 2SA1179-M7-TB
	405 163 1503	TR 2SA1179N-M6-TB		405 163 1503	TR 2SA1179N-M6-TB
	405 163 2708	TR 2SA1179N-M7-TB		405 163 2708	TR 2SA1179N-M7-TB
	405 173 9605	TR 2SA1235A1E		405 173 9605	TR 2SA1235A1E
	405 173 9704	TR 2SA1235A1F		405 173 9704	TR 2SA1235A1F
Q7031	405 014 4509	TR 2SC2412K-T-96-R	Q710 1	405 134 5925	TR 2SA1037AK T146 R
Q/USI	405 014 4608	TR 2SC2412K-T-96-S	Q. 101	405 147 2205	TR 2SA1037AK T146 S
	405 015 8724	TR 2SC2812-L6-TB		405 002 0308	TR 2SA1037K-T-96-R
	405 015 8922	TR 2SC2812-L7-TB		405 002 0407	TR 2SA1037K-T-96-S
	405 163 1602	TR 2SC2812N-L6-TB		405 002 6726	TR 2SA1179-M6
		TR 2SC2812N-L7-TB		405 002 6924	TR 2SA1179-M7-TB
	405 163 1701			405 163 1503	TR 2SA1179N-M6-TB
	405 173 9803	TR 2SC3928A1R		405 163 2708	TR 2SA1179N-M7-TB
07000	405 173 9902	TR 2SC3928A1S			
Q7032	405 014 4509	TR 2SC2412K-T-96-R		405 173 9605	TR 2SA1235A1E
	405 014 4608	TR 2SC2412K-T-96-S	00007	405 173 9704	TR 2SA1235A1F
	405 015 8724	TR 2SC2812-L6-TB	Q8227	405 014 4509	TR 2SC2412K-T-96-R
	405 015 8922	TR 2SC2812-L7-TB		405 014 4608	TR 2SC2412K-T-96-S
	405 163 1602	TR 2SC2812N-L6-TB		405 015 8724	TR 2SC2812-L6-TB
	405 163 1701	TR 2SC2812N-L7-TB		405 015 8922	TR 2SC2812-L7-TB
	405 173 9803	TR 2SC3928A1R		405 163 1602	TR 2SC2812N-L6-TB
	405 173 9902	TR 2SC3928A1S		405 163 1701	TR 2SC2812N-L7-TB
Q7033	405 014 4509	TR 2SC2412K-T-96-R		405 173 9803	TR 2SC3928A1R
	405 014 4608	TR 2SC2412K-T-96-S		405 173 9902	TR 2SC3928A1S
	405 015 8724	TR 2SC2812-L6-TB	Q8230	405 014 4509	TR 2SC2412K-T-96-R
	405 015 8922	TR 2SC2812-L7-TB		405 014 4608	TR 2SC2412K-T-96-S
	405 163 1602	TR 2SC2812N-L6-TB		405 015 8724	TR 2SC2812-L6-TB
	405 163 1701	TR 2SC2812N-L7-TB		405 015 8922	TR 2SC2812-L7-TB
	405 173 9803	TR 2SC3928A1R		405 163 1602	TR 2SC2812N-L6-TB
	405 173 9902	TR 2SC3928A1S		405 163 1701	TR 2SC2812N-L7-TB
Q7034	405 134 5925	TR 2SA1037AK T146 R		405 173 9803	TR 2SC3928A1R
	405 147 2205	TR 2SA1037AK T146 S		405 173 9902	TR 2SC3928A1S
	405 002 0308	TR 2SA1037K-T-96-R	Q8231	405 014 4509	TR 2SC2412K-T-96-R
	405 002 0407	TR 2SA1037K-T-96-S		405 014 4608	TR 2SC2412K-T-96-S
	405 002 6726	TR 2SA1179-M6		405 015 8724	TR 2SC2812-L6-TB
	405 002 6924	TR 2SA1179-M7-TB		405 015 8922	TR 2SC2812-L7-TB
	405 163 1503	TR 2SA1179N-M6-TB		405 163 1602	TR 2SC2812N-L6-TB
	405 163 2708	TR 2SA1179N-M7-TB		405 163 1701	TR 2SC2812N-L7-TB
	405 173 9605	TR 2SA1235A1E		405 173 9803	TR 2SC3928A1R
	405 173 9704	TR 2SA1235A1F		405 173 9902	TR 2SC3928A1S
07025		TR 2SC2412K-T-96-R	Q8232	405 134 5925	TR 2SA1037AK T146 R
Q7035	405 014 4509	TR 2SC2412K-T-96-S	Q0232	405 147 2205	TR 2SA1037AK T146 S
	405 014 4608			405 002 0308	TR 2SA1037K-T-96-R
	405 015 8724	TR 2SC2812-L6-TB		405 002 0308	TR 2SA1037K-T-96-S
	405 015 8922	TR 2SC2812-L7-TB			
	405 163 1602	TR 2SC2812N-L6-TB		405 002 6726	TR 2SA1179-M6
	405 163 1701	TR 2SC2812N-L7-TB		405 002 6924	TR 2SA1179-M7-TB
	405 173 9803	TR 2SC3928A1R		405 163 1503	TR 2SA1179N-M6-TB
	405 173 9902	TR 2SC3928A1S		405 163 2708	TR 2SA1179N-M7-TB
Q7036	405 014 4509	TR 2SC2412K-T-96-R		405 173 9605	TR 2SA1235A1E
	405 014 4608	TR 2SC2412K-T-96-S		405 173 9704	TR 2SA1235A1F
	405 015 8724	TR 2SC2812-L6-TB	Q8233	405 014 4509	TR 2SC2412K-T-96-R
	405 015 8922	TR 2SC2812-L7-TB		405 014 4608	TR 2SC2412K-T-96-S
	405 163 1602	TR 2SC2812N-L6-TB		405 015 8724	TR 2SC2812-L6-TB
	405 163 1701	TR 2SC2812N-L7-TB		405 015 8922	TR 2SC2812-L7-TB
	405 173 9803	TR 2SC3928A1R		405 163 1602	TR 2SC2812N-L6-TB
	405 173 9902	TR 2SC3928A1S		405 163 1701	TR 2SC2812N-L7-TB

Schematic	Da a Si		Schematic		<u> </u>	
Q8233 (Cont.)405 173 9803 405 173 9902		Description	Location	Part No.	De	escription
		TR 2SC3928A1R		405 173 9803		
Q8234	405 173 9902 405 014 4509	TR 2SC3928A1S TR 2SC2412K-T-06-P		405 173 9902	TR 2SC392	8A1S
WUZ04	405 014 4509 405 014 4608	TR 2SC2412K-T-96-R		PECIOTOS		
	405 014 4608	TR 2SC2412K-T-96-S	R1001	RESISTOR	BAT OLIT	May provide a second
	405 015 8724 405 015 8922	TR 2SC2812-L6-TB	R1001 R1002	401 256 2709 401 162 2909	MT-GLAZE	75 JA 1/10V
	405 015 8922	TR 2SC2812-L7-TB TR 2SC2812N-L6-TB	R1002 R1003	401 162 2909 401 162 3807	MT-GLAZE	220 JA 1/10V
	405 163 1602	TR 28C2812N-L6-1B TR 28C2812N-L7-TB	R1003	401 162 3807	MT-GLAZE	470K JA 1/10V
	405 163 1701	TR 2SC2812N-L7-1B TR 2SC3928A1R	R1004 R1005	401 162 2800 401 162 3807	MT-GLAZE	1.8K JA 1/10V
	405 173 9803	TR 2503928ATR TR 2503928ATS	R1005	401 162 3807	MT-GLAZE	470K JA 1/10\
Q8235	405 173 9902	TR 2503928ATS TR 2502412K-T-96-R	R1007	401 162 2800 401 256 2709	MT-GLAZE MT-GLAZE	1.8K JA 1/10\
	405 014 4608	TR 2SC2412K-T-96-S	R1007	401 256 2709	MT-GLAZE	75 JA 1/10\
	405 015 8724	TR 2SC2412K-1-96-5 TR 2SC2812-L6-TB	R1009	401 162 2909	MT-GLAZE	220 JA 1/10\
	405 015 8922	TR 2SC2812-L7-TB	R1010	401 162 2800	MT-GLAZE	470K JA 1/10\ 1.8K JA 1/10\
	405 163 1602	TR 2SC2812N-L6-TB	R1011	401 162 3807	MT-GLAZE	1.8K JA 1/10 470K JA 1/10
	405 163 1701	TR 2SC2812N-L7-TB	R1012	401 162 2800	MT-GLAZE MT-GLAZE	470K JA 1/10 1.8K JA 1/10
	405 173 9803	TR 2SC3928A1R	R1015	401 162 3807	MT-GLAZE	470K JA 1/10
	405 173 9902	TR 2SC3928A1S	R1016	401 162 2800	MT-GLAZE	1.8K JA 1/10
Q8236	405 014 4509	TR 2SC2412K-T-96-R	R1017	401 162 2800	MT-GLAZE	470K JA 1/101
	405 014 4608	TR 2SC2412K-T-96-S	R1018	401 162 2800	MT-GLAZE	1.8K JA 1/10\
	405 015 8724	TR 2SC2812-L6-TB	R1051	401 256 2709	MT-GLAZE	75 JA 1/10\
	405 015 8922	TR 2SC2812-L7-TB	R1052	401 162 2909	MT-GLAZE	220 JA 1/10\
	405 163 1602	TR 2SC2812N-L6-TB	R1056	401 256 2709	MT-GLAZE	75 JA 1/10\
	405 163 1701	TR 2SC2812N-L7-TB	R1057	401 162 2909	MT-GLAZE	220 JA 1/10\
	405 173 9803	TR 2SC3928A1R	R1058	401 162 3005	MT-GLAZE	22K JA 1/10V
	405 173 9902	TR 2SC3928A1S	R1059	401 150 6209	MT-GLAZE	1K JA 1/10V
Q8237	405 134 5925	TR 2SA1037AK T146 R	R1060	401 256 2709	MT-GLAZE	75 JA 1/10V
	405 147 2205	TR 2SA1037AK T146 S	R1061	401 162 2909	MT-GLAZE	220 JA 1/10V
	405 002 0308	TR 2SA1037K-T-96-R	R1062	401 256 2709	MT-GLAZE	75 JA 1/10V
	405 002 0407	TR 2SA1037K-T-96-S	R1063	401 162 2909	MT-GLAZE	220 JA 1/10V
	405 002 6726	TR 2SA1179-M6	R1064	401 162 3005	MT-GLAZE	22K JA 1/10V
	405 002 6924	TR 2SA1179-M7-TB	R1065	401 150 6209	MT-GLAZE	1K JA 1/10V
	405 163 1503	TR 2SA1179N-M6-TB	R1202	401 256 4109	MT-GLAZE	56 JA 1/10V
	405 163 2708	TR 2SA1179N-M7-TB	R1203	401 256 4109	MT-GLAZE	56 JA 1/10V
	405 173 9605	TR 2SA1235A1E	R1204	401 256 4109	MT-GLAZE	56 JA 1/10V
ეგევი	405 173 9704	TR 2SA1235A1F	R1205	401 256 4109	MT-GLAZE	56 JA 1/10V
Q8238	405 134 5925	TR 2SA1037AK T146 R	R1206	401 150 6100	MT-GLAZE	2.2K JA 1/10V
	405 147 2205	TR 2SA1037AK T146 S	R1207	401 150 6100	MT-GLAZE	2.2K JA 1/10W
	405 002 0308 405 002 0407	TR 2SA1037K-T-96-R	R1209	401 150 6209	MT-GLAZE	1K JA 1/10W
	405 002 0407 405 002 6726	TR 2SA1037K-T-96-S	R1214 R1215	401 255 6500	MT-GLAZE	100 JA 1/10W
	405 002 6726 405 002 6924	TR 2SA1179-M6 TR 2SA1179-M7-TR	R1215 R1216	401 255 6500 401 255 6500	MT-GLAZE	100 JA 1/10W
	405 002 6924 405 163 1503	TR 2SA1179-M7-TB	R1216 R1217	401 255 6500 401 255 6500	MT-GLAZE	100 JA 1/10W
	405 163 1503 405 163 2708	TR 2SA1179N-M6-TB TR 2SA1179N-M7-TB	R1217 R1219	401 255 6500 401 256 4100	MT-GLAZE	100 JA 1/10W
	405 163 2708	TR 2SA11/9N-M/-1B TR 2SA1235A1E	R1219	401 256 4109 401 256 4109	MT-GLAZE	56 JA 1/10W
	405 173 9605	TR 2SA1235A1E TR 2SA1235A1F	R1220 R1221	401 256 4109 401 150 6209	MT-GLAZE	56 JA 1/10W
Q8239	405 014 4509	TR 2SC2412K-T-96-R	R1222	401 150 6209 401 150 6209	MT-GLAZE	1K JA 1/10W
	405 014 4608	TR 2SC2412K-T-96-R TR 2SC2412K-T-96-S	R1222 R1223	401 150 6209 401 150 6209	MT-GLAZE	1K JA 1/10W
	405 015 8724	TR 2SC2812-L6-TB	R1223 R1224	401 150 6209 401 150 6209	MT-GLAZE	1K JA 1/10W
	405 015 8922	TR 2SC2812-L6-1B TR 2SC2812-L7-TB	R1224 R1228	401 150 6209	MT-GLAZE	1K JA 1/10W
	405 163 1602	TR 2SC2812N-L6-TB	R1229	401 256 4109	MT-GLAZE	56 JA 1/10W
	405 163 1701	TR 2SC2812N-L7-TB	R1229 R1239	401 256 4109	MT-GLAZE MT-GLAZE	56 JA 1/10W
	405 173 9803	TR 2SC3928A1R	R1239 R1240	401 256 4109 401 150 5905	MT-GLAZE MT-GLAZE	56 JA 1/10W
	405 173 9803	TR 2SC3928A1R TR 2SC3928A1S	R1240 R1241	401 150 5905 401 150 6209	MT-GLAZE MT-GLAZE	10K JA 1/10W
	405 173 9902 405 014 4509	TR 2SC3928ATS TR 2SC2412K-T-96-R	R1241 R1242		MT-GLAZE	1K JA 1/10W
	405 014 4509			401 256 4109 401 150 6209	MT-GLAZE	56 JA 1/10W
	405 014 4608	TR 2SC2412K-T-96-S TR 2SC2812-L6-TR	R1243 R1244	401 150 6209	MT-GLAZE	1K JA 1/10W
		TR 2SC2812-L6-TB	R1244	401 256 4109	MT-GLAZE	56 JA 1/10W
	405 015 8922 405 163 1602	TR 2SC2812-L7-TB	R1245	401 256 4109	MT-GLAZE	56 JA 1/10W
	405 163 1602	TR 2SC2812N-L6-TB	R1246	401 150 6209	MT-GLAZE	1K JA 1/10W
•	405 163 1701	TR 2SC2812N-L7-TB	R1247	401 256 4109	MT-GLAZE	56 JA 1/10W

Cala and all				Schematic			
Schematic Location	Part No.	Des	scription	Location	Part No.	De	scription
R7010	401 150 6209	MT-GLAZE	1K JA 1/10W	R8215	401 256 4109	MT-GLAZE	56 JA 1/10W
R7011	401 162 3708	MT-GLAZE	4.7K JA 1/10W	R8216	401 256 4109	MT-GLAZE	56 JA 1/10W
R7012	401 162 4002	MT-GLAZE	560 JA 1/10W	R8217	401 256 4109	MT-GLAZE	56 JA 1/10W
R7013	401 162 4101	MT-GLAZE	5.6K JA 1/10W	R8227	401 150 6209	MT-GLAZE	1K JA 1/10W
R7014	401 150 6209	MT-GLAZE	1K JA 1/10W	R8228	401 162 3005	MT-GLAZE	22K JA 1/10W
R7015	401 162 2909	MT-GLAZE	220 JA 1/10W	R8229	401 162 3005	MT-GLAZE	22K JA 1/10W
R7016	401 256 0002	MT-GLAZE	120 JA 1/10W	R8230	401 162 3807	MT-GLAZE	470K JA 1/10W
R7017	401 162 3609	MT-GLAZE	470 JA 1/10W	R8231	401 255 6005	MT-GLAZE	1M JA 1/10W
R7018	401 256 5601	MT-GLAZE	47 JA 1/10W	R8232	401 150 6100	MT-GLAZE	2.2K JA 1/10W
R7019	401 150 6209	MT-GLAZE	1K JA 1/10W	R8233	401 150 6100	MT-GLAZE	2.2K JA 1/10W
R7020	401 150 6209	MT-GLAZE	1K JA 1/10W	R8234	401 256 3607	MT-GLAZE	15K JA 1/10W
R7021	401 162 3708	MT-GLAZE	4.7K JA 1/10W	R8235	401 256 7308	MT-GLAZE	6.8K JA 1/10W
R7022	401 162 4002	MT-GLAZE	560 JA 1/10W	R8236 R8237	401 150 5905 401 150 6209	MT-GLAZE MT-GLAZE	10K JA 1/10W 1K JA 1/10W
R7023	401 162 4101	MT-GLAZE	5.6K JA 1/10W	R8238	401 150 5905	MT-GLAZE	10K JA 1/10W
R7024	401 162 2909 401 150 6209	MT-GLAZE MT-GLAZE	220 JA 1/10W 1K JA 1/10W	R8239	401 256 3508	MT-GLAZE	150K JA 1/10W
R7025 R7026		MT-GLAZE	470 JA 1/10W	R8240	401 162 4002	MT-GLAZE	560 JA 1/10W
R7026 R7027	401 162 3609 401 162 2909	MT-GLAZE	220 JA 1/10W	R8241	401 162 3104	MT-GLAZE	3.3K JA 1/10W
R7027	401 102 2909	MT-GLAZE	47 JA 1/10W	R8242	401 150 6209	MT-GLAZE	1K JA 1/10W
R7020	401 150 6209	MT-GLAZE	1K JA 1/10W	R8243	401 256 7605	MT-GLAZE	3.9K JA 1/10W
R7030	401 256 2907	MT-GLAZE	150 JA 1/10W	R8244	401 162 4002	MT-GLAZE	560 JA 1/10W
R7031	401 150 6100	MT-GLAZE	2.2K JA 1/10W	R8245	401 162 4002	MT-GLAZE	560 JA 1/10W
R7032	401 256 6905	MT-GLAZE	680 JA 1/10W	R8246	401 256 7605	MT-GLAZE	3.9K JA 1/10W
R7033	401 256 0309	MT-GLAZE	820 JA 1/10W	R8247	401 150 5905	MT-GLAZE	10K JA 1/10W
R7034	401 150 6100	MT-GLAZE	2.2K JA 1/10W	R8248	401 150 5806	MT-GLAZE	100K JA 1/10W
R7035	401 256 4109	MT-GLAZE	56 JA 1/10W	R8249	401 162 3104	MT-GLAZE	3.3K JA 1/10W
R7036	401 256 7803	MT-GLAZE	390K JA 1/10W				
R7037	401 162 4101	MT-GLAZE	5.6K JA 1/10W		MISCELLAN		
R7038	401 162 3104	MT-GLAZE	3.3K JA 1/10W	A1201	610 310 1781		AV -H3ABM
R7039	401 162 2909	MT-GLAZE	220 JA 1/10W	K1001	645 057 1725	TERMINAL,	
R7040	401 255 9501	MT-GLAZE	220K JA 1/10W	K1051	645 041 1847	SOCKET, DII	
R7041	401 256 6301	MT-GLAZE	47K JA 1/10W	T7010	645 028 2454	FILTER, LP (
R7042	401 150 6100	MT-GLAZE	2.2K JA 1/10W	T7020	645 028 2454	FILTER, LP (FILTER, LP (
R7043	401 162 3609	MT-GLAZE	470 JA 1/10W	T7030 X7100	645 028 2447 610 221 3126	CRYSTAL O	
R7044	401 150 6209	MT-GLAZE	1K JA 1/10W	X8201	645 024 8788		AL 3.579545MHZ
R7045	401 162 3708	MT-GLAZE	4.7K JA 1/10W	X8202	610 012 0532		/IC 500.0KHZ
R7046	401 255 6500	MT-GLAZE	100 JA 1/10W 2.2K JA 1/10W	X8230	645 006 3459		AIC 500.0KHZ
R7047	401 150 6100	MT-GLAZE MT-GLAZE	180 JA 1/10W	7,0200	010 000 0100	000, 02	
R7048 R7100	401 162 2701 401 256 0002	MT-GLAZE	120 JA 1/10W				
R7101	401 162 2909	MT-GLAZE	220 JA 1/10W		VIDEO PC	BOARD	
R7102	401 162 3609	MT-GLAZE	470 JA 1/10W				
R7103	401 150 6209	MT-GLAZE	1K JA 1/10W		CAPACITORS		
R7106	401 162 3708	MT-GLAZE	4.7K JA 1/10W	C2301	404 084 2705	ELECT	10U M 16V
R7107	401 255 6500	MT-GLAZE	100 JA 1/10W	C2302	403 279 0106	CERAMIC	0.1U Z 25V
R7108	401 255 6500	MT-GLAZE	100 JA 1/10W	C2313	404 084 2903	ELECT	1000U M 16V
R7111	401 162 3401	MT-GLAZE	39K JA 1/10W	C2314	404 084 2903	ELECT CERAMIC	1000U M 16V 0.1U Z 25V
R7112	401 162 3708	MT-GLAZE	4.7K JA 1/10W	C2315	403 279 0106	CERAMIC	0.1U Z 25V 0.1U Z 25V
R7113	401 162 3401	MT-GLAZE	39K JA 1/10W	C2316 C2317	403 279 0106 404 085 5002	ELECT	47U M 25V
R8201	401 256 5304	MT-GLAZE	56K JA 1/10W	C2317	404 085 4203	ELECT	100U M 10V
R8202	401 162 2800	MT-GLAZE	1.8K JA 1/10W	C2319	403 279 0106	CERAMIC	0.1U Z 25V
R8203	401 152 3206	MT-GLAZE	330 JA 1/10W	C2319	403 279 0106	CERAMIC	0.1U Z 25V
R8205	401 255 6500	MT-GLAZE	100 JA 1/10W	C2321	404 084 2507	ELECT	47U M 10V
R8206	401 162 2909	MT-GLAZE	220 JA 1/10W	C2323	404 092 9208	ELECT	1000U M 6.3V
R8208	401 255 6500	MT-GLAZE	100 JA 1/10W	C2324	404 092 9208	ELECT	1000U M 6.3V
R8209	401 255 6500	MT-GLAZE	100 JA 1/10W	C2325	403 224 5705	CERAMIC	1000P K 50V
R8210	401 256 1405	MT-GLAZE	330K JA 1/10W	C2327	401 150 6001	MT-GLAZE	0.000 ZA 1/10W
R8211	401 152 3206	MT-GLAZE	330 JA 1/10W	C2328	404 084 3306	ELECT	470U M 16V
R8212	401 256 0101	MT-GLAZE	8.2K JA 1/10W	C2329	403 279 0106	CERAMIC	0.1U Z 25V
R8213	401 264 1909	MT-GLAZE	10K FA 1/10W				

Schematic Location	Part No.	De	scription		Schematic	Part No.	Description		
	404.004.000	<u>l</u>			Location		Description		
C2330 C2331	404 084 2903	ELECT	1000U M		C2545	404 087 1200	ELECT 0.1U M 50V		
C2331	404 084 2705	ELECT ELECT	10U M		C2613	404 084 2804	ELECT 100U M 16V		
C2333	404 084 3801		1U M			DIODEO			
02000	403 056 7304 403 178 9200	POLYESTER			D2301	DIODES	DIODE ODOM ANA TO		
C2334	403 224 6108	POLYESTER			D2301 D2302	407 092 9526	DIODE SB07-03C-TB		
C2336	403 235 0409	CERAMIC CERAMIC	0.01U K 68P J		D2302 D2303	407 149 0807 407 149 0807	DIODE 188355 TE-17		
C2339	404 084 3108	ELECT	330U M		D2303 D2320	407 149 0807	DIODE 188355 TE-17		
C2341	404 085 5002	ELECT	47U M		D2321	407 149 0807	DIODE 1SS355 TE-17 DIODE 1SS355 TE-17		
C2342	403 354 2803	POLYPRO	0.1U J	50V	D2330	407 092 9526	DIODE 188355 TE-17		
C2343	404 084 5508	MT-POLYES		63V	D2342	407 092 9526	DIODE SB07-03C-TB		
	403 237 8007	MT-COMPO		50V	D2343	407 149 0807	DIODE 1SS355 TE-17		
C2344	404 084 5508	MT-POLYES		63V	D2501	407 206 5608	ZENER DIODE UDZS10B TE-17		
	403 237 8007	MT-COMPO	0.1U J	50V	D2502	407 206 5608	ZENER DIODE UDZS10B TE-17		
C2345	403 279 0106	CERAMIC	0.1U Z	25V	D2503	407 206 5608	ZENER DIODE UDZS10B TE-17		
C2346	404 084 3306	ELECT	470U M	16V	D2510	407 149 0807	DIODE 1SS355 TE-17		
C2372	404 084 3207	ELECT	47U M	16V	D2511	407 149 0807	DIODE 1SS355 TE-17		
C2373	403 279 0106	CERAMIC	0.1U Z	25V					
★ C2380	404 084 3801	ELECT	1U M	50V		INTEGRATED	CIRCUITS		
C2500	404 091 6604	ELECT	4.7U M	25V	IC2301	409 476 8600	IC NJM319M-TE2		
C2501	403 279 0106	CERAMIC	0.1U Z	25V	IC2303	409 124 5708	IC L78M09T-TL		
C2502	404 084 2705	ELECT	10U M	16V	IC2304	409 398 1901	IC L88MS05TL-TL		
C2503	403 234 9007	CERAMIC	5P C	50V	★ IC2501	409 555 0709	IC CXA2180Q		
C2503B	403 234 9007	CERAMIC	5P C	50V	IC2502	409 528 6202	IC PQ050ES1MXP		
C2503R	403 234 9007	CERAMIC	5P C	50V		0011.0			
C2505	403 279 0106	CERAMIC	0.1U Z	25V	L2301	COILS	INDUSTOR A CULT		
C2506	404 084 2804	ELECT	100U M	16V	L2301	645 040 3101 645 026 1008	INDUCTOR, 3.3U M		
C2507	403 279 0106	CERAMIC	0.1U Z	25V	L2340	645 008 2276	INDUCTOR, 3.3U M INDUCTOR, 22U K		
C2508 C2509	403 279 0106	CERAMIC	0.1U Z	25V	L2341	645 008 2009	INDUCTOR, 220 K INDUCTOR, 100 K		
C2509 C2510	403 279 0106	CERAMIC	0.1U Z	25V	L2501	645 008 2009	INDUCTOR, 100 K		
02310	403 063 2309 403 179 0107	POLYESTER		50V	L2517	645 008 2009	INDUCTOR, 100 K		
	403 312 3002	POLYESTER		50V	L2520	645 008 2009	INDUCTOR, 100 K		
C2511	403 224 5606	POLYESTER CERAMIC		50V		3.0 003 2000	110001011, 100 K		
C2512	403 235 0607	CERAMIC	2700P K 100P J	50V 50V		TRANSISTOR	S		
C2513	404 084 3207	ELECT	47U M	16V	★ Q2320	405 014 4509	TR 2SC2412K-T-96-R		
C2515	404 084 2705	ELECT	10U M	16V		405 014 4608	TR 2SC2412K-T-96-S		
C2521	403 279 0106	CERAMIC	0.1U Z	25V		405 015 8724	TR 2SC2812-L6-TB		
C2522	403 279 0106	CERAMIC	0.1U Z	25V 25V		405 015 8922	TR 2SC2812-L7-TB		
C2523	403 279 0106	CERAMIC	0.1U Z	25V		405 163 1602	TR 2SC2812N-L6-TB		
C2524	403 279 0106	CERAMIC	0.1U Z	25V		405 163 1701	TR 2SC2812N-L7-TB		
C2525	403 279 0106	CERAMIC	0.1U Z	25V		405 173 9803	TR 2SC3928A1R		
C2526	403 279 0106	CERAMIC	0.1U Z	25V		405 173 9902	TR 2SC3928A1S		
C2527	403 325 4706		0.047U K	25V	Q2330	405 014 4509	TR 2SC2412K-T-96-R		
C2530	404 084 5706	MT-POLYEST		63V		405 014 4608	TR 2SC2412K-T-96-S		
	403 256 0808	MT-COMPO	0.47U J	50V		405 015 8724	TR 2SC2812-L6-TB		
C2531	404 084 4006	ELECT	2.2U M	50V		405 015 8922	TR 2SC2812-L7-TB		
C2532	403 279 0106	CERAMIC	0.1U Z	25V		405 163 1602	TR 2SC2812N-L6-TB		
C2533	404 092 9208		1000U M	6.3V		405 163 1701	TR 2SC2812N-L7-TB		
C2534	404 084 5508	MT-POLYEST	0.1UJ	63V		405 173 9803 405 173 9902	TR 2SC3928A1R		
0000	403 237 8007	MT-COMPO	0.1U J	50V		405 014 4509	TR 2SC3928A1S TR 2SC2412K-T-96-R		
C2535	404 084 5508	MT-POLYEST	0.1UJ	63V		405 014 4608	TR 2SC2412K-T-96-S		
COEOC	403 237 8007	MT-COMPO	0.1U J	50V		405 015 8724	TR 2SC2812-L6-TB		
C2536	404 084 5508	MT-POLYEST	0.1UJ	63V		405 015 8922	TR 2SC2812-L7-TB		
00597	403 237 8007	MT-COMPO	0.1U J	50V		405 163 1602	TR 2SC2812N-L6-TB		
C2537	403 279 0106	CERAMIC	0.1U Z	25V		405 163 1701	TR 2SC2812N-L7-TB		
C2538	403 279 0106	CERAMIC	0.1U Z	25V		405 173 9803	TR 2SC3928A1R		
C2539	403 279 0106	CERAMIC	0.1U Z	25V		405 173 9902	TR 2SC3928A1S		
C2543 C2544	404 087 1200	ELECT	0.1U M	50V			5500025/110		
U4U 11	404 087 1200	ELECT	0.1U M	50V					


02333 405 134 5925 178 2SA1037AK T146 R	Schematic Location	Part No.	Description	Schematic Location	Part No.	Description
495 147 2205	02333	405 134 5925	TR 2SA1037AK T146 R		ADS 014 AS00	TD 2902412K T 06 D
## 405 002 00308 ## R 25A1037K-T-96-R ## 405 013 8022 ## 78 25C812-L6-TB ## 405 002 6024 ## 78 25A1179-MAT-TB ## 405 103 602 6024 ## 78 25A1179-MAT-TB ## 405 103 103 27 R 25C812K-L6-TB ## 405 103 1603 ## 78 25A1179-MAT-TB ## 405 103 103 27 R 25C812K-L6-TB ## 405 103 1603 ## 78 25A1179-MAT-TB ## 405 103 103 TR 25A1179-MAT-TB ## 405 103 103 TR 25A1179-MAT-TB ## 405 103 103 TR 25A1179-MAT-TB ## 405 103 203 TR 25C812K-L6-TB ## 25A1037K-T 104 R ## 405 103 203 TR 25C812K-L6-TB ## 405 103 203 TR 25A1037K-T-96-R ## 405 103 203 TR 25A1037K	Q2000			Q2500		
405 002 0407						
## 405 002 6726 ## 178 25A1179-M/F ## 405 163 1670 ## 25C2612A11-0-TB ## 405 163 1670 ## 25A1179-M-FB ## 405 163 173 9803 ## 25SA125A11 ## 405 163 1670 ## 25A1179-M-FB ## 405 173 9803 ## 25SA125A11 ## 405 173 9805 ## 25A125A11 ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 405 173 9805 ## 25A1037AK 1146 R ## 25A						
405 002 6924 TR 25A1179-M7-TB						
405 183 1803 TR 25A1179H-M6-TB 405 173 9803 TR 25A1293A1 TR 25A1293A1 405 173 9805 TR 25A1293A1 405 173 9805 TR 25A1235A1 405 173 9805 TR 25A1037AT 1146 R 405 102 0308 TR 25A1037AT 1146 R 405 102 0308 TR 25A1037AT 1146 R 405 102 0308 TR 25A1037AT 1146 R 405 102 0407 TR 25A1037AT 1146 R 405 103 102 052 0407 TR 25A1037AT 1146 R 405 103 102 052 0407 TR 25A1037AT 1146 R 405 103 103 103 TR 25A1179H-M7-TB 405 103 2708 TR 25A1235A1F TR 25A1235A1						
405 162 2708						
405 173 9905						
Q5501		405 173 9605	TR 2SA1235A1E	Q2513		
405 102 20407 TR 2SA1037AK T146 S 405 002 0407 TR 2SA1037K-T-96-S 405 002 0407 TR 2SA1037K-T-96-S 405 002 05726 TR 2SA1179-M6 405 103 1000 26924 TR 2SA1179-M7-TB 405 002 05924 TR 2SA1179-M7-TB 405 163 2708 TR 2SA1179-M7-TB 405 163 1503 TR 2SA1179-M7-TB 405 163 1503 TR 2SA1179-M7-TB 405 163 2708 TR 2SA1179-M7-TB 405 173 9605 TR 2SA125SA1E 405 173 9605 TR 2SA125SA1E 405 173 9605 TR 2SA125SA1F 405 173 9605 TR 2SA1037AK T146 R R2002 401 255 6500 MT-GLAZE 8.2K JA 170W 405 002 0407 TR 2SA1037AK T146 R R2002 401 256 0101 MT-GLAZE 8.2K JA 170W 405 002 0407 TR 2SA1037AK T146 R R2002 401 256 0101 MT-GLAZE 8.2K JA 170W 405 002 6924 TR 2SA1037AK T146 R R2003 401 150 6209 MT-GLAZE 1K JA 170W 405 002 6924 TR 2SA1037AK T146 R R2004 401 150 6209 MT-GLAZE 8.2K JA 170W 405 002 6924 TR 2SA1037AK T146 R R2004 401 256 0101 MT-GLAZE 8.2K JA 170W 405 002 6924 TR 2SA1079-M6-TB R2004 401 255 6500 MT-GLAZE 1K JA 170W 405 103 173 9605 TR 2SA125SA1F 405 173 9605 TR 2SA1037AK T146 R R2114 401 255 6500 MT-GLAZE 100 JA 170W 405 173 9704 TR 2SA1037AK T146 R R2114 401 255 6500 MT-GLAZE 100 JA 170W 405 173 9704 TR 2SA1037AK T146 R R2114 401 255 6500 MT-GLAZE 100 JA 170W 405 173 9704 TR 2SA1037AK T146 R R2114 401 255 6500 MT-GLAZE 100 JA 170W 405 173 9704 TR 2SA1037AK T146 R R2114 401 255 6500 MT-GLAZE 100 JA 170W 405 173 9704 TR 2SA1037AK T146 R R2114 401 255 6500 MT-GLAZE 100 JA 170W 405 173 9704 TR 2SA1037AK T146 R R2114 401 255 6500 MT-GLAZE 100 JA 170W 405 173 9704 TR 2SA1037AK T146 R R2114 401 255 6500 MT-GLAZE 100 JA 170W 405 173 9704 TR 2SA1037AK T146 R R2114 401 255 6500 MT-GLAZE 100 JA 170W 405 173 9704 TR 2SA1037AK T146 R R2114 401 255 6500 MT-GLAZE 10		405 173 9704	TR 2SA1235A1F			
405 002 0308	Q2501	405 134 5925	TR 2SA1037AK T146 R		405 002 0308	TR 2SA1037K-T-96-R
405 002 0407			TR 2SA1037AK T146 S		405 002 0407	TR 2SA1037K-T-96-S
405 002 6726		405 002 0308			405 002 6726	TR 2SA1179-M6
405 002 6824 TR 2SA1179-M7-TB					405 002 6924	TR 2SA1179-M7-TB
405 163 1603					405 163 1503	TR 2SA1179N-M6-TB
405 173 9704 TR ZSA1179N-M7-TB 405 173 9704 TR ZSA123SA1F						TR 2SA1179N-M7-TB
Q5502 405 134 5925 TR 2SA123SA1E RESISTORS 405 134 5925 TR 2SA1037AK T146 R R2301 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2303 401 150 6209 MT-GLAZE 1K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2303 401 150 6209 MT-GLAZE 1K JA 1/10W 405 002 6726 TR 2SA1179-M6 R2305 401 256 6101 MT-GLAZE 8.2K JA 1/10W 405 002 6726 TR 2SA1179-M6-TB R2306 401 256 6101 MT-GLAZE 8.2K JA 1/10W 405 102 6924 TR 2SA1179-M6-TB R2309 401 291 7608 MT-GLAZE 8.2K JA 1/10W 405 103 2708 TR 2SA1179N-M6-TB R2309 401 291 7608 MT-GLAZE 8.2K JA 1/10W 405 103 2708 TR 2SA1179N-M6-TB R2309 401 291 7608 MT-GLAZE 8.2K JA 1/10W 405 173 9605 TR 2SA123SA1E R2312 401 255 6500 MT-GLAZE 100 JA 1/10W 405 173 9704 TR 2SA123SA1E R2312 401 255 6500 MT-GLAZE 100 JA 1/10W 405 173 9704 TR 2SA123SA1F R2313 401 255 6500 MT-GLAZE 100 JA 1/10W 405 102 020 020 TR 2SA1037K-T-96-R R2314 401 255 6500 MT-GLAZE 100 JA 1/10W 405 102 020 020 TR 2SA1037K-T-96-R R2315 401 256 6500 MT-GLAZE 100 JA 1/10W 405 002 030 TR 2SA1037K-T-96-R R2317 401 256 6500 MT-GLAZE 100 JA 1/10W 405 002 030 TR 2SA1037K-T-96-R R2317 401 256 6500 MT-GLAZE 100 JA 1/10W 405 002 030 TR 2SA1037K-T-96-R R2317 401 256 6500 MT-GLAZE 400 JA 1/10W 405 103 2708 TR 2SA1037K-T-96-R R2317 401 256 6500 MT-GLAZE 400 JA 1/10W 405 103 2708 TR 2SA1037K-T-96-R R2324 401 256 6500 MT-GLAZE 400 JA 1/10W 405 103 2708 TR 2SA1037K-T-96-R R2324 401 256 6500 MT-GLAZE 400 JA 1/10W 405 103 2708 TR 2SA1037K-T-96-R R2322 401 256 6500 MT-GLAZE 400 JA 1/10W 405 103 2708 TR 2SA1037K-T-96-R R2322 401 150 6600 MT-GLAZE 400 JA 1/10W 405 103 2708 TR 2SA1037K-T-96-R R2324 401 150 6600 MT-GLAZE 400 JA 1/10W 405 103 3904 TR 2SA1037K-T-96-R R2322 401 150 6600 MT-GLAZE 400 JA 1/10W 405 103 3904 TR 2SA1037K-T-96-R R2324 401 150 6600						
Q2502					405 173 9704	TR 2SA1235A1F
Q2502					DECICTORS	
405 147 2205	00500			D0304		MT 01 575 400 15 4/4014
405 002 0308	Q2502		·			
405 002 0407						
405 002 6726						
405 002 6924 TR 2SA1179-M7-TB R2306 401 256 6101 MT-GLAZE 8.2K JA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2309 401 291 7608 MT-GLAZE 10 FA 1/2W 405 163 2708 TR 2SA1179N-M7-TB R2310 401 255 6500 MT-GLAZE 100 JA 1/10W 405 173 9605 TR 2SA123SA1F R2312 401 255 6500 MT-GLAZE 100 JA 1/10W 405 173 9704 TR 2SA123SA1F R2313 401 255 6500 MT-GLAZE 100 JA 1/10W 405 147 2205 TR 2SA1037AK T146 R R2314 401 255 6500 MT-GLAZE 100 JA 1/10W 405 102 0308 TR 2SA1037AK T146 S R2315 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2317 401 256 6004 MT-GLAZE 100 JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2318 401 256 6004 MT-GLAZE 27K JA 1/10W 405 002 6924 TR 2SA1179-M6 R2319 401 162 3609 MT-GLAZE 27K JA 1/10W 405 163 1503 TR 2SA1179-M-TB R2320 401 162 3609 MT-GLAZE 401 A1/10W 405 163 1503 TR 2SA1179-M-6TB R2321 401 256 6001 MT-GLAZE 401 A1/10W 405 163 2708 TR 2SA1179-M-6TB R2322 401 150 6001 MT-GLAZE 400 JA 1/10W 405 163 2708 TR 2SA123SA1F R2323 403 343 4603 CERAMIC 0.000 ZA 1/10W 405 173 9704 TR 2SA123SA1F R2323 403 343 4603 CERAMIC 0.000 ZA 1/10W 405 173 9704 TR 2SA123SA1F R2324 401 256 5909 MT-GLAZE 27K JA 1/10W 405 102 0407 TR 2SA1037K-T-96-R R2327 401 150 5905 MT-GLAZE 27K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2327 401 150 5906 MT-GLAZE 27K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2327 401 150 5906 MT-GLAZE 27K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2327 401 150 5906 MT-GLAZE 27K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2327 401 150 5905 MT-GLAZE 27K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2328 401 162 3005 MT-GLAZE 27K JA 1/10W 405 002 0407 TR 2SA1179-M7-TB R2331 401 256 6908 MT-GLAZE 27K JA 1/10W 405 103 300 TR 2SA1179-M7-TB R2331 401 256 6908 MT-GLAZE 27K JA 1/10W 405 103 300 TR 2SA1179-M7-TB R2331 401 256 69						
405 163 1503						
405 163 2708 TR 2SA1179N-M7-TB R2310 401 255 6500 MT-GLAZE 100 JA 1/10W 405 173 9905 TR 2SA123SA1E R2313 401 255 6500 MT-GLAZE 100 JA 1/10W 405 173 9904 TR 2SA123SA1F R2313 401 255 6500 MT-GLAZE 100 JA 1/10W 405 134 5925 TR 2SA1037AK T146 R R2314 401 255 6500 MT-GLAZE 100 JA 1/10W 405 147 2205 TR 2SA1037AK T146 S R2315 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2317 401 256 6500 MT-GLAZE 100 JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2318 401 256 6004 MT-GLAZE 27K JA 1/10W 405 002 6924 TR 2SA1179-M6 R2319 401 256 6004 MT-GLAZE 27K JA 1/10W 405 002 6924 TR 2SA1179-M6-TB R2320 401 162 3609 MT-GLAZE 470 JA 1/10W 405 163 1503 TR 2SA1179N-M7-TB R2322 401 150 6001 MT-GLAZE 470 JA 1/10W 405 163 2708 TR 2SA125A1E R2323 403 343 4603 CERAMIC 0.0022 IX 50V 405 173 9704 TR 2SA1235A1F R2324 401 256 5809 MT-GLAZE 27K JA 1/10W 405 107 39704 TR 2SA1235A1F R2324 401 256 5809 MT-GLAZE 27K JA 1/10W 405 107 39704 TR 2SA1037K-T-96-R R2325 401 150 5805 MT-GLAZE 27K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2325 401 150 5805 MT-GLAZE 10K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2326 401 150 5806 MT-GLAZE 10K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2326 401 150 5806 MT-GLAZE 10K JA 1/10W 405 002 6924 TR 2SA1179N-M7-TB R2330 401 126 708 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1179N-M7-TB R2330 401 126 6608 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1179N-M7-TB R2333 401 126 6608 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1137N-M7-TB R2333 401 126 6608 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1137N-M7-TB R2333 401 126 6008 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1179N-M7-TB R2333 401 126 6000 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1137N-M7-TB R2334 401 162 4101 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R						
405 173 9605 TR 2SA1235A1E R2312 401 255 6500 MT-GLAZE 100 JA 1/10W						
Q2503 Q250						
Q2503						
405 147 2205	Q2503					
405 002 0308						
405 002 6726		405 002 0308		R2317	401 264 1909	
405 002 6924 TR 2SA1179-M7-TB R2320 401 162 3609 MT-GLAZE 470 JA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2321 401 255 6500 MT-GLAZE 100 JA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2322 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2323 403 343 4603 CERAMIC 0.022 U K 50V 405 173 9704 TR 2SA1235A1F R2324 401 256 5809 MT-GLAZE 270K JA 1/10W 405 147 2205 TR 2SA1037AK T146 R R2325 401 150 5905 MT-GLAZE 33K JA 1/10W 405 147 2205 TR 2SA1037AK T146 S R2326 401 150 5905 MT-GLAZE 33K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2327 401 150 5806 MT-GLAZE 33K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2328 401 150 5806 MT-GLAZE 100K JA 1/10W 405 002 6924 TR 2SA1179-M6 R2329 401 256 7308 MT-GLAZE 4.7K JA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2330 401 256 7308 MT-GLAZE 6.8K JA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2331 401 150 5806 MT-GLAZE 22K JA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2332 401 162 3005 MT-GLAZE 22K JA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2332 401 162 3005 MT-GLAZE 22K JA 1/10W 405 173 9605 TR 2SA1235A1F R2334 401 162 4101 MT-GLAZE 2.7K JA 1/10W 405 147 2205 TR 2SA137AK T146 R R2335 401 256 6908 MT-GLAZE 2.7K JA 1/10W 405 147 2205 TR 2SA1037AK T146 R R2337 401 162 3005 MT-GLAZE 5.6K JA 1/10W 405 147 2205 TR 2SA1037AK T146 R R2337 401 162 3005 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037AK T146 R R2337 401 162 3708 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037AK T146 R R2337 401 162 3708 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037AK T146 R R2337 401 162 3708 MT-GLAZE 5.6K JA 1/10W 405 147 2205 TR 2SA1037AK T146 R R2337 401 162 3708 MT-GLAZE 0.000 ZA 1/10W 405 002 0407 TR 2SA1037AK T146 R R2337 401 162 3708 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M6-TB R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 16		405 002 0407	TR 2SA1037K-T-96-S		401 256 6004	MT-GLAZE 27K JA 1/10W
405 163 1503 TR 2SA1179N-M6-TB R2321 401 255 6500 MT-GLAZE 100 JA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2322 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2323 403 343 4603 CERAMIC 0.022U K 50V 405 173 9704 TR 2SA1235A1F R2324 401 256 5809 MT-GLAZE 270K JA 1/10W 405 173 9704 TR 2SA1037AK T146 R R2325 401 150 5905 MT-GLAZE 270K JA 1/10W 405 147 2205 TR 2SA1037AK T146 S R2326 401 150 5905 MT-GLAZE 10K JA 1/10W 405 002 0308 TR 2SA1037AK T146 S R2326 401 150 5806 MT-GLAZE 33K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2327 401 150 5806 MT-GLAZE 100K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2328 401 162 3708 MT-GLAZE 18K JA 1/10W 405 002 6924 TR 2SA1179-M6 R2329 401 256 7209 MT-GLAZE 18K JA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2330 401 256 7308 MT-GLAZE 68K JA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2331 401 256 6608 MT-GLAZE 68K JA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2331 401 256 6608 MT-GLAZE 68K JA 1/10W 405 173 9605 TR 2SA125A1F R2331 401 256 5908 MT-GLAZE 22K JA 1/10W 405 173 9704 TR 2SA1235A1F R2333 401 256 5908 MT-GLAZE 22K JA 1/10W 405 173 9704 TR 2SA1235A1F R2333 401 256 5908 MT-GLAZE 27K JA 1/10W 405 173 9704 TR 2SA1235A1F R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 172 205 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 5.6K JA 1/10W 405 173 9704 TR 2SA1235A1F R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 172 205 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037AK T146 R R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 15K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2334 401 162 4101 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1235A1E R2346		405 002 6726	TR 2SA1179-M6			
405 163 2708 TR 2SA1179N-M7-TB R2322 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 173 9605 TR 2SA123SA1E R2323 403 343 4603 CERAMIC						
Q2504 405 173 9704 TR 2SA1235A1F R2324 401 256 5809 MT-GLAZE 270K JA 1/10W Q2504 405 134 5925 TR 2SA1037AK T146 R R2325 401 150 5905 MT-GLAZE 10K JA 1/10W 405 147 2205 TR 2SA1037K-T146 S R2326 401 256 1702 MT-GLAZE 33K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2327 401 150 5806 MT-GLAZE 100K JA 1/10W 405 002 6726 TR 2SA1179-M6 R2328 401 162 3708 MT-GLAZE 18K JA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2330 401 256 7308 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2331 401 256 6608 MT-GLAZE 6.8K JA 1/10W 405 163 2708 TR 2SA1159N-M7-TB R2332 401 162 3005 MT-GLAZE 22K JA 1/10W 405 173 9605 TR 2SA1235A1F R2332 401 162 3005 MT-GLAZE 22K JA 1/10W 405 173 9704 TR 2SA1037K T146 R R2333 401 256 3607 MT-GLAZE 2.7K JA 1/10W 405 147 2205 TR 2SA1037K T146 R </td <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
Q2504 405 134 5925 TR 2SA1037AK T146 R R2325 401 150 5905 MT-GLAZE 10K JA 1/10W 405 147 2205 TR 2SA1037AK T146 S R2326 401 256 1702 MT-GLAZE 33K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2327 401 150 5806 MT-GLAZE 100K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2328 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 6726 TR 2SA1179-M6 R2329 401 256 7209 MT-GLAZE 18K JA 1/10W 405 163 1503 TR 2SA1179-M7-TB R2330 401 256 6608 MT-GLAZE 68K JA 1/10W 405 163 2708 TR 2SA1179N-M6-TB R2331 401 256 6608 MT-GLAZE 68K JA 1/10W 405 163 2708 TR 2SA1235A1E R2332 401 162 3005 MT-GLAZE 22K JA 1/10W 405 173 9704 TR 2SA1235A1E R2333 401 256 5908 MT-GLAZE 2.7K JA 1/10W 405 147 2205 TR 2SA1037AK T146 R R2335 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2337						
405 147 2205 TR 2SA1037AK T146 S R2326 401 256 1702 MT-GLAZE 33K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2327 401 150 5806 MT-GLAZE 100K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2328 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 6726 TR 2SA1179-M6 R2329 401 256 7209 MT-GLAZE 18K JA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2330 401 256 7308 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2331 401 256 6608 MT-GLAZE 68K JA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2332 401 162 3005 MT-GLAZE 22K JA 1/10W 405 173 9605 TR 2SA1235A1E R2333 401 256 5908 MT-GLAZE 22K JA 1/10W 405 173 9704 TR 2SA1235A1F R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 134 5925 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 5.6K JA 1/10W 405 103 2038 TR 2SA1037AK T146 S R2336 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 5.6K JA 1/10W 405 002 0407 TR 2SA1279-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 002 0308 TR 2SA1037K-T-96-R R2327 401 150 5806 MT-GLAZE 100K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2328 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 6726 TR 2SA1179-M6 R2329 401 256 7209 MT-GLAZE 18K JA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2330 401 256 7308 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2331 401 256 6608 MT-GLAZE 68K JA 1/10W 405 163 2708 TR 2SA1235A1E R2332 401 162 3005 MT-GLAZE 22K JA 1/10W 405 173 9605 TR 2SA1235A1E R2333 401 256 5908 MT-GLAZE 2.7K JA 1/10W 405 173 9704 TR 2SA1235A1F R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 173 9704 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 15K JA 1/10W 405 147 2205 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037AK T146 R R2336 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 100 JA 1/10W 405 002 6726 TR 2SA1037K-T-96-S R2338 401 256 5600 MT-GLAZE 100 JA 1/10W 405 002 6924 TR 2SA1179-M6-R R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M7-TB R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M7-TB R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1125A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W	U2504					
405 002 0407 TR 2SA1037K-T-96-S R2328 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 6726 TR 2SA1179-M6 R2329 401 256 7209 MT-GLAZE 18K JA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2330 401 256 7308 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2331 401 256 6608 MT-GLAZE 68K JA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2332 401 162 3005 MT-GLAZE 22K JA 1/10W 405 173 9605 TR 2SA1235A1E R2333 401 256 5908 MT-GLAZE 2.7K JA 1/10W 405 173 9704 TR 2SA1235A1F R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 173 9704 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 15K JA 1/10W 405 147 2205 TR 2SA1037AK T146 S R2336 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037AK T146 S R2337 401 162 3708 MT-GLAZE 5.6K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M6-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 002 6726 TR 2SA1179-M6 R2329 401 256 7209 MT-GLAZE 18K JA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2330 401 256 7308 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2331 401 256 6608 MT-GLAZE 68K JA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2332 401 162 3005 MT-GLAZE 22K JA 1/10W 405 173 9605 TR 2SA1235A1E R2333 401 256 5908 MT-GLAZE 2.7K JA 1/10W 405 173 9704 TR 2SA1235A1F R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 173 9704 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 15K JA 1/10W 405 147 2205 TR 2SA1037AK T146 S R2336 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037AK T146 S R2336 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2338 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 002 6924 TR 2SA1179-M7-TB R2330 401 256 7308 MT-GLAZE 6.8K JA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2331 401 256 6608 MT-GLAZE 68K JA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2332 401 162 3005 MT-GLAZE 22K JA 1/10W 405 173 9605 TR 2SA1235A1E R2333 401 256 5908 MT-GLAZE 2.7K JA 1/10W 405 173 9704 TR 2SA1235A1F R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 147 2205 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 15K JA 1/10W 405 147 2205 TR 2SA1037AK T146 S R2336 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2338 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 163 1503 TR 2SA1179N-M6-TB R2331 401 256 6608 MT-GLAZE 68K JA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2332 401 162 3005 MT-GLAZE 22K JA 1/10W 405 173 9605 TR 2SA1235A1E R2333 401 256 5908 MT-GLAZE 2.7K JA 1/10W 405 173 9704 TR 2SA1235A1F R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 134 5925 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 15K JA 1/10W 405 147 2205 TR 2SA1037AK T146 S R2336 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2338 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 163 2708 TR 2SA1179N-M7-TB R2332 401 162 3005 MT-GLAZE 22K JA 1/10W 405 173 9605 TR 2SA1235A1E R2333 401 256 5908 MT-GLAZE 2.7K JA 1/10W 405 173 9704 TR 2SA1235A1F R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 134 5925 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 15K JA 1/10W 405 147 2205 TR 2SA1037AK T146 S R2336 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2338 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 173 9605 TR 2SA1235A1E R2333 401 256 5908 MT-GLAZE 2.7K JA 1/10W 405 173 9704 TR 2SA1235A1F R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 134 5925 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 15K JA 1/10W 405 147 2205 TR 2SA1037AK T146 S R2336 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2338 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
Q2505 405 173 9704 TR 2SA1235A1F R2334 401 162 4101 MT-GLAZE 5.6K JA 1/10W Q2505 405 134 5925 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 15K JA 1/10W 405 147 2205 TR 2SA1037AK T146 S R2336 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2338 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
Q2505 405 134 5925 TR 2SA1037AK T146 R R2335 401 256 3607 MT-GLAZE 15K JA 1/10W 405 147 2205 TR 2SA1037AK T146 S R2336 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2338 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 147 2205 TR 2SA1037AK T146 S R2336 401 162 4101 MT-GLAZE 5.6K JA 1/10W 405 002 0308 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2338 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W	02505					
405 002 0308 TR 2SA1037K-T-96-R R2337 401 162 3708 MT-GLAZE 4.7K JA 1/10W 405 002 0407 TR 2SA1037K-T-96-S R2338 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W	acooo					
405 002 0407 TR 2SA1037K-T-96-S R2338 401 255 6500 MT-GLAZE 100 JA 1/10W 405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 002 6726 TR 2SA1179-M6 R2341 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 002 6924 TR 2SA1179-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 002 6924 TR 2SA1179-M7-TB R2343 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 1503 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 163 1503 TR 2SA1179N-M6-TB R2344 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 163 2708 TR 2SA1179N-M7-TB R2345 401 150 6001 MT-GLAZE 0.000 ZA 1/10W 405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
405 173 9605 TR 2SA1235A1E R2346 401 150 6001 MT-GLAZE 0.000 ZA 1/10W						
				R2347	401 255 6500	

Schematic Location	Part No.	De	scription	Schematic Location	Part No.	Description
R2348	401 255 6500	MT-GLAZE	100 JA 1/10W		MISCELLANE	ous
R2349	401 256 5908	MT-GLAZE	2.7K JA 1/10W	A4351	610 310 1798	ASSY, PWB, VIDEO-H3ABM
R2350	401 255 6500	MT-GLAZE	100 JA 1/10W	X2301	645 047 2794	OSC, CERAMIC 2.696MHZ
R2352	401 255 6500	MT-GLAZE	100 JA 1/10W			
R2353	401 256 6905	MT-GLAZE	680 JA 1/10W		CDT SOCKE	T PC BOARD
R2354	401 162 3104	MT-GLAZE	3.3K JA 1/10W		CHI SOCKI	ET FC BOARD
R2355	401 256 7704	MT-GLAZE	3.9M JA 1/10W		CAPACITORS	
R2356	401 256 7803	MT-GLAZE	390K JA 1/10W	C710	403 069 8305	CERAMIC 0.01U Z 50V
R2357	401 255 6500	MT-GLAZE	100 JA 1/10W	C711	403 161 9200	MT-POLYEST 0.22U K 250V
R2358	401 255 6500	MT-GLAZE	100 JA 1/10W	C721	403 161 9200	MT-POLYEST 0.22U K 250V
R2360	401 162 3708	MT-GLAZE	4.7K JA 1/10W 2.2K JA 1/10W	C731	403 161 9200	MT-POLYEST 0.22U K 250V
R2361	401 150 6100	MT-GLAZE MT-GLAZE	2.2K JA 1/10W 2.2K JA 1/10W	C733	403 057 3107	POLYESTER 0.1U K 50V
R2362	401 150 6100	MT-GLAZE	2K JA 1/10W		403 181 8207	POLYESTER 0.1U K 50V
R2363	401 255 5800 401 255 5800	MT-GLAZE	2K JA 1/10W	★ C742	403 245 5609	ELECT 10U M 250V
R2364 R2365	401 162 2909	MT-GLAZE	220 JA 1/10W	★ C744	403 077 2807	CERAMIC 1000P Z 2K
R2367	401 102 2909	MT-GLAZE	56K JA 1/10W	C754	404 087 0500	ELECT 220U M 10V
R2368	401 250 5504	MT-GLAZE	2.2K JA 1/10W			
R2369	401 150 6100	MT-GLAZE	2.2K JA 1/10W		DIODES	
R2371	401 150 5905	MT-GLAZE	10K JA 1/10W	D711	407 006 3903	DIODE ERB43-04
★ R2380	401 150 5905	MT-GLAZE	10K JA 1/10W		407 011 4407	DIODE TVR1G
R2382	401 150 6001	MT-GLAZE	0.000 ZA 1/10W	D712	407 006 3903	DIODE ERB43-04
R2503	401 152 3206	MT-GLAZE	330 JA 1/10W	B =0.4	407 011 4407	DIODE TVR1G
R2506	401 306 3809	MT-GLAZE	470FA 1/4W	D721	407 006 3903	DIODE ERB43-04
R2507	401 152 3206	MT-GLAZE	330 JA 1/10W	D700	407 011 4407	DIODE TVR1G DIODE ERB43-04
R2508	401 152 3206	MT-GLAZE	330 JA 1/10W	D722	407 006 3903 407 011 4407	DIODE TVR1G
R2510	401 306 3809	MT-GLAZE	470FA 1/4W	D731	407 006 3903	DIODE ERB43-04
R2511	401 306 3809	MT-GLAZE	470FA 1/4W	D/31	407 011 4407	DIODE TVR1G
R2512	401 150 6209	MT-GLAZE	1K JA 1/10W	D732	407 006 3903	DIODE ERB43-04
R2513	401 255 6500	MT-GLAZE	100 JA 1/10W	2102	407 011 4407	DIODE TVR1G
R2514	401 256 1702	MT-GLAZE	33K JA 1/10W	D742	407 124 6404	DIODE ERA18-04
R2516	401 150 6209	MT-GLAZE	1K JA 1/10W	21 12	407 007 6606	DIODE ES1
R2517	401 150 6001	MT-GLAZE	0.000 ZA 1/10W		407 124 5506	DIODE RMPG06G
R2520	401 255 6500	MT-GLAZE	100 JA 1/10W	D754	408 008 2406	DIODE 1N4148
R2522	401 256 1900	MT-GLAZE	3.3M JA 1/10W		407 013 4306	DIODE 1S2076A
R2523	401 255 6500	MT-GLAZE	100 JA 1/10W		407 013 7109	DIODE 1S2473
R2525	401 255 6500	MT-GLAZE	100 JA 1/10W 4.7K FA 1/10W	D755	407 065 1308	ZENER DIODE MTZJ3.68
R2527	401 265 1700	MT-GLAZE MT-GLAZE	10K JA 1/10W	D761	407 099 6607	ZENER DIODE MTZJ12B
R2538	401 150 5905	MT-GLAZE	1K JA 1/10W		407 054 3207	ZENER DIODE RD12EB2
R2543	401 150 6209 401 150 6209	MT-GLAZE	1K JA 1/10W	D762	407 099 6607	ZENER DIODE MTZJ12B
R2544 R2545	401 150 6209	MT-GLAZE	1K JA 1/10W		407 054 3207	ZENER DIODE RD12EB2
R2546	401 162 2909	MT-GLAZE	220 JA 1/10W	D763	407 099 6607	ZENER DIODE MTZJ12B
R2547	401 150 6209	MT-GLAZE	1K JA 1/10W		407 054 3207	ZENER DIODE RD12EB2
R2548	401 256 4109	MT-GLAZE	56 JA 1/10W		INTEGRATED	CIRCUITS
R2560	401 256 4109	MT-GLAZE	56 JA 1/10W	10711	409 542 4406	IC TDA6118JF/N1
R2561	401 256 4109	MT-GLAZE	56 JA 1/10W	10711	409 542 4406	IC TDA6118JF/N1
R2562	401 256 4109	MT-GLAZE	56 JA 1/10W	IC731	409 542 4406	IC TDA6118JF/N1
R2616	401 150 6001	MT-GLAZE	0.000 ZA 1/10W	10701	703 072 1100	10 15/101/100//11
R2617	401 150 6001	MT-GLAZE	0.000 ZA 1/10W		COILS	
R2624	401 150 6001	MT-GLAZE	0.000 ZA 1/10W	Ł710	401 025 7102	CARBON 22 JA 1/6W
R2626	401 150 6001	MT-GLAZE	0.000 ZA 1/10W	L711	645 008 0777	INDUCTOR, 12U K
R2962	401 255 6500	MT-GLAZE	100 JA 1/10W	L721	645 008 0777	INDUCTOR, 12U K
R2963	401 255 6500	MT-GLAZE	100 JA 1/10W	L731	645 008 0777	INDUCTOR, 12U K
R2964	401 255 6500	MT-GLAZE	100 JA 1/10W	L741	645 001 4871	INDUCTOR, 10U K
R2968	401 162 2909	MT-GLAZE	220 JA 1/10W			
R2969	401 162 2909	MT-GLAZE	220 JA 1/10W			
R2985	401 150 5806	MT-GLAZE	100K JA 1/10W			
R2986	401 150 5806	MT-GLAZE	100K JA 1/10W			

			Schematic	David N.C.	Da	cription	
Schematic Location	Part No.	Description	Location	Part No.			
l	TRANSISTOR	S		RESISTORS	o a DDON	400 14	1/4W
0744	405 011 8401	TR 2SC1740S-Q	R701	401 012 4503	CARBON	100 JA 100 JA	
Q711	405 011 8500	TR 2SC1740S-R	R702	401 012 4503	CARBON		1/4W
	405 011 8609	TR 2SC1740S-S	R703	401 012 4503	CARBON	100 JA 100 JA	
	405 017 0003	TR 2SC1815-GR	R711	401 024 6700	CARBON	470 JA	1/4W
	405 012 2101	TR 2SC1815-0	R712	401 020 0801	CARBON CARBON	56 JA	1/6W
	405 012 2309	TR 2SC1815-Y	R713	401 027 2105	CARBON	56 JA	1/6W
	405 157 0505	TR 2SC536NF-NPA	R714	401 027 2105 401 012 4503	CARBON	100 JA	1/4W
	405 151 8705	TR 2SC536NG-NPA	R716	401 012 4303	CARBON	220 JA	1/2W
	405 020 7501	TR 2SC945A-PA	R717	401 025 4903	CARBON	180K JA	1/6W
	405 020 7709	TR 2SC945A-QA	R719	401 024 6700	CARBON	100 JA	1/6W
	405 020 7907	TR 2SC945A-RA	R721 R722	401 020 0801	CARBON	470 JA	1/4W
Q721	405 011 8401	TR 2SC1740S-Q	R723	401 027 2105	CARBON	56 JA	
	405 011 8500	TR 2SC1740S-R	R724	401 027 2105	CARBON	56 JA	1/6W
	405 011 8609	TR 2SC1740S-S	R725	401 012 4503	CARBON	100 JA	
	405 012 2002	TR 2SC1815-GR	R726	401 008 6702	CARBON	220 JA	
	405 012 2101	TR 2SC1815-0	R727	401 012 5708	CARBON	1K JA	1/4W
	405 012 2309	TR 2SC1815-Y	R729	401 025 4606	CARBON	18K JA	
	405 157 0505	TR 2SC536NF-NPA	R731	401 024 6700	CARBON	100 JA	
	405 151 8705	TR 2SC536NG-NPA	R732	401 020 0801	CARBON	470 JA	
	405 020 7501	TR 2SC945A-PA	R733	401 027 2105	CARBON	56 JA	
	405 020 7709	TR 2SC945A-QA	R734	401 027 2105	CARBON	56 JA	
	405 020 7907	TR 2SC945A-RA	R735	401 012 4503	CARBON	100 JA	
Q731	405 011 8401	TR 2SC1740S-Q	R736	401 008 6702	CARBON	220 JA	
	405 011 8500	TR 2SC1740S-R	R737	401 012 5708	CARBON	1K JA	
	405 011 8609	TR 2SC1740S-S	R739	401 012 5708	CARBON	1K JA	
	405 012 2002	TR 2SC1815-GR	★ R741	401 068 6209	OXIDE-MT	5.6 JA	
	405 012 2101	TR 2SC1815-0 TR 2SC1815-Y	R742	401 024 7707	CARBON	100K JA	
	405 012 2309	TR 2SC536NF-NPA	R743	401 025 1902	CARBON	15K JA	
	405 157 0505	TR 2SC536NG-NPA	R744	401 024 7707	CARBON	100K JA	
	405 151 8705	TR 2SC945A-PA	★ R745	401 068 5509	OXIDE-MT	47K JA	
	405 020 7501 405 020 7709	TR 2SC945A-QA	★ R746	401 067 4206	OXIDE-MT	33 JA	
	405 020 7709	TR 2SC945A-RA	R747	401 027 2600	CARBON	5.6K JA	
0744	405 020 7907	TR 2SC1740S-Q	R756	401 024 7004	CARBON	1K JA	
Q741	405 011 8500	TR 2SC1740S-R	R757	401 026 6609	CARBON	390 J <i>A</i> 10K J <i>A</i>	
	405 011 8609	TR 2SC1740S-S	R758	401 024 7400	CARBON		1/6%
	405 012 2002	TR 2SC1815-GR	R759	401 024 6403	CARBON	10 97	1/01
	405 012 2101	TR 2SC1815-0		MISCELLA	SEOLIS		
	405 012 2309	TR 2SC1815-Y	A704	610 311 9236	ASSY, PWE	SOCKET-	H3GLM
	405 157 0505	TR 2SC536NF-NPA	A701	645 028 0306	SOCKET, C		
	405 151 8705	TR 2SC536NG-NPA	★ K702	652 001 1472	SOCKET, C		
	405 020 7501	TR 2SC945A-PA	VI 740	610 216 4268	FILTER, EN		
	405 020 7709	TR 2SC945A-QA	XL710	610 216 4268		AI 120PF	
	405 020 7907	TR 2SC945A-RA	XL720	610 216 4268	FILTER, EN	/II 120PF	
Q742	405 029 7106	TR 2SC2271-D	XL730	010 210 4200	(121211, 411		
QI 72	405 013 6207	TR 2SC2271-D-CTV					
	405 029 7205	TR 2SC2271-E					
	405 013 6306	TR 2SC2271-E-CTV					
Q743	405 101 5600	TR 2SA1786E-AN					
Q753	406 000 6804	TR 2SA1015-GR(SAN)					
Q. 00	405 001 7407	TR 2SA1015-0(SAN)					
	405 001 7605	TR 2SA1015-Y(SAN)					
	405 004 3109	TR 2SA564A-Q(CU)					
	405 004 3208	TR 2SA564A-R(CU)					
	405 151 3304	TR 2SA608NF-NPA					
	405 006 1707	TR 2SA933S-Q					
	405 006 1806	TR 2SA933S-R					

Schema Location		Description		Schematic Location	Part No.	De	scription	
VI	ELOCITY MOD	DULATION PC BOA	BD		405 157 0505	TR 2SC536I		
J =					405 151 8705	TR 2SC5361		
	CAPACITO	RS			405 020 7501	TR 2SC945/		
C1705	404 092 1905	ELECT 100U M	50V		405 020 7709	TR 2SC945A		
C1711	403 057 3107	POLYESTER 0.1U K	50V		405 020 7907	TR 2SC945A		
	403 181 8207	POLYESTER 0.1U K	50V		100 020 7307	111 2003404	THA	
C1712	403 062 0504	POLYESTER 0.047U K	50V		RESISTORS			
	403 179 0909	POLYESTER 0.047U K	50V	R1701	401 024 6700	CARBON	100 JA	1/6
C1713	403 071 5606	CERAMIC 220P K	50V	R1707	401 027 5205	CARBON	680 JA	
C1715	403 159 7409	MT-POLYEST 0.1U K	250V	R1708	401 015 7808	CARBON	2.7 JA	
C1717	404 084 5508	MT-POLYEST 0.1UJ	63V	R1709	401 015 7808	CARBON	2.7 JA	
_	403 237 8007	MT-COMPO 0.1U J	50V	R17 1 1	401 027 2105	CARBON	56 JA	
C1718	404 084 2507	ELECT 47U M	10V	R1716	401 026 3905	CARBON	330 JA	
C1719	403 259 9006	ELECT 10U M	160V	R1720	401 024 9701	CARBON	12K JA	
C1721	404 084 3801	ELECT 1U M	50V	R1722	401 026 4605	CARBON	33K JA	
C1722	403 222 0603	£LECT 22U M	160V	R1723	401 027 2600	CARBON	5.6K JA	1/6\
C1723	403 075 8009	CERAMIC 0.01U K	500V	R1724	401 027 5908	CARBON	68K JA	1/6\
C1724	403 071 5606	CERAMIC 220P K	50V	R1727	401 006 9408	CARBON	10 JB	1/2\
C1748	403 069 8305	CERAMIC 0.01U Z	50V	R1728	401 025 3807	CARBON	180 JA	1/6\
C1749	404 084 4303	ELECT 47U M	50V	★ R1730	401 067 5302	OXIDE-MT	330 JA	21
C1750	403 069 8305	CERAMIC 0.01U Z	50V	R1732	401 024 9305	CARBON	1.2K JA	1/6\
C1751	404 084 3900	ELECT 10U M	50V	R1733	401 024 7707	CARBON	100K JA	1/61
	DIODEC			R1734	401 024 7707	CARBON	100K JA	1/61
D1705	DIODES	DIODE ODGE COM		R1735	401 024 9305	CARBON	1.2K JA	1/6v
D1705 D1707	407 108 5300	DIODE SB07-03N		R1736	401 024 9701	CARBON	12K JA	1/60
D1707 D1708	407 108 5300	DIODE SB07-03N		★ R1737	401 065 1801	OXIDE-MT	12 JA	21
D1700 D1750	407 012 4406	DIODE 1SS133		★ R1738	401 065 1801	OXIDE-MT	12 JA	27
D1750 D1751	407 012 4406 407 012 4406	DIODE 188133		★ R1742	401 066 6102	OXIDE-MT	220 JA	27
D1751	407 012 4406	DIODE 188133		★ R1743	402 063 6706	FUSIBLE RES	270 J-	27
D1732	407 012 4400	DIODE 1SS133		R1744	401 024 9305	CARBON	1.2K JA	1/6V
	COILS				BAICOTLLAND	.0110		
★ L1708	402 001 6300	FUSIBLE RES 10 J- 1/4W		A1701	MISCELLANE 610 314 6133	:OUS - ASSY, PWB, \	/M-H3GLM	ļ.
	TRANSISTORS					7,001,1110,1	IVI TIOULIV	
Q1702	405 011 8401	TR 2SC1740S-Q			DIOITAL DO			
47102	405 011 8500	TR 2SC1740S-R		4000	DIGITAL PC			
	405 011 8609	TR 2SC1740S-S		A900	645 065 0079	UNIT, US DIGI		
	405 012 2002	TR 2SC1815-GR		Nonservicabl	e part. No discreet _l	parts provided f	or this po t	oard.
	405 012 2101	TR 2SC1815-GR						
	405 012 2309	TR 2SC1815-Y			MISCELLAN	MECHIC		
	405 157 0505	TR 2SC536NF-NPA		★ L901	645 064 9240		EO ALIDON	۱۵
	405 151 8705	TR 2SC536NG-NPA		★ Q900	414 012 7108	ASSY, COIL, D	EGAUSSIN	lG
	405 020 7501	TR 2SC945A-PA		A 0300	414 012 8105	CRT W76QEN		
	405 020 7709	TR 2SC945A-QA		SP901	652 001 1311	CRT W76QEN6		
	405 020 7907	TR 2SC945A-RA		SP902	652 001 1311	SPEAKER, 8-5		
Q1706	405 086 8702	TR 2SC4159		★ W901	610 312 7743	SPEAKER, 8-5		·ATA:
	405 086 8801	TR 2SC4159		NA NA	610 311 6440	ASSY, WIRE G		UIUI
Q1707	405 086 8702	TR 2SC4159		147 (010 311 0440	VM BOARD HO	ILDEK IP	
	405 086 8801	TR 2SC4159						
Q1708	405 100 1603	TR 2SA1606-D-RA						
	405 100 1702	TR 2SA1606-E-RA						
Q1709	405 108 4903	TR 2SA1837-LB						
Q1711	405 108 5009	TR 2SC4793-LB						
Q1712	405 011 8401	TR 2SC1740S-Q						
	405 011 8500	TR 2SC1740S-R						
	405 011 8609	TR 2SC1740S-S						
	405 012 2002	TR 2SC1815-GR						ŕ
	405 012 2101	TR 2SC1815-0						Ì
	405 012 2309	TR 2SC1815-Y						
								1

CABINET PARTS LIST




CABINET PARTS LIST

ACCESSORY PARTS LIST


KEY NO.	PARTS NO.	DESCRIPTION	KEY NO.	PARTS NO.	DESCRIPTION
1	610 311 0103	CABINET FRONT-H3GLM		610 312 2304	OWNER'S MANUAL-H3GLM
2	610 268 9648	CRT MTG WASHER (4 USED)		645 065 6897	ASSY, REMOCON FXYA
3	412 053 3905	CRT MTG SCREW (4 USED)		610 312 0744	RC-BATTERY LID-FXYA
4	610 311 0127	CABINET BACK-H3GLM			
5	412 064 4304	SCREW 4X14 (10 USED)			
6	411 026 2303	SCREW 3X10 (5 USED)			
7	610 313 2440	DEC AV SHEET-H3ELM			
8	610 311 6402	CHASSIS RAIL- (3) G7FAM			
9	610 311 9908	ASSY, BUTTON ÙNIT-G7FAM			
10	610 289 5148	CAP RC-G8EAM			
11	610 311 9397	DEC PLATE			
12	645 067 1333	SANYO BADGE			
13	610 313 4093	DEC SHEET VIZON			
9 10 11 12	610 311 9908 610 289 5148 610 311 9397 645 067 1333	CAP RC-G8EAM DEC PLATE SANYO BADGE			

COMPONENT AND TESTPOINT LOCATIONS


MAIN BOARD PARTS SIDE




MAIN BOARD FOIL SIDE




POWER / DEFLECTION BOARD PARTS SIDE




POWER / DEFLECTION BOARD FOIL SIDE





CRT SOCKET BOARD PARTS SIDE




VM BOARD PARTS SIDE









VIDEO BOARD







FRONT PWB PARTS SIDE




FRONT PWB FOIL SIDE




POWER LINES




MAIN CPU DATA BUS LINES




SIGNAL LINES




IC2501 CRT DRIVER BLOCK DIAGRAM



IC3601 AUDIO PROCESSOR BLOCK DIAGRAM




IC3401 AUDIO CONTROL BLOCK DIAGRAM




TROUBLESHOOTING FLOW CHARTS

NO POWER




NO PICTURE



TROUBLE SHOOTING FLOW CHARTS (Cont.)

NO SOUND



CONTROL PORT FUNCTION

System Control (CPU : IC801)

	em control (or	<u>. </u>		
		Function :		
1	P11/SCL1	IIC bus clock for TV	IN	
2	P00	Audio AMP Mute	OUT	Active : High
_3	P01	DM Reset Out	OUT	Reset Out : Low
4	P02	BPF-SW	OUT	Active : High
_ 5	P03/AD1	Key In	IN	
6	P04/PWM4/AD2	AV SW 2	IN	Active : High
7	P05/AD3	AFT S-IN	IN	S-Curve Input (AFT) to Tuner
8	P06/INT2/AD4	ABL In	IN	Active : Low (SDTV only)
9	P07/INT1	RC In	IN	
10	P20/SCLK//AD5	SCLK for DM	OUT	
11	P21/SOUT/AD6	SOUT for DM	OUT	
12	P22/SIN/AD7	SIN for DM	IN	
13	P23/TIM3	CS for DM	OUT	
14	P24/TIM2	Power Fail In	IN	Active : Low
15	P25/INT3	Normal SW	IN	Active : High (SDTV only)
16	P26/XCIN	Status In	IN	IIC bus control for factory, Bus Release Request : Low
17	P27/XCOUT	Ack Out	OUT	IIC bus control for factory, Bus Release Request : Low
18	CNVss	CNVss	-	
19	Xin	Xin	IN	CPU System Clock (8MHz)
20	Xout	Xout	OUT	CPU System Clock (8MHz)
21	Vss	Vss	IN	GND (0Vdc)
22	Vcc	Vcc	IN	+5Vdc±10%
23	FILT	Filter for IC	IN	Capacitor must be connected to Vss.
24	HLF	HLF Out	OUT	For Caption RC - Filter
25	Vhold	Vhold	OUT	For Caption
26	Cvin	CV In	IN	For Caption
27	RESET	Reset In	IN	Reset Input (From H to L)
28	Pullup	Pullup	IN	For UOC (10kΩ)
29	P15	AW SW 1	OUT	Active : High
30	P31/SCL3	IIC bus clock for AV	IN	(HDTV only)
31	P30/SDA3	IIC bus data for AV	OUT	(HDTV only)
32	CLK/cont/P10	Fix/Variable Out	OUT	Fix : Low, Variable : High
33	P55/OUT	OSD BLK Out	OUT	OSD Blanking Output (Negative Polarization)
34	P54/R	OSD R Out	OUT	OSD R Output (Negative Polarization)
35	P53/G	OSD G Out	OUT	OSD G Output (Negative Polarization)
36	P52/B	OSD B Out	OUT	OSD B Output (Negative Polarization)
37	P51/Vsync	Vsync	IN	V-SYNC Input (Negative Polarization)
38	P50/Hsync	Hsync	IN	H-SYNC Input (Negative Polarization)
39	P16/AD8/TIM2	TV Relay Out	OUT	Active : High
40	P14/SDA2	IIC bus data for NVL	OUT	
41	P13/SDA1	IIC bus data for TV	OUT	
42	P22	IIC bus clock for NVL	IN	

For parts or service contact

SANYO Fisher Service Corporation 21605 Plummer Street Chatsworth, CA 91311 (U.S.A.) 300 Applewood Crescent, Concord, Ontario L4K 5C7 (CANADA)

March / 2004 / 2000 SMC

NOTE:

The official *Service Manual* includes two oversized (approximately 24" x 30") double-sided diagrams which are not included in this PDF.

This PDF was made from scanning the original *Service Manual* which was obtained from:

SANYO Manufacturing Corporation 3333 SANYO Road Forrest City, Arkansas 72335

E-mail: support@sanyotv.com Phone: 870-633-5030 Fax: 870-633-0650

The above office gave permission to post this copy on the web for non-commercial use by owners of the Sanyo HT30744 tv.

Gray M. Strickland – gs AT slf DOT us